

dahua DH-N45EFNZ Bullet Network Camera User Guide

Home » Dahua » dahua DH-N45EFNZ Bullet Network Camera User Guide 🖺





Bullet Network Camera Quick Start Guide

Contents

- 1 Foreword
- 2 Important Safeguards and Warnings
- 3 Introduction
- **4 Network Configuration**
- 5 Installation
- 6 Documents / Resources
- 7 Related Posts

Foreword

General

This manual introduces the functions, installation and operations of the camera.

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
WARNING	Indicates a medium or low potential hazard that, if not avoided, could result in slight or moderate injury.
CAUTION	Indicates a potential risk that, if not avoided, could result in property dama ge, data loss, lower performance, or unpredictable result.
NOTE	Provides additional information as the emphasis and supplement to the te xt.

Revision History

Version	Revision Content	Release Date
V1.0.2	Updated "Important Safeguards and Warnings."	Apr-20
V1.0.1	Modify the picture in Figures 1-2.	Jun-20
V1.0.0	First release.	May-20

About the Manual

- The manual is for reference only. If there is an inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, QR code or our official website. If there is an inconsistency between the paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There still might be a deviation in technical data, functions, and operations description, or errors in print. If there is any doubt or dispute, we reserve the right of a final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks, and the company names in the manual are the properties of their respective owners.
- Please visit our website, and contact the supplier or customer service if there is any problem occurring when using the device.
- If there is any uncertainty or controversy, we reserve the right of a final explanation.

Important Safeguards and Warnings

Electrical Safety

- All installation and operation shall conform to your local electrical safety codes.
- The power source shall conform to the Safety Extra Low Voltage (SELV) standard, and supply power with a

rated voltage that conforms to the Limited Power Source requirement according to IEC60950-1. Note that the power supply requirement is subject to the device label.

- Make sure that the power supply is correct before operating the device.
- A readily accessible disconnecting device shall be incorporated in the building installation wiring.
- Prevent the power cable from being trampled or pressed, especially the plug, power socket, and junction extruded from the device.

Environment

- Do not aim the device at strong light to focus, such as lamp light and sunlight; otherwise, it might cause over brightness or light marks, which are not the device malfunction, and affect the longevity of Complementary Metal-Oxide Semiconductor (CMOS).
- Do not place the device in a damp, dusty extremely hot or cold environment, or locations with strong electromagnetic radiation or unstable lighting.
- Keep the device away from any liquid to avoid damage to the internal components.
- Keep the indoor device away from rain or dampness to avoid fire or lightning.
- Keep sound ventilation to avoid heat accumulation.
- Transport, use, and store the device within the range of allowed humidity and temperature.
- Heavy stress, violent vibration, or water splash are not allowed during transportation, storage, and installation.
- Pack the device with standard factory packaging or the equivalent material when transporting the device.
- Install the device in a location where only professional staff with relevant knowledge of safety guards and warnings can access it. The accidental injury might happen to the non-professionals who enter the installation area when the device is operating normally.

Operation and Daily Maintenance

- Do not touch the heat dissipation component of the device to avoid scalding.
- Carefully follow the instructions in the manual when performing any disassembly operation on the device; otherwise, it might cause water leakage or poor image quality due to unprofessional disassembly. Please make sure that the gasket ring is flat and properly installed in the groove before installing the cover. Please contact after-sale service for desiccant replacement if there is condensed fog on the lens after unpacking or when the desiccant turns green (Not all models are included with the desiccant).
- It is recommended to use the device together with a lightning arrester to improve the lightning protection effect.
- It is recommended to ground the device to enhance reliability.
- Do not touch the image sensor (CMOS) directly. Dust and dirt could be removed with an air blower, or you can wipe the lens gently with a soft cloth that is moistened with alcohol.
- You can clean the device body with a soft dry cloth, and for stubborn stains, use the cloth with mild detergent.
 To avoid possible damage to the device body coating which could cause a performance decrease, do not use volatile solvents such as alcohol, benzene, diluent, and so on to clean the device body, nor can strong, abrasive detergent be used.
- The Dome cover is an optical component. Do not touch or wipe the cover with your hands directly during installation or operation. For removing dust, grease or fingerprints, wipe gently with moistened oil-free cotton with diethyl or moisten the soft cloth. You can also remove dust with an air blower.



- Strengthen the protection of network, device data, and personal information by adopting measures that include but are not limited to using a strong password, modifying passwords regularly, upgrading the firmware to the latest version, and isolating the computer network. For some devices with old firmware versions, the ONVIF password will not be modified automatically along with the modification of the system password, and you need to upgrade the firmware or manually update the ONVIF password.
- Use standard components or accessories provided by the manufacturer and make sure that the device is installed and maintained by professional engineers.
- The surface of the image sensor should not be exposed to laser beam radiation in an environment where a laser beam device is used.
- Do not provide two or more power supply sources for the device unless otherwise specified. A failure to follow this instruction might cause damage to the device.

Introduction

1.1 Cable



- Cable types might vary with different devices, and the actual product shall prevail.
- Waterproof all the cable joints with insulating tape and waterproof tape to avoid short circuits and water damage. For the detailed operation, see the FAQ Manual.

For more information about cable ports, see Table 1-1. Table 1-1 Cable information

No.	Port name	Description
1	12V DC power input	Inputs 12V DC power. Be sure to supply power as instructed in the ma nual. Device abnormity or damage might occur if power is not supplied correctly.
2	Ethernet port	 Connects to network with a network cable. Provides power to the device with PoE. PoE is available on select models.
3	Alarm I/O	Includes alarm signal input and output ports, the number of I/O ports might vary on different devices. For detailed information, see Table 1-2.
4	Audio input	Connects to sound pickups to receive the audio signals. Audio input is available on select models.
5	Audio output	Connects to the speaker to output audio signal. Audio output is available on select models.

For more information about I/O port, see Table 1-2.

Table 1-2 Alarm information

Port	Port Name	Description
	ALARM_OUT	Outputs alarm signal to the alarm device.
Alarm I/O	ALARM_IN	Receives the switch signal of the external alarm source.
	ALARM_GND	Ground connection.

1.2 Connecting Alarm Input/Output

The camera can connect to the external alarm input/output device through the digital input/output port.




Alarm input/output is available on select models.

Step 1 Connect the alarm input device to the alarm input end of the I/O port. See Figures 1-2. The device collects different states of alarm input port when the input signal is idling and being grounded.

- \bullet The device collects logic "1" when the input signal is connected to +3V to +5V or idling.
- The device collects logic "0" when the input signal is grounded.


Figure 1-2 Alarm input



Step 2 Connect the alarm output device to the alarm output end of the I/O port. The alarm output is an open-drain output, which works in the following modes.

- Mode A: Level application. The alarm outputs high and low levels, and the alarm outlet is OD, which requires external pull-up resistance (10K Ohm typical) to work. The maximum external pull-up level is 12V, the maximum port current is 300mA and the default output signal is high-level (external pull-up voltage). The default output signal switches to low-level when there is alarm output (As long as the operating current is below 300mA, the output low-level voltage is lower than 0.8V).
- Mode B: Switch application. The alarm output is used to drive an external circuit, the maximum voltage is 12V and the maximum current is 300mA. If the voltage is higher than 12V, please use an additional electric relay.

Figure 1-3 Mode A



Step 3 Log in to the web interface, and configure alarm input and alarm output in the alarm setting.

- The alarm input on the web interface is corresponding to the alarm input end of the I/O port. There will be high-level and low-level alarm signals generated by the alarm input device when an alarm occurs, set the input mode to "NO" (default) if the alarm input signal is logic "0" and to "NC" if the alarm input signal is logic "1".
- The alarm output on the web interface is corresponding to the alarm output end of the device, which is also the alarm output end of the I/O port.

Network Configuration

Device initialization and IP setting can be finished with the "ConfigTool" or on the web interface. For more information, see the Web Operation Manual.



- Device initialization is available on select models, and it is required at first-time use and after the device is reset.
- Device initialization is available only when the IP addresses of the device (192.168.1.108 by default) and the PC stays in the same network segment.
- Plan usable network segments properly to connect the device to the network.
- The following figures and interfaces are for reference only, and the actual product shall prevail.

2.1 Initializing Device

Step 1 Double-click "ConfigTool.exe" to open the tool.



The Modify IP interface is displayed.




Figure 2-1 Modify IP

Step 3 Click the Search setting.

The Setting interface is displayed.

Step 4 Enter the start IP address and end IP address of the network segment in which you want to search devices, and then click OK.

All the devices found in the network segment are listed.


Step 5 Select one or several devices in uninitialized status, and then click Initialize.

The Device initialization interface is displayed.

Step 6 Select the devices that need initialization, and then click Initialize.

The password setting interface is displayed.

Figure 2-2 Password setting



Step 7 Set and confirm the password of the devices, then enter a valid email address, and then click Next. The final setting interface is displayed.



Password can be modified or reset in System Settings.

Step 8 Select the options according to your needs, and then click OK.

The Initialization interface is displayed after initialization is completed. Click the success icon (\checkmark) or the failure icon (\checkmark) for the details.

Step 9 Click Finish.

The device status on the Modify IP interface (Figure 2-1) turns to Initialized.

2.2 Modifying Device IP Address



- You can modify IP address of one or multiple devices at one time. This section is based on modifying IP addresses in batches.
- Modifying IP addresses in batches is available only when the corresponding devices have the same login password.


Step 1 Do Step1 to Step4 in "2.1 Initializing Device" to search devices in your network segment.



After clicking the Search setting, enter the username and password, and make sure that they are the same as

what you set during initialization; otherwise, there will be a wrong password notice. Step 2 Select the devices whose IP addresses need to be modified, and then click Modify IP. The Modify IP Address interface is displayed.

Figure 2-3 Modify IP address



Step 3 Select Static mode, and then enter start IP, subnet mask, and gateway.



- IP addresses of multiple devices will be set to the same if you select the Same IP check box.
- If a DHCP server is available in the network, devices will automatically obtain IP addresses from the DHCP server when you select DHCP.

Step 4 Click OK.

2.3 Logging into Web Interface


Step 1 Open the IE browser, enter the IP address of the device in the address bar, and then press the Enter key. If the setup wizard is displayed, finish the settings as instructed.

Step 2 Enter the username and password in the login box, and then click Login.

Step 3 For the first-time login, click Click Here to Download Plugin and then install the plugin as instructed.

The main interface is displayed when the installation is finished.

Figure 2-4 Main interface




Installation

3.1 Packing List



- The tool required for the installation such as electric drill is not provided in the package.
- The operation manual and related tool information are contained in the disk or the QR code, and the actual package shall prevail.


Figure 3-1 Packing list






The following figures are for reference only, and the actual product shall prevail.

Figure 3-2 Dimensions (Unit: mm [inch])



3.3 Installing Camera 3.3.1 Installation Method

Figure 3-3 Installation method




3.3.2 Installing SD Card (Optional)



- SD card slot is available on select models.
- Disconnect the power before installing or removing the SD card.

Figure 3-4 Installing SD card



Press the reset button for 10 seconds to reset the device.

3.3.3 Attaching Camera



Make sure that the mounting surface is strong enough to hold at least three times of the weight of the device and bracket.

Figure 3-5 Cable going through the side cable tray





Figure 3-6 Cable going through the mounting surface



3.3.4 Installing Waterproof Connector (Optional)



This part is needed only when there is a waterproof connector in the package and the device is used outdoors.

Figure 3-7 Installing waterproof connector





Figure 3-8 Adjusting lens angle



Dahua Technology USA

15245 Alton Parkway, Suite #100 Irvine, CA 92618 Tel: (949) 679-7777

Fax: (949) 679-5760 Support: 877-606-1590

Sales: sales.usa@dahuatech.com
Support: support.usa@dahuatech.com

© 2021 Dahua Technology USA. All rights reserved. Design and specifications are subject to change without notice.

Documents / Resources



dahua DH-N45EFNZ Bullet Network Camera [pdf] User Guide

DH-N45EFNZ, Bullet Network Camera, DH-N45EFNZ Bullet Network Camera, Network Camera, Camera

Manuals+, home privacy