



Danfoss 80G8650  
Gateway Unit



# Danfoss 80G8650 Gateway Unit Installation Guide

[Home](#) » [Danfoss](#) » Danfoss 80G8650 Gateway Unit Installation Guide 

## Contents

- 1 [Danfoss 80G8650 Gateway Unit](#)
- 2 [Product Usage Instructions](#)
- 3 [DIMENSION](#)
- 4 [INSTALLATION](#)
- 5 [REAR VIEW](#)
- 6 [FACTORY SETTINGS](#)
- 7 [General IT security recommendations](#)
- 8 [POWER SUPPLY](#)
- 9 [CONNECTIONS](#)
- 10 [OPTIONAL PLUGIN MODULE](#)
- 11 [TECHNICAL DATA](#)
- 12 [PRODUCT IDENTIFICATION](#)
- 13 [INSTALLATION PROCEDURE](#)
- 14 [Documents / Resources](#)
  - 14.1 [References](#)
- 15 [Related Posts](#)



**Danfoss 80G8650 Gateway Unit**



## Specifications

- Model: Gateway Unit Type X-Gate
- Dimensions:
  - Height: 75 mm (2.95 inches)
  - Width: 25.4 mm (1.0 inches)
  - Depth: 110 mm (4.33 inches)
- Ports:
  - 1 USB 2.0 OTG (Type C, 500 mA max.)
  - 2 Ethernet Ports (10/100 BaseT)
  - RS485/CAN ports
- Power Supply: L2 (-) 24 V, L1 (+)
- CPU: i.MX6UL ARM Cortex A7 Single Core 528 MHz
- Operating System: Linux Yocto
- Memory: 4GB Flash, 512MB RAM
- Real-Time Clock (RTC Back-up): Yes (SuperCAP)
- Weight: 0.140 Kg

## Product Usage Instructions

### Installation

Ensure the unit is grounded to earth using terminal 3 on the power supply terminal block.

### Power Supply

Verify that the power supply can provide sufficient power for the equipment's operation.

### Connection Setup

Connect ETH1/WAN via DHCP and ETH2/LAN with the IP Address 192.168.2.101, Subnet mask 255.255.255.0. Access settings at <https://192.168.2.101/> with Username: admin and Password: PASS.

### CAN Bus Termination

To enable CAN bus termination, connect pins 1-2 externally. The RS485 A+ has an internal pull-up resistor, and the RS485 B- has an internal pull-down resistor. RS485 +5V is optional for external bias resistors.

## Optional Plugin Modules

The unit supports multiple optional plugin modules, allowing for various configurations.

## FAQ


### Q: What are the recommended IT security practices for the X-Gate series?

A: The X-Gate device should be installed behind a router and firewall, following general IT security recommendations and best practices to ensure secure operation.


### Q: How do I configure the network settings for the X-Gate?

A: Connect ETH1/WAN via DHCP and ETH2/LAN with specific IP settings as mentioned in the manual. Access further settings using the provided URL, Username, and Password.

## DIMENSION




## INSTALLATION



The X-Gate is suitable for mounting on a DIN rail.

## REAR VIEW



1	USB 2.0 OTG (500 mA max., Type C) <sup>(1)</sup>	4	RS485/CAN ports
2	Ethernet Port 2 (10/100 BaseT)	5	Power supply
3	Ethernet Port 1 (10/100 BaseT)	6	Expansion slot for plug-in modules

for maintenance only

## FACTORY SETTINGS

- ETH1 / WAN : DHCP
- ETH2 / LAN : IP Address 192.168.2.101
- Subnet mask : 255.255.255.0
- Settings : <https://192.168.2.101/>
- Username : admin
- Password : PASS


Don't open the panel rear cover when the power supply is applied.

## General IT security recommendations

The X-Gate series device is an embedded controller designed to be installed behind an appropriate router and firewall. Whilst the X-Gate offers many IT industry security technologies, Danfoss strongly recommends the deployment using IT security best practices and protocols.

## POWER SUPPLY


•



Power Connector, Female – R/C Terminal Blocks (XCFR2), manufactured by Weidmuller Inc., Cat. No. BLZ 5.08, torque 4.5 lb-in.


- 3 conductor 1,5 mm<sup>2</sup> wire size minimum, minimum temperature conductor rating 105 °C.
- Do not open the cabinet while the system is powered up.
- **WARNING:** Do not separate when energized.

- The unit must always be grounded to earth. Earth connection will have to be done using terminal 3 on the power supply terminal block.



- Ensure that the power supply has enough power capacity for the operation of the equipment.

### CONNECTIONS



To enable CAN bus termination (R120Ω) pins 1-2 must be connected externally. The RS485 A+ comes with an internal pull-up/bias resistor of 680 Ω enabled by software.


### OPTIONAL PLUGIN MODULE

The panels have several optional plugin module, multiple modules configurations are possible.


### TECHNICAL DATA

Features	Description
Model	X-Gate
CPU	i.MX6UL ARM Cortex A7 Single Core – 528 MHz
Operating System	Linux Yocto
Flash	4GB
RAM	512MB
Real Time Clock (RTC Back-up)	Yes (SuperCAP)
LED	1 – RGB
Ethernet port	2 – 10/100 BaseT
USB port	1 – USB 2.0 OTG (500 mA max., Type C)
RS485 port	1 (isolated, Modbus Master/Slave configuration)
CAN/CAN-FD port	1 (isolated)
Expansion port	Yes
Power supply	24 V AC/DC (not isolated) +/-15%
Current Consumption	1.06A max. at 24 V AC, 1.56 A max. at 24 V DC
Input Protection	Electronic Fuse
Operating Temp	-20 – +60 °C
Storage Temp	-30 – +70 °C
Operating / Storage Humidity	5 – 90% RH, non-condensing
Protection Class	IP20
Weight	0.140 Kg


## PRODUCT IDENTIFICATION



## INSTALLATION PROCEDURE







The products have been designed in compliance with:

- EN 61000-6-3
- EN 61000-6-2
- FCC Part 15 Subpart B Class A
- ICES-003 issue7 Class B



■ This device cannot be disposed of as a domestic waste but according to WEEE European Directive 2012/19/EU

User Manual available on su: [www.danfoss.com](http://www.danfoss.com)

Reproduction of the contents of this copyrighted document, in whole or part, without written permission of Danfoss, is prohibited.

#### **DISCLAIMER:** Professional Use Only

- This product is not subject to the UK PSTI regulation, as it is for supply to and use only by professionals with the necessary expertise and qualifications. Any misuse or improper handling may result in unintended consequences. By purchasing or using this product, you acknowledge and accept the professional-use-only nature of its application. Danfoss does not assume any liability for damages, injuries, or adverse consequences (“damage”) resulting from the incorrect or improper use of the product and you agree to indemnify Danfoss for any such damage resulting from your incorrect or improper use of the product.



DanfossA/S

- Climate Solutions • [danfoss.com](https://danfoss.com) • +45 7488 2222
- Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, on line or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material.
- Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or . COMfunction of the product.
- All trademarks in this material are property of Danfoss A/5 or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/5. All rights reserved.

## Documents / Resources

	<a href="#">Danfoss 80G8650 Gateway Unit</a> [pdf] Installation Guide 80G8650, 80G8651, 80G8607, 80G8652, 80G8653, 80G8650 Gateway Unit, 80G8650, Gateway Unit, Unit
---	---

## References

-  [Engineering Tomorrow | Danfoss](#)
-  [Engineering Tomorrow | Danfoss](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.