

**Danfoss**

**AME 11  
Electrical  
Actuator**



## Danfoss AME 11 Electrical Actuator User Guide

[Home](#) » [Danfoss](#) » Danfoss AME 11 Electrical Actuator User Guide 

### Contents

- [1 Danfoss AME 11 Electrical Actuator](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Models](#)
- [6 Tools](#)
- [7 Safety Notes](#)
- [8 Mounting](#)
- [9 Wiring](#)
- [10 DIP switch settings](#)
- [11 Dimensions](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)

**Danfoss**

**Danfoss AME 11 Electrical Actuator**



## Specifications

- Model: AME 10, AME 11
- Maintenance: Maintenance Free
- Operating Conditions: 5-95% RH, no condensing
- Protection Rating: IP 54
- Wiring: A, B, Neutral Power supply
- Supply Voltage: 24 V~ -15 to +10%, 50/60 Hz

## Product Usage Instructions

### Mounting:

Fix the actuator on the valve.

### Wiring:

- **Control Signal:** Connect the control signal from the controller to terminals Y (input signal) and SN (common) on the AME printed board.
- **Output Signal:** Use the output signal from terminal X for an indication of the current position. The range depends on the DIP switch settings.

### Supply Voltage:

Connect the supply voltage (24 V~ -15 to +10%, 50/60 Hz) to the SN and SP terminals.

## FAQ


- **Q: What should I do to avoid injury and device damage?**

- **A:** Read and observe all safety notes carefully. Assembly, start-up, and maintenance should be done by qualified personnel only.


• **Q: How should I dispose of the product?**

- **A:** Dismantle the product and sort its components for recycling or disposal following local regulations.

## Models



## Tools



## Safety Notes

To avoid injury of persons and damages to the device, it is absolutely necessary to read and observe these instructions carefully. Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only. Please comply with the instructions of the system manufacturer or system operator.








## Disposal instruction





This product should be dismantled and its components sorted, if possible, in various groups before recycling or disposal. Always follow the local disposal regulations.

## Mounting





Fix the actuator on the valve.

1





O = min 6.3 / max 8.9 mm





	CLOSE	OPEN
A ↓		
B ↑		

## Wiring

DIP 6 = OFF

#### Wiring for modulating mode





SN	0 Vac	Neutral
SP	24 Vac	Power supply
Y	0(2)-10 Vdc 0(4)-20 mA	Input
1	0 Vac	Input
3		
X	0(2)-10 Vdc	Output

DIP 6 = ON

Actuator needs to perform Self stroking prior changing DIP 6 to ON.  
Output signal depends on DIP 2, 3&5 setting.



#### Wiring for 3-point floating mode / Controller with relay output



SN	0 Vac	Neutral
SP	24 Vac	Power supply
1	24 Vac	Input
3		
X	0(2)-10 Vdc	Output

DIP 6 = ON

#### Wiring for 3-point floating mode / Controller with triacs output



SN	0 Vac	Neutral
SP	24 Vac	Power supply
1	24 Vac	Input
3		
X	0(2)-10 Vdc	Output

\* Only for actuators with safety function  
\*\*R1, \*\*R2=2.6 kΩ (0.5W)

## Control signal

Control signal from the controller must be connected to terminals Y (input signal) and SN (common) on the AME printed board.



## Output signal

Output signal from the terminal X can be used for indication of the current position. Range depends on the DIP switch settings.

## Supply voltage

Supply voltage (24 V~ -15 to +10 %, 50/60 Hz) must be connected to the terminals SN and SP.

## DIP switch settings



## Factory settings:

**ALL switches are on OFF position! ①**

Note: All combinations of DIP switches are allowed. All functions that are selected are added consecutively. There is only one logic override of functionalities i.e. the switch No.6 Proportional / 3 point, which sets actuator to ignore control signal and works as a “simple” 3-point actuator.

## **SW1: U/I ②**

The actuator can respond to a voltage or current control signal. With switch No.1: U/I actuator can be set either to operate with a voltage control signal (actuator responds to signal between 0-10 V), or current control signal (actuator responds to signal between 0-20 mA).

Factory setting: voltage control signal (0-10 V).

## **SW2: 2 V-10 / 0 V-10 ③**

The actuator can be set to respond on a control signal from 2 V, or 0 V. If the actuator is set current signal then it responds to a control signal from 4 mA or 0 mA.

Factory setting is: 2-10 V.

## **SW3: Direct/Inverse ④**

The actuator can be set for spindle to travel downwards on rising control signal (DIRECT), OR for the spindle to travel upwards on rising control signal (INVERSE).

Factory setting is: DIRECT

## **SW4: —/Sequential ⑤**

Two actuators can be set to work parallel with one control signal. If the SEQUENTIAL is set then an actuator responds to split control signal (see 0(2)-5(6) V/ 6(6)-10 V).

Note: This combination works in combination with switch No.5: 0(2)-5(6) V/ 6(6)-10 V

## **SW5: 0(2)-5(6) V/6(6)-10 V ⑥**

Note: This function is available if switch No.4:

— / Sequential is set.

## **SW6: Proportional/3 point ⑦**

Actuator needs to perform Self stroking prior to changing DIP 6 to ON. Output signal depends on DIP 2, and 3&5 setting. Actuator can operate in modulating (DIP 6 to OFF) or in "simple" 3-point mode, if the 3-point function is selected (DIP 6 to ON). Connect power supply on terminals SN and SP terminals. Factory set DIP 6 to OFF for operating actuator in Modulating mode. Actuator's stem will run to its totally extended or retracted position by bridging SN signal to terminals 1 or 3 and will remain in this position as long as potential is present. Set DIP 6 to ON for operating the actuator in 3-point mode. Look carefully wiring diagram as wiring is different for controllers with triac output (ECL) in comparison to controllers with relay output. Return signal X indicates the correct position. Note: If the 3-point function is selected actuator does not respond to any control signal on port Y. It only rises and lowers spindle if power is supplied on port 1 or 3.

## **SW7: LOG/LIN – Not in use.**

## **SW8: 100 % kVS/Reduced kVS – Not in use.**

## **SW9: Reset ⑧**



## Function test

## Constant light

- No light**

- ### Intermittent light (1 Hz)

- Intermittent light (3 Hz):**

- ## Dimensions

**4**

121

107

min. 200

121

M.D.063.1/02

M.V.D.055.1/01

H<sub>1</sub>

M.V.D.055.1/01

H<sub>2</sub>

M.V.D.055.1/01

H<sub>3</sub>

M.V.D.055.1/01

H<sub>4</sub>

M.V.D.055.1/01

H<sub>5</sub>

M.V.D.055.1/01

H<sub>6</sub>

see AVQM data sheet

see AVQM data sheet

see AVQM data sheet

AVQM 10, 11, 16

AVQM 10, 11, 16

AVQM 10, 11, 16

DN	H 1	H 2	H 3	H 4
	mm			
15	163	–	159	192
20	163	149	159	192
25	163	155	164	192
32		–	169	–
40	–	–	174	–

Part Name	Hazardous Substances Table					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Plug	X	O	O	O	O	O
Bush	X	O	O	O	O	O
O: Indicates that this hazardous substance contained in all of the homogeneous material for this part is below the limit requirement in GB/T 26572;						
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement in GB/T 26572;						


## Danfoss A/S

- Climate Solutions
- [danfoss.com](https://danfoss.com)
- +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogs descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

## Documents / Resources

	<p><a href="#">Danfoss AME 11 Electrical Actuator</a> [pdf] User Guide  AME 11 Electrical Actuator, AME 11, Electrical Actuator, Actuator</p>
---	---

## References

- [Danfoss värmelösningar | Effektiva lösningar för överlägsen komfort | Danfoss](#)
- [Engineering Tomorrow | Danfoss](#)
- [Danfoss](#)
- [Danfoss España: Soluciones innovadoras y ahorro de energía | Danfoss](#)
- [Danfoss - Kestävää tulevaisuuden tekniikka | Danfoss](#)
- [Danfoss France - économie d'énergie et solutions innovantes | Danfoss](#)
- [Danfoss Engineering Tomorrow - ontdek energie-efficiënte en innovatieve oplossingen voor uw branche | Danfoss](#)
- [Danfoss – Engineering Tomorrow | Danfoss](#)
- [Engineering Tomorrow | Danfoss](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.