



DST X520 Rotary Position  
Sensor



# Danfoss DST X520 Rotary Position Sensor Installation Guide

[Home](#) » [Danfoss](#) » Danfoss DST X520 Rotary Position Sensor Installation Guide 

## Contents

- [1 Danfoss DST X520 Rotary Position Sensor](#)
- [2 Specifications](#)
- [3 ELECTRICAL CONNECTIONS](#)
- [4 FAQs](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)



**Danfoss DST X520 Rotary Position Sensor**




## Specifications

- **Product** Rotary sensor without shaft DST X520
- **Manufacturer** Danfoss A/S
- **Output Options:** CW Output, CCW Output, 0.5Vdc Output, 4.5Vdc Output
- **Electrical Connections** AMP Superseal 6-pole 282108-1 connector
- **Cable Version** 6 wires 18 AWG, 1.65 mm OD

## ROTATION DIRECTION


### AMP VERSION

The output increases  
for versions CCW




Zero angular position of 0 °

## CABLE VERSION



**Ex 098G1500**


SINGLE-  $\pm 90^\circ$ - supply 7Vdc – output 0.5..4.5V – clockwise CW



## ELECTRICAL CONNECTIONS

### AMP VERSION

## AMP Superseal 6-pole 282108-1 connector



### CONNECTIONS


1. GROUND 1
2. + SUPPLY 1
3. OUTPUT 1
4. GROUND 2
5. + SUPPLY 2
6. OUTPUT 2

### CAN CONNECTIONS

1. OV (GND)
2. +Vs (+9 ... +36 Vdc)
3. NC
4. NC
5. CAN-L
6. CAN-H

### CABLE VERSION

6 wires 18 AWG 1.65 mm OD



## CONNECTIONS

- Black. GROUND 1
- Red. + SUPPLY 1
- Yellow. OUTPUT 1
- Green. GROUND 2
- Blue. + SUPPLY 2
- White. OUTPUT 2

## CAN CONNECTIONS

1. OV (GND)
2. +Vs (+9 ... +36 Vdc)
3. NC
4. NC
5. CAN-L
6. CAN-H

To ensure the degree of protection IPX9, the connector must be coupled with an AMP 282600-1 female connector.

## DST X520

HALL-EFFECT SINGLE-TURN ROTARY SENSOR WITHOUT SHAFT Danfoss A/S 6430 Nordborg Denmark  
[www.danfoss.com](http://www.danfoss.com)

## WARNINGS AND SAFETY

Although all of the information in this manual has been carefully checked, Danfoss A/S assumes no liability regarding the presence of any errors or damage to property and/or harm to individuals due to any improper use of this manual. Danfoss A/S also reserves the right to make changes to the contents and form of this manual and to the characteristics of the devices illustrated at any time and without prior warning. The installation of the devices illustrated in the manual must be carried out by qualified technicians in compliance with the laws and standards in force and agreement with the instructions contained in the manual. The system should be used only for the

expected protection. The sensor must be used by the environmental features and performance of the instrument.

## LOAD CONDITIONS

- +0.5Vdc...+4.5 Vdc output with power +9...+36Vdc and +0..10Vdc output with power +11..36Vdc: it is recommended a load resistance > 100 K $\Omega$
- +0.5Vdc...+4.5 Vdc output with power +5 Vdc: it is recommended a load resistance > 10 K $\Omega$
- +4...20 mA output with power < + 15..36Vdc: the maximum load resistance is admissible 200 $\Omega$
- +4...20 mA output with power > + 15..36Vdc: the maximum load resistance is admissible 500 $\Omega$

## MAGNETS

- Magnet should NOT be incorporated in a ferromagnetic housing (Holder)
- Magnet should NOT be installed in close contact with a surface of ferromagnetic material
- If the magnet is incorporated in a housing (holder) of ferromagnetic material or is installed in close contact with a surface of ferromagnetic material, the magnetic field is reduced
- If the magnetic field is reduced, the Air Gap value is no longer guaranteed up to 7 mm, and the useful working distance magnet-sensor is reduced to <5 mm
- If the application does not allow to use of a material for the magnet bearing surface is necessary to raise the magnet by at least 1 cm
- To raise the magnet of at least 1 cm from the ferromagnetic surface we recommend to use NON ferromagnetic screws or spacers

## MOUNTING

**Mount the sensor using M4 screws in nonmagnetic stainless steel** eg AISI 316 or brass (not included). The maximum torque amounts to 2.5Nm.

- It is recommended to use M12 female connectors with a key interface, in order to mount with specified torque using a torque spanner.
- In a harsh environment, we recommend using thread sealing liquid.

Danfoss A/S with the “CE” mark manufactured according to the Community Directives and the related National Legislation of conception:

- 2011/65/EU Restriction of the use of certain hazardous substances (RoHS)
- 2014/30/EU Electromagnetic Compatibility (EMC)
- 2001/95/EC General product safety

## FAQs


### **Q: What are the recommended load resistances for different output options?**

A: The manual specifies load resistance recommendations based on the output voltage and power supply. Refer to the manual for detailed information.

### **Q: Can magnets be used with the rotary sensor?**

A: Yes, magnets can be used with the rotary sensor for specific applications. Follow manufacturer guidelines for proper magnet use.

## Documents / Resources



### [Danfoss DST X520 Rotary Position Sensor](#) [pdf] Installation Guide

DST X520, DST X520 Rotary Position Sensor, DST X520, Rotary Position Sensor, Position Sensor, Sensor

## References

- [User Manual](#)

### [Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.