



# Danfoss EVRH 10 22 Solenoid Valve Types Installation Guide

Home » Danfoss » Danfoss EVRH 10 22 Solenoid Valve Types Installation Guide The Danfoss solenoid Valve Types Installation Guide



#### **Contents**

- 1 Danfoss EVRH 10 22 Solenoid Valve
- **Types**
- 2 Specifications
- 3 Installation
- 4 Usage
- **5 Maintenance**
- 6 FAQ
- 7 Documents / Resources

7.1 References




Danfoss EVRH 10 22 Solenoid Valve Types





# Refrigerants:


R744, R22/R407C, R404A/R507, R410A, R134a, R407A, R23. For other refrigerants, please contact Danfoss.













Туре	[Nm]	[kpm]	[ft-lbs]	Torx size
EVRH 10	5	0.5	3.6	T30
EVRH 15 – 18	14	1.4	10	T30
EVRH 20 – 22	20	2.0	14	T40

# **UL** approved coils






# 14 W a.c.


$$t_{max} = 122 \, ^{\circ}F \, (50 \, ^{\circ}C)$$


$$t_{min.}$$
 = -40 °F (- 40 °C)


## Data on armature tube US data on label



Min. medium temperature	-40 °C (-40 °F)			
Max. medium temperature	-105 °C (221°F)			
Max. working pressure PS/MWP	45.2 barg / 655 psig			
Max. opening diff. pressure MOPD	<b>→</b> □○			









## **Specifications**

- Refrigerants: R744, R22/R407C, R404A/R507, R410A, R134a, R407A, R23
- Coil Types: EVRH 10, EVRH 15, EVRH 18, EVRH 20, EVRH 22 (NC), EVRH 10, EVRH 15, EVRH 20, EVRH (NO)
- · UL Approved Coils

### Installation

- 1. Ensure the O-ring is in place before installation.
- 2. Refer to specific tube construction details for proper installation.
- 3. Do not switch on power to the coil when dismounted from the valve to prevent damage and injuries.





## **Usage**

- Ensure the coil is properly mounted on the valve before powering on.
- Consult the label for data on armature tube and other specifications.
- Follow the recommended Torx size for installation.

#### Maintenance

- 1. Regularly check for any leaks or damages.
- 2. Keep the coil and valve clean from dirt and debris.

### **FAQ**

### Q: Can I use other refrigerants not listed in the manual?

A: For other refrigerants, please contact Danfoss for compatibility and guidance.

### Q: What should I do if the coil is dismounted from the valve?

A: Never switch on power to the coil when dismounted to avoid damage and potential injuries. Always ensure proper mounting before powering on.

### **Documents / Resources**



<u>Danfoss EVRH 10 22 Solenoid Valve Types</u> [pdf] Installation Guide EVRH 10, EVRH 15, EVRH 18, EVRH 20, EVRH 22, EVRH 10 22 Solenoid Valve Types, EVRH 10 22, Solenoid Valve Types, Valve Types

#### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.