



## Danfoss MBS 5100 Pressure Transmitters Installation Guide

[Home](#) » [Danfoss](#) » Danfoss MBS 5100 Pressure Transmitters Installation Guide 



Installation guide  
Pressure transmitters  
MBS 5100, MBS 5103, MBS 5150, MBS 5153  
060R9349




### Contents

- [1 MBS 5100 Pressure Transmitters](#)
- [2 American and Canadian approvals:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

### MBS 5100 Pressure Transmitters


 	Electrical connection:
--	------------------------

EN 175301-803



Thread

MBS 5100/5103,  
MBS 5150/5153



Normal

ATEX Zone 2



 **Australian approvals:** According to N1297.

**American and Canadian approvals:**

1. Automatic electrical controls acc. to UL 60730-1 and part 2-6 / CAN/CSA E60730 and part 2-6, file E31024.
2. Equipment for process measurement and control acc. to UL 61010-1 / CSA C22.2 No. 61010-12, file E494625.
3. Nonincendive electrical equipment for use in Class I, Div. 2, Groups A, B, C, and D, hazardous locations in acc. To UL 121201 / C22.2 No. CSA-213, file E227388 and E510763. Combinations of equipment in systems are subject to investigation by the local Authority Having Jurisdiction at the time of installation. These components are to be installed within a suitable tool-secured enclosure in end application. **WARNING – EXPLOSION HAZARD – Do not disconnect equipment unless power has been removed or the area is known to be non-hazardous.**
4. The MWP (max. working pressure) in the range from 1 to 600 bar depending on the sensor range. Refer to product lable (E494625).
5. Evaluated for pollution Degree 3.
6. Altitude up to 8,000 m.
7. Max. R.H. 95% non-condensing.
8. Overvoltage category I.
9. Powered by class 2 supply.

Type	MBS 5100, MBS 5103, MBS 5150, MBS 5153
Max. ambient temperature/(T-code)	85 °C to 135 °C (T4)
Electrical connectors	For UL approved see overview page 1
Voltage supply	+9 to 32 V DC
Output	4 – 20 mA




  <b>II 3G</b> <b>Ex ec IIA T3 Gc</b> <b>-20 °C &lt; Ta &lt; + 55 °C</b>	EN60079-0; EN60079-7
--	----------------------

Applicable in ATEX Zone 2 with media classified as IIA in accordance to EN 60079-20-1:  
 All electrical connections must comply with the ATEX requirements for Zone 2 – and EN 60079-14.

Danfoss can accept no responsibility for possible errors in catalogs, brochures, and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are the property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

© Danfoss 'Climate Solutions  
12021.07 ANO2548642585101-00070212

## Documents / Resources



[Danfoss MBS 5100 Pressure Transmitters](#) [pdf] Installation Guide  
MBS 5100, MBS 5103, MBS 5150, MBS 5153, MBS 5100 Pressure Transmitters, MBS 5100, Pressure Transmitters, Transmitters

[Manuals+](#)