




**Danfoss PLUS+  
1 Compliant  
EMD Speed  
Sensor QUAD  
Function Block**



## Danfoss PLUS+1 Compliant EMD Speed Sensor QUAD Function Block User Manual


[Home](#) » [Danfoss](#) » Danfoss PLUS+1 Compliant EMD Speed Sensor QUAD Function Block User Manual

### Contents

- 1 Danfoss PLUS+1 Compliant EMD Speed Sensor QUAD Function Block
- 2 Specifications
- 3 Product Information
- 4 FAQ
- 5 DIMENSIONS
- 6 Overview
- 7 Inputs
- 8 Outputs
- 9 About Function Block Connections
- 10 Status and Fault Logic
- 11 Function Block Parameter Values
- 12 MC Controller—Input Configuration
- 13 SC Controller—Input Configuration
- 14 Products we offer
- 15 Documents / Resources
  - 15.1 References



**Danfoss PLUS+1 Compliant EMD Speed Sensor QUAD Function Block**



## Specifications

- **Product:** PLUS+1 Compliant EMD Speed Sensor Quadrature Function Block
- **Revision:** Rev AA (May 2015)
- **Manufacturer:** Danfoss

## Product Information


The EMD\_SPD\_QUAD Function Block outputs an RPM signal and a DIR signal based on inputs from an EMD Speed Sensor. It receives inputs such as Phase A, Phase B, Voltage, and Config signals to calculate RPM output.

## FAQ

**Q: What is the purpose of the EMD\_SPD\_QUAD Function Block?**

**A:** The EMD\_SPD\_QUAD Function Block outputs an RPM signal and a DIR signal based on inputs from an EMD Speed Sensor.

## DIMENSIONS



[www.powersolutions.danfoss.com](http://www.powersolutions.danfoss.com)

## Revision History


Revision	Date	Comment
Rev AA	May 2015	

©2015 Danfoss Power Solutions (US) Company. All rights reserved.

All trademarks in this material are properties of their respective owners.

PLUS+1, GUIDE, and Sauer-Danfoss are trademarks of Danfoss Power Solutions (US) Company. The Danfoss, PLUS+1 GUIDE, PLUS+1 Compliant, and Sauer-Danfoss logotypes are trademarks of Danfoss Power Solutions (US) Company.

## Overview



This function block outputs an RPM signal and a DIR signal based on inputs from an EMD Speed Sensor. On an MC and SC controller, this function block receives its:

- Phase A input through an MFIIn.
- Phase B input through an MFIIn.

## Inputs

### EMD\_SPD\_QUAD Function Block Inputs

Input	Type	Range	Description
<b>Param</b>	—	—	Input for a user-defined <b>Pulse/Rev</b> value that defines the number of pulses equal to one revolution.  Optionally, an input for a <b>DirLockHz</b> value to replace this function block's internal default fault direction-lock frequency value.
<b>Phase A</b>	Bus	—	Inputs speed and direction signals from the speed sensor.
<b>Per</b>	U32	1,250 to 10,000,000	The measured period output by the <b>Speed Sensor</b> .  The function block uses the <b>Per</b> signal, <b>Count</b> signal, and <b>Puls/Rev</b> parameter value to calculate its <b>RPM</b> output.  10,000 = 1,000 $\mu$ s.

L1429531 · Rev AA · May 2015

### EMD\_SPD\_QUAD Function Block Inputs

Input	Type	Range	Description
<b>Count</b>	U16	0 to 65,535	The measured count per program loop output by the <b>Speed Sensor</b> .  The function block uses the <b>Per</b> signal, <b>Count</b> signal, and <b>Puls/Rev</b> parameter value to calculate its <b>RPM</b> output. 1,000 = 1,000.
<b>QuadCount</b>	S16	-32768 to 32767	The measured direction and number of counts based on phase shifted pulse waves from <b>Phase A</b> and <b>Phase B</b> .  1,000 = 1,000.
<b>Volt/Voltage</b>	U16	0 to 5,250	The measured voltage of the input signal that the Speed Sensor outputs, which the block uses for fault detection.
<b>Config</b>	Sub-bus	—	Contains the signals that configure this input.
<b>Phase B</b>	Bus	—	Inputs speed signals from the speed sensor.
<b>Per</b>	U32	1,250 to 10,000,000	The measured period output by the <b>Speed Sensor</b> .  The function block uses the <b>Per</b> signal, <b>Count</b> signal, and <b>Puls/Rev</b> parameter value to calculate its <b>RPM</b> output. 10,000 = 1,000 $\mu$ s.
<b>Count</b>	U16	0 to 65,535	The measured count per program loop output by the <b>Speed Sensor</b> .  The function block uses the <b>Per</b> signal, <b>Count</b> signal, and <b>Puls/Rev</b> parameter value to calculate its <b>RPM</b> output. 1,000 = 1,000.
<b>Volt/Voltage</b>	U16	0 to 5,250	The measured voltage of the input signal that the Speed Sensor outputs, which the block uses for fault detection.
<b>Config</b>	Sub-bus	—	Contains the signals that configure this input.

## Outputs

### EMD\_SPD\_QUAD Function Block Outputs

Output	Type	Range	Description
--------	------	-------	-------------


<b>Status</b>	U16	—	<p>Reports the function block's status.</p> <p>This function block uses a <u>non-standard</u> bitwise scheme to report its status and faults.</p> <ul style="list-style-type: none"> <li>0x0000 = Block is OK.</li> <li>0x0008 = <b>Puls/Rev</b> or <b>DirLockHz</b> parameter value is out of range.</li> </ul>
<b>Fault</b>	U16	—	<p>Reports the function block's faults.</p> <p>This function block uses a <u>non-standard</u> bitwise scheme to report its status and faults.</p> <ul style="list-style-type: none"> <li>0x0000 = Block is OK.</li> <li>0x0001 = <b>Per</b> signal in the function block's <b>Phase A</b> input is too low.</li> <li>0x0002 = <b>Volt/Voltage</b> signal in the function block's <b>Phase A</b> input is out of range.</li> <li>0x0004 = <b>Per</b> signal in the function block's <b>Phase B</b> input is too low.</li> <li>0x0008 = <b>Volt/Voltage</b> signal in the function block's <b>Phase B</b> input is out of range.</li> <li>0x0010 = The difference in frequencies reported by the function block's <b>Phase A</b> and <b>Phase B</b> inputs is greater than 5%.</li> </ul>
<b>Diag</b>	— —	—	<p>Outputs a bus with <b>Freq</b>, <b>FltTmrPhase A</b>, <b>FltTmrPhase B</b>, and <b>FltTmrFreqDiff</b> signals that are available for troubleshooting.</p>
<b>Freq</b>	U32	0 to 1,000,000,000	<p>The measured frequency of the Speed Sensor. 100,000 = 10,000 Hz.</p>
<b>FltTmrPhase A</b>	U16	0 to 65,535	<p>When a frequency fault:</p> <ul style="list-style-type: none"> <li>Occurs, this output counts up the milliseconds until the function block makes a fault declaration.</li> <li>Clears, the output counts down the milliseconds until the function clears the fault declaration.</li> </ul> <p>1,000 = 1,000 ms.</p>
<b>FltTmrPhase B</b>	U16	0 to 65,535	<p>When a frequency fault:</p> <ul style="list-style-type: none"> <li>Occurs, this output counts up the milliseconds until the function block makes a fault declaration.</li> <li>Clears, the output counts down the milliseconds until the function clears the fault declaration.</li> </ul> <p>1,000 = 1,000 ms.</p>

<b>FltTmrFreq Diff</b>	U16	0 to 65,535	<p>When a frequency difference fault:</p> <ul style="list-style-type: none"> <li>Occurs, this output counts up the milliseconds until the function block makes a fault declaration.</li> <li>Clears, the output counts down the milliseconds until the function clears the fault declaration.</li> </ul> <p>1,000 = 1,000 ms.</p>
<b>dRPM</b>	U16	0–25,000	<p>Speed sensor revolutions per minute x 10 (decirPM). The function block clamps this output at 25,000.</p> <p>1 = 0.1 rpm.</p>
<b>RPM</b>	U16	0–2,500	<p>Speed sensor revolutions per minute.</p> <p>The function block clamps this output at 2,500. 1 = 1 rpm.</p>

### EMD\_SPD\_QUAD Function Block Outputs

Output	Type	Range	Description
<b>Dir</b>	S8	-1, 0, +1	<p>The Speed Sensor's direction of rotation.</p> <ul style="list-style-type: none"> <li>-1 = Counterclockwise (CCW).</li> <li>0 = Neutral.</li> <li>+1 = Clockwise (CW).</li> </ul>

### About Function Block Connections



### Function Block Connections

Item	Description
1.	Input for common parameters that can be applied to multiple function blocks.
2.	Input for a bus with: <ul style="list-style-type: none"> <li>· The voltage, period, <b>quadcount</b>, and count signals output by the EMD Speed Sensor.</li> <li>· A sub-bus with signals that configure the controller input that receives these signals.</li> </ul>
3.	Input for a bus with: <ul style="list-style-type: none"> <li>· The voltage, period, <b>quadcount</b>, and count signals output by the EMD Speed Sensor.</li> <li>· A sub-bus with signals that configure the controller input that receives these signals.</li> </ul>
4.	Reports the status of the function block.
5.	Reports the fault of the function block.
6.	Outputs a bus with <b>Freq</b> , <b>FltTmrPhase A</b> , <b>FltTmrPhase B</b> , and <b>FltTmrFreqDiff</b> signals that are available for troubleshooting.
7.	Speed sensor revolutions per minute.
8.	Speed sensor revolutions per minute x 10 (decRPM).
9.	The Speed Sensor's direction of rotation. <ul style="list-style-type: none"> <li>· -1 = Counterclockwise (CCW).</li> <li>· 0 = Neutral.</li> <li>· +1 = Clockwise (CW).</li> </ul>

## Status and Fault Logic

Unlike most other PLUS+1 compliant function blocks, this function block uses non-standard status and fault codes.

### Status Logic

Status	Hex*	Binary	Cause	Response	Correction
A parameter is out of range.	0x0008	1000	<b>Puls/Rev</b> , <b>FaultDetTm</b> , or <b>DirLockHz</b> parameter is out of range.	The function block clamps the out-of-range value at either its upper or lower limit.	Get the out-of-range parameter back within its range.

\* Bit 16 set to 1 identifies a standard Danfoss status or fault code.

### Fault Logic



Fault	Hex*	Binary	Cause	Response	Delay†	Latch‡	Correction
<b>Per</b> signal in the function block's <b>Phase A</b> input is too low.	0x0001	00000001	<b>Per</b> signal < 1, 250 Hz.	The function block outputs its maximum <b>RPM</b> and <b>dRPM</b> values.	Y	N	Check for hardware issues, such as electrical noise, that can produce an invalid <b>Per</b> signal value.
<b>Volt</b> signal in the function block's <b>Phase A</b> input is out of range.	0x0002	00000010	2000 V < <b>Volt</b> signal < 3000 V.	The function block outputs 0 for <b>RPM</b> and <b>dRPM</b> values.	Y	N	Check for hardware issues, such as an open circuit signal wire or missing sensor voltage supply.
<b>Per</b> signal in the function block's <b>Phase B</b> input is too low.	0x0004	00000100	<b>Per</b> signal < 1, 250 Hz.	The function block outputs its maximum <b>RPM</b> and <b>dRPM</b> values.	Y	N	Check for hardware issues, such as electrical noise, that can produce an invalid <b>Per</b> signal value.
<b>Volt</b> signal in the function block's <b>Phase B</b> input is out of range.	0x0008	00001000	2000 V < <b>Volt</b> signal < 3000 V.	The function block outputs 0 for <b>RPM</b> and <b>dRPM</b> values.	Y	N	Check for hardware issues, such as an open circuit signal wire or missing sensor voltage supply.
Measured difference between <b>Phase A</b> and <b>Phase B</b> frequency too big.	0x0010	00010000	Freq A - Freq B  > 5% of current frequency.	No built-in response, output reported as measured by <b>Phase A</b> input.	Y	N	Check for hardware issues, such as electrical noise, that can produce an invalid <b>Per</b> signal value.


Bit 16 set to 1 identifies a standard Danfoss status or fault code.

A delayed fault is reported if the detected fault condition persists for a specified delay time. A delayed fault cannot be cleared until the fault condition remains undetected for the delay time.

The function block maintains a latched fault report until the latch releases.

## Function Block Parameter Values

Enter the top-level page of the EMD\_SPD\_QUAD function block to view and change this function block's parameters.



## Function Block Parameters

Input	Type	Range	Description
<b>Puls/Rev</b>	U16	20–120, 180	Number of pulses per revolution of the Speed Sensor. Refer to the EMD Speed Sensor Technical Information (Danfoss part L1017287) for the correct value.
<b>FaultDetTm</b>	U16	—	Sets the time between when the function block detects a: <ul style="list-style-type: none"> <li>Fault condition and then makes a fault declaration.</li> <li>Cleared fault condition and then clears the fault declaration. 1,000 = 1,000 ms.</li> </ul>
<b>DirLockHz</b>	U16	0–8,000 Hz	Sets the frequency above which the function block's Dir output locks. Above this frequency, the function block does not report changes in direction. 1,000 = 1,000 Hz.

## MC Controller—Input Configuration

If you have an SC controller

You route the function block's:

Phase A and Phase B inputs through MFIn.  
You must change the MFIn default configurations to accept these inputs.


## How to Configure a MFIn



1. In the GUIDE template, enter the Inputs page.



2. Enter the MFIN page that receives the input.



3. Make the changes that are shown in the preceding figure.

## SC Controller—Input Configuration

If you have an MC controller

You route this function block's:

Phase A and Phase B inputs through MFIN.

You must change the default configuration of the MFIN to accept this input.

The MFIN that you use must be capable of a Freq input and have configurable Bias, Range, and InputMode values.


### How to Configure a MFIN



1. In the GUIDE template, enter the Inputs page.



2. Enter the MFIN page that receives the input.



3. Make the changes that are shown in the preceding figure.

## Products we offer

- Bent Axis Motors
- Closed Circuit Axial Piston Pumps and Motors
- Displays
- Electrohydraulic Power Steering
- Electrohydraulic
- Hydraulic Power Steering
- Integrated Systems
- Joysticks and Control Handles
- Microcontrollers and Software
- Open Circuit Axial Piston Pumps
- Orbital Motors
- PLUS+1™ GUIDE
- Proportional Valves
- Sensors

**Danfoss Power Solutions** is a global manufacturer and supplier of high-quality hydraulic and electronic components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market. Building on our extensive applications expertise, we work closely with our customers to ensure exceptional performance for a broad range of off-highway vehicles. We help OEMs around the world speed up system development, reduce costs and bring vehicles to market faster. Danfoss—Your Strongest Partner in Mobile Hydraulics.

Go to [www.powersolutions.danfoss.com](http://www.powersolutions.danfoss.com) for further product information.

- Wherever off-highway vehicles are at work, so is Danfoss.
- We offer expert worldwide support for our customers, ensuring the best possible solutions for outstanding

performance. And with an extensive network of Global Service Partners, we also provide comprehensive global service for all of our components.

- Please contact the Danfoss Power Solution representative nearest you.

#### Local address:

##### Danfoss

Power Solutions US Company 2800 East 13th Street  
Ames, IA 50010, USA  
Phone: +1 515 239-6000

##### Danfoss

Power Solutions GmbH & Co. OHG Krokamp 35  
D-24539 Neumünster, Germany Phone: +49 4321 871 0

##### Danfoss

Power Solutions ApS Nordborgvej 81  
DK-6430 Nordborg, Denmark Phone: +45 7488 4444

##### Danfoss Ltd.

Power Solutions  
B#22, No. 1000 Jin Hai Rd. Shanghai 201206, China Phone: +86 21 3418 5200


Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are the property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss Power Solutions (US) Company. All rights reserved.

L1429531 · Rev AA · May 2015

[www.danfoss.com](http://www.danfoss.com)




©2015 Danfoss Power Solutions (US) Company

#### Documents / Resources

	<p><a href="#">Danfoss PLUS+1 Compliant EMD Speed Sensor QUAD Function Block</a> [pdf] User Manual PLUS 1 Compliant EMD Speed Sensor QUAD Function Block, PLUS 1, Compliant EMD Speed Sensor QUAD Function Block, Speed Sensor QUAD Function Block, Sensor QUAD Function Block, QUAD Function Block, Function Block, Block</p>
---	--

#### References

- [Danfoss Power Solutions – Explore our power solutions | Danfoss](#)
- [Daikin Sauer Danfoss - Home](#)
- [Engineering Tomorrow | Danfoss](#)
- [Leading Drivetrain Manufacturer - Hydro-Gear](#)

-  [Danfoss Power Solutions – Explore our power solutions | Danfoss](#)
-  [Homepage - DanaTM4](#)
-  [Danfoss Power Solutions – Explore our power solutions | Danfoss](#)
- [User Manual](#)

**Manuals+, Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.