



Danfoss X-Gate Gateway Unit Type User Guide

[Home](#) » [Danfoss](#) » Danfoss X-Gate Gateway Unit Type User Guide 

Contents

1 Danfoss X-Gate Gateway Unit Type

2 Introduction

3 System Access

4 User Configuration

5 Network Configuration

6 Services

7 Use Cases

8 Update

9 Annexure

10 Documents / Resources

10.1 References

11 Related Posts



Danfoss X-Gate Gateway Unit Type



Introduction

X-Gate is the new Danfoss gateway, designed to support and make the “Integration” activity at the field level. **X-Gate can manage mainly two kinds of integrations:**


- At the south-bound level: Capability to read from electronic devices with different protocols: Modbus RTU, Modbus TCP/IP, BACnet IP, BACnet MS/TP, CANBus and translate into another protocol suitable for the integration at the monitoring system level. Typical Modbus RTU.
- At the north-bound level: Capability to read the Open XML protocol from System Manager 800A and expose the normalized data points on different protocols: Modbus RTU or TCP/IP, BACnet IP for an “on top” BMS.

DISCLAIMER: Professional Use Only

This product is not subject to the UK PSTI regulation, as it is for supply to and use only by professionals with the necessary expertise and qualifications. Any misuse or improper handling may result in unintended consequences. By purchasing or using this product, you acknowledge and accept the professional-use-only nature of its application. Danfoss does not assume any liability for damages, injuries, or adverse consequences (“damage”) resulting from the incorrect or improper use of the product and you agree to indemnify Danfoss for any such damage resulting from your incorrect or improper use of the product.

Use Cases Scenarios

Following the typical use-cases scenarios where X-Gate can fit:



X-Gate can provide flexibility with a focus on 3rd party device integration into System Manager and at the same time make it easy for a BMS to integrate the desired data points over standard protocols.

First-time configuration

For the installation phase of X-Gate please refer to the standard “Installation Guide” provided inside the packaging. X-Gate has a Web User Interface, that can be accessed using a standard browser. The X-Gate starts in DHCP mode to be easily connected to an existing network. To discover the IP address of X-Gate in the network, the User can plug in a USB pen driver and perform the following steps:

On your PC:

- Insert a USB memory stick.
- Make sure the USB stick is formatted as FAT or FAT32.
- Create an empty file in the root named node_info.txt.
- Unmount and remove the USB memory stick from your PC.

On your X-Gate:

- Power-up the X-Gate
- Insert the USB stick into the USB connector of the X-Gate.
- Wait about 10 seconds (X-Gate will write the information in automatic mode into the txt file).
- Remove the USB stick and insert it into your PC

The file node_info.txt will contain the basic information about the X-Gate. Here is an example of the content:

- [node_info]
- ip=10.16.176.86
- mac_address=02:50:41:00:00:01
- sw_descr=X-Gate v.1.10 (180628.1713)

The file contains information on IP and aMAC-ADDRESS of X-Gate.

After getting the IP address of X-Gate in the network, the User can connect using a browser by typing the following URL: <http://10.16.176.86> If you connect directly to X-Gate to PC via ethernet cable on ETH2, you will find the X-Gate at the IP address 192.168.2.101.

System Access

Login


To access the main configuration section of X-Gate, a login is required with User & Password. The default account is “admin” with the default password “PASS”. For security reasons, after 3 attempts to enter a wrong password, X-Gate will lock access for 10 minutes. The default login credentials must be changed in the ser Configuration menu.



- After the first login, we strongly suggest changing the default password to prevent unauthorized access.
- After logging into the system, the User can access the configuration options according to the user profile.

Network Overview


“Network Overview” is the landing page after login. It contains the list of the devices (Node) connected to X-Gate, plus the X-Gate itself.



ID	Device Name	Application	Action
1	Modbus TCP Device 01	3rd Party Modbus Dev	>
2	Modbus TCP Device 02	3rd Party Modbus Dev	>
100	X-GATE	MGTW	>

Network Alarm

The network Alarm page contains the real-time alarm list of the X-Gate device. It can be used to troubleshoot in case of problems in the installation.




If parameter “G17 Enable alarm history” is enabled, a history of cleared alarms and other events will be kept in X-Gate.

The following events are recorded:

- Alarm start/end.
- Alarm acknowledges.
- Power-up
- Change of parameter
- Firmware updates
- Time change
- Security threat

Event Log


The event page traces the events of the X-Gate. Users can save the event log list in a csv format.




User Configuration

User List

The accounts list can be accessed from the User Configuration page. By default, 4 users are available in the system: admin, Manufacturer, Service, and User.



All the Account have a dedicated profile to have different visibility inside the X-Gate configuration page. Profiles available are Maintenance and Service.



The User Configuration page provides the following features:

- “Add User” button: To add a new user to the system.
- Delete “—” button: to delete the single user.
- “Save” button: to confirm the modification done.

Network Configuration

Device List

The device (Node) list can be accessed from the Network Configuration page. The default Device present is the X-Gate itself with its configuration.

X-GATE

25/04/2024 00:16:43

Danfoss

NETWORK

Network overview

Network alarm

Event log

CONFIGURATION

Network configuration

Users configuration

Settings

Files

Editor CDF

Info

Logout

Network configuration

Node Id: 100

Description: X-GATE

Application: MGTW

Protocol address:

ADD NODE

SAVE

To add a new device, the “Add Node” button that provides the information needed:

- Node Id: the serial address of the device
- Description
- Application: the device profile with the list of the data points to read
- Protocol address: in the case of TCP/IP protocol like Modbus, it is the IP address of the device itself.

X-GATE

25/04/2024 00:19:19

Danfoss

NETWORK

Network overview

Network alarm

Event log

CONFIGURATION

Network configuration

Users configuration

Settings

Files

Editor CDF

Info

Logout

Network configuration

100 X-GATE

Node Id: 1

Description:

Application: 3rd Party Modbus Dev

Protocol address:


ADD NODE

SAVE

Every time the User adds or removes a device, he must be saved with the “Save” button.


X-Gate set-up

Enter the “Network Overview” and access the X-Gate main menu page.



Supervisor

This page contains the main parameters to set up the communication over a serial line.



- SU2 & SU3 are the configuration parameters for the serial line at COM1.
- SU4 is used to set up the speed over the CANBus serial line (there is a dedicated port for CANBus built-in into X-Gate).
- S10 is used to define which protocol must be used on the COM1 serial port.
- In case of an extra RS485 module, parameter G35 must be put at YES.
- An extra set of parameters can be set up:
- SU5 & SU6 are the configuration parameters for the serial line at COME (COM Extension).
- S40 is used to define which protocol must be used for the COME (COM Extension) serial port.

Other

This page contains the main parameters to set up the LAN configuration both for the ethernet port 1 and port 2.

→ 100 - 06/05/2024 23:02:37 Danfoss

Overview ⇒ Main Menu → Others

Parameter settings

VER	SW Descr	Multigateway v.5.15 (240417.1536) - beta	✕
MAC	MAC Address		✕
SER	Serial number	PC-5CG23758LT	✕
IP1	IP Address Mode	DHCP	▼
IP0	Current IP	192.168.1.81	✕
IP21	Address Mode 2	DHCP	▼
IP20	Current IP 2	10.132.26.142	✕
TMS	Current time	2024-05-06 21:02:37	✕
TOF	Time offset	0minutes	▼
BBB	Reboot	NO	▼
ADV	Advanced options	OFF	▼

- In the case of STATIC IP management, set up parameters IP1 & IP21 to “Static”. BBB parameter can be used in case of a manual reboot of the X-Gate machine.

Services

→ 100 - 06/05/2024 23:06:12 Danfoss

Overview ⇒ Main Menu → Services

Parameter settings

G18	Web server port	8280	▼
G27	Enable CANRS485 gateway mode	OFF	▼
NTP	NTP Enable	OFF	▼
G54	Enable NTP Server	OFF	▼

Parameter NTP will enable X-Gate to synchronize the time with an online service. Parameter G54 will enable X-Gate as an NTP Server for another Client.

Client Fieldbus

This section allows configuring to the “SOURCE of the DATA”.

→ 100 - 07/05/2024 09:53:14 Danfoss

Overview ⇒ Main Menu → Client fieldbus

Parameter settings

G14	Modbus TCP Client	OFF	▼
G58	Modbus UDP Client	OFF	▼
G20	Modbus RTU Client	OFF	▼
G29	Modbus ASCII Client	OFF	▼
G31	SM800 Xml	OFF	▼
G36	Enable CANbus	OFF	▼
G41	BACnet IP Client	OFF	▼
G42	BACnet MSTP Client	OFF	▼

According to the protocol to read from the device on the field, the User must activate the right configuration.

- G14: To enable communication with Modbus TCP/IP device using the RJ45 (LAN) cable.


- G58, G20, G29: To enable the communication with Modbus device over the serial port (RS485).
- G31: To enable in case X-Gate must read over XML protocol on System Manager (via LAN cable).
- G36: To enable for a communication with a CANBus device.
- G41, G42: To enable in case of BBACnetdevice with IP (LAN) or MSTP over serial RS485.

According to the enabled client fieldbus, extra configuration parameters will be displayed. Here is the example in the case of Modbus TCP/IP with the need to set up the IP address of the device.



Server Fieldbus

This section allows to configuration of the “DESTINATION of the DATA” read from the field.




According to the protocol to read from the device on the field, the User must activate the right configuration.

- G01, G59: To enable the data sharing via Modbus TCP/IP server.
 - G11: To enable the data sharing in Modbus on the RS45 port.
 - G02: To enable data sharing over SNMP protocol over TCP/IP.
 - G28, G30: To enable data sharing over BBACnetin IP or MSTP according to the setting
- According to the enabled server fieldbus, extra configuration parameters will be displayed. The G04 parameter provides the capability to limit variable visibility according to the Level. From Level 1 to Level 3. The level is a characteristic of the variable coming from the CDF file (or CDF Editor).

CDF Editor


The Editor CDF is a feature that allows the user to edit or create from scratch a CDF file. To use it, click on the “Editor CDF” icon on the left side of the menu tab.



The user can decide to load and eventually modify an existing CDF. If the desired CDF is stored inside the X-Gate, the “Select CDF from X-Gate” window must be opened.




All the CDF files stored inside the device will be listed and are available for selection.




Either way, if the CDF is not stored inside the X-Gate itself but is saved inside the host machine (a PC, eventually), click on “LOAD CDF LOCALLY” and select the file you want to load.

Create new CDF


- If a CDF must be created from scratch, the user must fill in the CDF fields as described in the following sections.
- The header of the CDF is a field that contains a general overview of the CDF itself. Five fields can be modified.
- **Name:** The given name will be stored inside the CDF and will also be the file name. It is a string of a maximum of 20 characters. This field must be filled.
- **Description:** A general description of the CDF. It is a string of a maximum of 20 characters. This field must be filled.
- **Model:** A 2 digit number, representing the model of the CDF. This field must be filled.
- **Version:** A 3 digit number, representing the version of the CDF. For example, if the field is 100, the version will be interpreted as 1.0.0. This field must be filled.
- **Device Category:** A list, containing the category of the CDF. It is an optional field.



The enum section allows the user to create and modify new enumeration types.




If the button “ADD ENUM TEXT-VALUE PAIR” is clicked, an additional row will appear:







Two fields describe the text-value pair that needs to be added to the enumeration under definition:

- **Text:** A textual description of the current enumeration value
- **Value:** the relative value

For example, suppose that the user wants to define an enumeration representing the baud rate available for a serial communication:








New Enum

Text	Value	
<input type="text" value="1200"/>	<input type="text" value="1"/>	
<input type="text" value="2400"/>	<input type="text" value="2"/>	
<input type="text" value="4800"/>	<input type="text" value="3"/>	
<input type="text" value="9600"/>	<input type="text" value="4"/>	

ADD ENUM TEXT-VALUE PAIR

SAVE ENUM

Once the enum is complete, the user must click “SAVE ENUM” to use it in the parameters section, which will be described later. All the defined enums will be saved inside the CDF. If the enum is correctly formatted, then a successful message will appear: “ENUM SAVED” message. Otherwise, if an error is presentwhen clicking on “SAVE ENUM” the corresponding row will appear highlighted in red:

Text	Value	
<input type="text" value="1200"/>	<input type="text" value="1"/>	
<input type="text" value="2400"/>	<input type="text" value="2"/>	
<input type="text" value="4800"/>	<input type="text" value="3"/>	
<input type="text" value="9600"/>	<input type="text" value="4"/>	
<input type="text" value="9600"/>	<input type="text" value="5"/>	

ADD ENUM TEXT-VALUE PAIR

SAVE ENUM

In this case, the same text cannot be used for storing two different values. Once an enum has been correctly saved, the selection list containing all the enenumssill refresh and the jjust-createdentity will appear formatted as follows:



13: 1200; 2400; 4800; 9600;

Where 13 is the index of the enum (this means that the CDF file already had 12 enum saved), followed by the texts used to define the enum itself. In case of error during the Enum creation, there are some conditions to look for asfollowsg:

- The text is not unique.
- The value is not unique.
- The value is not numeric.

The parameters table allows the user to specify the parameters that will be stored inside the CDF:

Pos	En	Addr	Bit	RW	Dec	Type	Enum	Min	Def	Max	Eng Unit	Descr	MB Fn	Group	
↑ ↓	<input checked="" type="checkbox"/>	<input type="text"/>	<input type="text" value="0"/>	<input type="text" value="0-1"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	

ADD PARAM

The fields that define a parameter are:

- **Pos:** Position inside the table. If the user clicks the arrows on the left of the rows, the parameter position will be switched with either the next or the previous parameter (if possible). This feature can be used for quickly sorting the file in case the parameter is out of place by some positions.
- **En:** If the En checkbox is selected, the device will be saved inside the groups and will be visible.
- **Addr:** Represents the address of the parameter (for example, the registered address for a Modbus register)
- **Bit:** This selection box is enabled and can be modified just for U1-typed parameters. It represents the bit that this parameter occupies for the given address.
- **• RW:** Read/Write permission. The first digit is relative to the read permission, the second is relative to the write.
- **0:** always allowed
- **1:** require level user
- **2:** require level of service
- **3:** require level OEM
- **X:** hidden
- **Dec: Number** of decimals, disabled if the parameter is of type STR or U1
- **Type:** The type of the parameter. Can be:
 - Empty
 - **U1:** Unsigned bit
 - **U8:** Unsigned 1 byte
 - **U16:** Unsigned 2 bytes
 - **U32:** Unsigned 4 bytes
 - **U64:** Unsigned 8 bytes
 - **S16:** Signed 2 bytes
 - **S32:** Signed 4 bytes
 - **S64:** Signed 8 bytes
 - **F32:** Float 4 bytes
 - **F64:** Float 8 bytes
- **Enum:** This field can be either empty or one of the indexes of the defined enums
- **Min:** The minimum value that the parameter can assume
- **Def:** The default value that the parameter will assume.
- **Max:** The maximum value that the parameter will assume
- **Eng Unit:** The Engineering unit that describes the parameter.
- **Descr:** A textual description of the parameter
- **MB Fn:** In the case of Modbus protocol, the user can specify the function code used to interact with it
- **Group:** The group that contains the parameter. If this field is empty, then the group is "ROOT" by default. Otherwise, the group is the string provided by the user. The group can be nested inside another group with the "[" char. For example, the group "Stats | Calculated" defines the
 - Calculated group inside the Stats group.

In the previous image, the "Addr" and "Group" column header are highlighted in red. If the user clicks them, the entire parameter table will be sorted in ascending/alphabetical order. This feature can be used to quickly sort a messy CDF.

Note: also a parameter row can be deleted from the table by clicking the bin icon located at the right of the group.

The following conditions are defined as errors when creating a new param:

- The address field is empty.
- The address field contains chars different from 0-9.
- The address field is not unique with respect to all other addresses.
- Min, default, and maximum are not coherent with the given parameter type (for example, max=256 and type=U8)
- Min <= default <= maximum is not respected
- Min, default, and maximum contain chars different from 0-9.

The alarms table allows the user to specify the alarms that will be stored inside the CDF:

Address	Bit	Modbus Fn	Description
<input type="text"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>
<div>ADD ALARM</div>			

The fields that define an alarm are:

- **Address:** Represents the address of the alarm
- **Bit:** Represents the bit of the address which is effectively occupied by the alarm
- **Modbus Fn:** In the case of Modbus protocol, the user can specify the function code used to interact with it
- **Description:** A textual description of the parameter

The following conditions are defined as errors when creating a new alarm:

- The pair (Address, Bit) is not unique.
- The tags table allows the user to link a pre-defined tag with a
 - Parameter
 - parameter list
 - Enum
 - Alarm list
 - Enum reference
 - Number
 - Text

Tag	Tag Type	Tag Origin	Param or Alarm Index(es) separated by comma
0: 0000_MAIN_SWITCH	Param	DeviceSpecific	
ADD TAG			

The tags, which type, and origin cannot be modified, can be linked to the parameters or alarms by their index, eventually separated by a comma in case a parameter list or alarm list is selected.

The index of a parameter can be found as a tool tip when the mouse is over a parameter/alarm table row:

↑ ↓	<input checked="" type="checkbox"/>	3230	0	0 - 2	0	S16		1	100	254		Address		Supervisor
-----	-------------------------------------	------	---	-------	---	-----	--	---	-----	-----	--	---------	--	------------

In the case pictured above, the index is seven. Note that the index of the first parameter is 0. The following conditions are defined errors when creating a new tag

- The tag is not unique.
- The tag type is “param” and more than one parameter is specified.
- Tag type is “param”, “param list” or “alarm list” and the index(es) specified are higher than the index of the last defined parameter.

As for the loading part, the CDF can be either saved on the X-Gate itself or in the local host, such as the user's PC. The user must click one of the buttons pictured below, according to its necessity.

↓	SAVE CDF LOCALLY
↑	SAVE CDF X-GATE

The button with the label “SAVE CDF LOCALLY” allows the user to save and store the edited CDF in the host (PC), while the other saves the CDF on the X-Gate itself. If the saving procedure does not find any error, then the file is either downloaded or a message saying “CDF saved on XGATE” will be shown. On the other side, if any error on the CDF file is found, an alert will pop up: “There are some errors: could not save the file”. The message shown above will appear if the save procedure finds one or more errors. The possible errors have been listed and explained in the previous sections. The user can then explore the CDF and see where the error is located, by searching for a red backgrounded element, such as is the following:

↑ ↓	<input checked="" type="checkbox"/>	3353	0	1 - 2	0	S16	4	0	0	1		BACnet MS/		Client fieldb
↑ ↓	<input checked="" type="checkbox"/>	3353	0	0 - 1	0	STF		0		100		APN		Modem

Once all the errors are resolved, the CDF can be saved again.

Note: that the errors are also shown in real time and not just when a CDF is saved. The row that was modified by the user is scanned when another row has been clicked.

8. Customization of HTTP user interface


It is possible to customize the user interface of X-Gate.

It is possible to customize the:

- Logo in the top right corner of the (instead of the default Danfoss logo)
- The color of the interface (instead of the default red)

Logo Customization

1. To customize the logo shown at top right of the page, create a PNG file named custom_logo.png with width of 133 pixels, height of 55 pixels.
2. Once the PNG file is ready go to the “Files” menu, which can be found on the left-side panel:




3. Here you should click the “Upload” button and click on your logo customization PNG file.



4. Refresh the page to see your changes.

Color Customization


1. You can also customize colors by creating a custom_style.css. This is an example of a custom_style.css



2. Upload the file in the same way as specified above under the “Files” menu and click “Upload”.
3. Refresh the page to see your changes.

Here is an example of customizing the main colour into blue.

Removing Customizations

1. If you want to remove a customization, simply remove the file in the “Files” list using the icon:  on the right.
2. Refresh the page to see your changes.


Use Cases

Use Case 1: Source BACNET & Destination MODBUS

- As a step 1, User must activate the “source of the data”. It could be BACNet IP or MSTP from the Client Fieldbus configuration page. Main parameters to set up are: G41 or G42.
- G55 parameter is use as write priority property for BACNet protocol: Default is 16.
- G43 parameter is used as max number of units: Default is 127.

Parameter ID	Parameter Name	Status	Action
G14	Modbus TCP Client	OFF	▼
G58	Modbus UDP Client	OFF	▼
G20	Modbus RTU Client	OFF	▼
G29	Modbus ASCII Client	OFF	▼
G31	SM800 Xml	OFF	▼
G36	Enable CANbus	OFF	▼
G41	BACnet IP Client	OFF	▼
G42	BACnet MSTP Client	ON	▼
G43	BACnet Max Master	127	▼
G55	BACnet write priority	16	▼


- After this configuration done, X-Gate will start to automatically scan the network (IP or Serial as per configuration done) and automatically will create all the CDF files of the discovered devices (nodes) and create the related device in the Network Configuration page.
- User can modify the CDF file directly using the CDF Editor or use as it is.
- As a step 2, User must activate the “Destination of the data”, in this case Modbus TCP/IP.
- In the Server Fieldbus page, the main parameter is G01 and later the G48 as default port of the server at 502.
- With this configuration, X-Gate is reading BACNET and exposing over MODBUS TCP/IP.




In case of sharing data with a local BMS, the full list of variable/data-points can be downloaded as a CVS file with the utility in settings download CSV file.



In case the destination of the data is the System Manager over Modbus RTU (serial RS485), G11 parameter must be on.



In this case, User must set up the communication port with the correct enabled feature. S10 parameter must have the correct set up "Modbus server" and the parameter SU2 and SU3 must be set up according.




Finally, User can download the file for the System Manager integration from the settings menu with the download of the ED3 / EPK files.



Use Case 2(1) Source CANBUS & Destination MODBUS

As a step 1, User must activate the “source of the data” with parameter G36.



Check the communication speed on the port with parameter **SU4**.



Import the CDF file or create/modify an existing one with the CDF Editor.



(1) Feature available starting from software version greater than 5.22.

Create a new Device on the Network Configuration page.

X-GATE
08/05/2024 10:10:09

Network configuration

100 X-GATE

Node Id: 1

Description: My CANBus Device

Application: CANBus Dev Profile

Protocol address:

ADD NODE

SAVE

- As a step 2, User must activate the “Destination of the data”, in this case Modbus TCP/IP.
- In this case, the activities to be done are the same already described for the Use-Case 01 to set up the destination of the data.

Use Case 3: Source MODBUS & Destination MODBUS

- As step 1, User must activate the “source of the data”. In this case X-Gate must have the additional expansion card with the extra RS485 port.
- G35 parameter to enable the use of the extra RS485.
- SU2 and SU3 for the serial line configuration of COM1
- SU5 and SU6 for the serial line configuration of COME (extended)
- S10 for COM1 as Client
- S40 for COME as Server

X-GATE → 100 - X-GATE
08/05/2024 10:10:12

Parameter settings

Site name: X-GATE

SU0 New value:

SU1 Address: 100

SU2 Baudrate: 38400

SU3 Serial Settings: 8E1

SU4 CAN Baudrate: 50kbps

G35 Use external RS485: YES

SU5 Baudrate Ext: 38400

SU6 Serial Settings Ext: 8E1

SU9 PC Com port:

S10 COM1 Protocol: ModbusRTUClient

S40 COME Protocol: ModbusServer

G20 ON to enable the source of the data via Modbus.

X-GATE → 100 - X-GATE
08/05/2024 10:10:04

Parameter settings

G14 Modbus TCP Client: OFF

G58 Modbus UDP Client: OFF

G20 Modbus RTU Client: ON

G20 New value: ON

G29 Modbus ASCII Client: OFF

G31 SM800 Xml: OFF

G36 Enable CANbus: OFF

G41 BACnet IP Client: OFF


G42 BACnet MSTP Client: OFF

- Import the CDF file or create/modify an existing one with the CDF Editor (as done for Use Case 2).
- Create a new Device in the Network Configuration page (as done for Use Case 2).

- As a step 2, User must activate the “Destination of the data”, in this case Modbus TCP/IP. In this case the activities to be done are the same already described for the Use Case 1 to set up the destination of the data.

Use Case 4: Source XML Interface & Destination MODBUS

- As a step 1, User must activate the “source of the data” with parameter G31 to on.
- G32 parameter with the System Manager IP address (please consider also to add the port number like IP:PORT)
- G33 parameter with a valid User defined into System Manager
- G34 parameter with the password of the User



After this configuration done, X-Gate will start to automatically collect data from the System Manager and automatically will create all the CDF files of the discovered devices (nodes) and create the related device in the Network Configuration page. As a step 2, User must activate the “Destination of the data”, in this case Modbus TCP/IP. In this case the activities to be done are the same already described for the Use Case 1 to set up the destination of the data.

Update


10.1 X-Gate Software

User can update the X-Gate software using the feature available in the settings page. Software can be downloaded from the official Danfoss “Software ADAP-KOOL” website. The final “*.bin” file must be imported and used for the upgrade.



CDF Files

User can upload / delete available CDF files on the X-Gate using the Files menu.



Annexure

Supported BACNET features

- Who Is Router to Network
- I Am Router to Network
- Reject Message to Network
- Router Busy to Network
- Router Available to Network
- What Is Network Number
- Network Number Is
- Confirmed Request
- Unconfirmed Request
- Simple ACK
- Complex ACK
 - Error PDU
- Reject PDU
- Abort PDU
- Read Property
- Write Property
- Read Property Multiple
- Write Property Multiple
- Subscribe COV
- COV Notification
- Who Is
- I Am
- Who Has
- I Have
- Time Synchronization
- Device Communication Control
- BACnet objects:

- Device (D)
- Integer Value (IV)
- Positive Integer Value (PI)
- Analog Value (AV)
- Analog Output (AO)
- Analog Input (AI)
- Large Analog Value
- Binary Input (BI)
- Binary Output (BO)
- Binary Value (BV)
- Multistate Input
- Multistate Output
- Multistate Value
- Bitstring Value
- Character String Value

Supported BACNET properties

- Object Identifier
- Object Type
- Object Name
- Description
- Present Value
- Event State
- Units
- Resolution
- Out of service
- Status Flags
- Reliability
- Min Pres Value
- Max Pres Value
- Polarity

The X-Gate supports BACnet segmentation.

Danfoss A/S

- Climate Solutions
- danfoss.com
- +45 7488 2222


Catalogue descriptions. d/Vertisementse. and whether made available in writing, orally, electronically once desian, wend, shall be considered informative, which is only binding if and to thuals, extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also

applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

- © Danfoss | Climate Solutions | 2024.11
- BC491019063010en-000301 | 20

Documents / Resources

	<p>Danfoss X-Gate Gateway Unit Type [pdf] User Guide X-Gate Gateway Unit Type, X-Gate, Gateway Unit Type, Unit Type, Type</p>
---	---

References

-  [Engineering Tomorrow | Danfoss](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.