



DASH Multi Plate Mini Maker User Guide

[Home](#) » [Dash](#) » DASH Multi Plate Mini Maker User Guide 

Contents

- [1 DASH Multi Plate Mini Maker](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Before First Use](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



DASH Multi Plate Mini Maker



Product Information

The Multi-Plate Mini Maker is a versatile kitchen appliance designed for cooking various types of waffles. It comes with removable plates that allow you to easily switch between different shapes and sizes of waffles. The appliance features a top and bottom plate, labeled as “Top” and “Bottom,” respectively. The plates are easy to install and remove, ensuring convenience and flexibility in cooking.

Product Usage Instructions

- 1. Before First Use:** Prior to using the Mini Maker, it is important to note that you should never touch the Removable Plates or the Cover while the appliance is in use. Additionally, avoid touching the plates or the inside of the Mini Maker when it is plugged in and preheating, or when it has not fully cooled.
- 2. Installing Your Plates:** To install the Removable Plates, follow these steps
 - Slide the plates into the slots located at the top and bottom of the Mini Maker. Each plate is labeled as “Top” or “Bottom.”
 - The Top Plate should fit into the top of the Maker, while the Bottom Plate should fit into the bottom of the Maker. You should feel a slight click when each plate is properly in place.
 - While installing or removing the plates, avoid lifting the Cover so that your arm is over the Removable Plates to prevent potential injuries from the hot plates.
- 3. Cooking with your Multi-Plate Mini Maker:** To cook waffles in different shapes using specific plates, follow these guidelines
 - For heart-shaped or pumpkin-shaped waffles using the Heart Waffle Plate or Pumpkin Waffle Plate, use approximately 1.5 tablespoons of batter.
 - For circular waffles with a diameter of approximately 4 inches, use 3-4 tablespoons of batter.
- 4. Removing Your Plates:** To remove the Removable Plates, follow these steps
 - Press the corresponding Release Tabs inside the Handle. There is one Release Tab at the bottom and another at the top.
 - Always lift and lower the Cover from the right side using the Cover Handle to avoid hitting the Release Tab and potentially damaging the appliance.

For further assistance or inquiries, you can contact customer support at 1-800-898-6970 or visit the official website at [@bydash](#).

Before First Use



- Never touch the Removable Plates or Cover while appliance is in use.
- Never touch the Removable Plates or the inside of the Mini Maker while it is plugged in and preheating, or when it has not fully cooled.

- DO NOT lift the Cover so that your arm is over the Removable Plates as they are hot and may cause injury.

Installing Your Plates

Install your Removable Plates by sliding them into the slots located at the top and bottom of the Mini Maker (photo A). Each Removable Plate is labeled either "Top" or "Bottom." The Top Plate fits into the top of the Maker, and the Bottom Plate fits into the bottom of the Maker (photo B). You should feel a slight click when each plate is properly in place.³



TOP



BOTTOM




1-800-898-6970 | @bydash | bydash.com

Cooking with your Multi-Plate Mini Maker

To cook a waffle in the shape of a heart or pumpkin using the Heart Waffle Plate or Pumpkin Waffle Plate, use 1.5 tbsp of batter. For a 4" circular waffle, use 3-4 tbsp of batter.

1.5 TBSP



3-4 TBSP



Removing Your Plates

To remove them, press the corresponding Release Tabs inside the Handle [there's one at the bottom (photo A) and one at the top (photo B).]



CAUTION: Always lift and lower from the right side using the Cover Handle to avoid ! hitting the Release Tab.

1-800-898-6970 | @bydash | bydash.com

Documents / Resources



[DASH Multi Plate Mini Maker](#) [pdf] User Guide
Multi Plate Mini Maker, Plate Mini Maker, Mini Maker, Maker

References

- [Dash](#)