

DELTA DVP04PT-S PLC Analog Input Output Module Instructions

Home » Delta » DELTA DVP04PT-S PLC Analog Input Output Module Instructions



Contents

- 1 DELTA DVP04PT-S PLC Analog Input Output
- **2 Product Usage Instructions**
- 3 Introduction
- **4 Product Profile & Dimension**
- 5 Wiring
- **6 Specifications**
- 7 Control Register
- 8 FAQ
- 9 Documents / Resources
 - 9.1 References



DELTA DVP04PT-S PLC Analog Input Output Module



Specifications

• Model: DVP04/06PT-S

• Input: 4/6 points of RTDs

• Output: 16-bit digital signals

• Installation: Control cabinet free of dust, humidity, electric shock, and vibration

• Dimensions: 90.00mm x 60.00mm x 25.20mm

Open-type device

• Separate power unit

Product Usage Instructions

Installation Guidelines

- Ensure the control cabinet is free of airborne dust, humidity, electric shock, and vibration.
- Use a safeguard to prevent unauthorized access or accidents.
- Avoid connecting AC power to any I/O terminals.

Powering Up

- Double-check all wiring before powering up the device.
- Avoid touching any terminals for a minute after disconnecting the device.
- Correctly ground the terminal to prevent electromagnetic interference.

External Wiring

- Follow the wiring diagram provided in the manual for proper connection.
- Use shielded cables for better signal integrity.
- Keep wires as short as possible to reduce noise interference.

Introduction


Thank you for choosing Delta DVP series PLC. DVP04/06PT-S is able to receive 4/6 points of RTDs and convert them into 16-bit digital signals. Through FROM/TO instructions in DVP Slim series MPU program, the data can be read and written. There are many 16-bit control registers (CR) in modules. The power unit is separate from it and is small in size and easy to install.

DVP04/06PT-S is an OPEN-TYPE device. It should be installed in a control cabinet free of airborne dust, humidity, electric shock and vibration. To prevent non-maintenance staff from operating DVP04/06PT-S, or to prevent an accident from damaging DVP04/06PT-S, the control cabinet in which DVP04/06PT-S is installed should be equipped with a safeguard. For example, the control cabinet in which DVP04/06PT-S is installed can be unlocked with a special tool or key.

DO NOT connect AC power to any of I/O terminals, otherwise serious damage may occur. Please check all wiring again before DVP04/06PT-S is powered up. After DVP04/06PT-S is disconnected, Do NOT touch any terminals in

a minute. Make sure that the ground terminal on DVP04/06PT-S is correctly grounded in order to prevent electromagnetic interference.


Product Profile & Dimension




Status indicator (POWER, RUN and ERROR)	2. Model name	3. DIN rail clip
4. I/O terminals	5. I/O point indicator	6. Mounting holes
7. Specification label	8. I/O module connection port	9. I/O module clip
10. DIN rail (35mm)	11. I/O module clip	12. RS-485 communication port (DV P04PT-S)
13. Power connection port (DVP04PT-S)	14. I/O connection port	

Wiring

I/O Terminal Layout



External Wiring



Notes

• Use only the wires that are packed with the temperature sensor for analog input and separate from other power line or any wire that may cause noise.

- 3-wire RTD sensor provides a compensation loop that can be used to subtract the wire resistance while 2-wire RTD sensor has no mechanism to compensate. Use cables (3-wired) with the same length (less than 200 m) and wire resistance of less than 20 ohm.
- If there is noise, please connect the shielded cables to the system earth point, and then ground the system earth point or connect it to the distribution box.
- Please keep wires as short as possible when connecting the module to a device whose temperature is going to be measured, and keep the power cable used as far away from the cable connected to a load as possible to prevent noise interference.
- Please connect on a power supply module and on the temperature module to a system ground, and then ground the system ground or connect the system ground to a distribution box.

Specifications

Electrical Specifications

Max. rated power consumption	2W
Operation/storage	Operation: 0°C~55°C (temp.), 5~95% (humidity), pollution degree 2 Storage: -25°C~70°C (temp.), 5~95% (humidity)
Vibration/shock resistance	International standards: IEC61131-2, IEC 68-2-6 (TEST Fc)/ IEC61131-2 & IEC 68-2-27 (TEST Ea)
Series connection to DVP- PL C MPU	The modules are numbered from 0 to 7 automatically by their distance from MP U. No.0 is the closest to MPU and No.7 is the furthest. Maximum 8 modules are allowed to connect to MPU and will not occupy any digital I/O points.

Functional Specifications

DVP04/06PT-S	Celsius (°C)	Fahrenheit (°F)			
Analog input channel	4/6 channels per module				
Sensors type	2-wire/3-wire Pt100 / Pt1000 3850 PPM/°C (DIN 43760 JIS C1604-1989) / Ni100 / Ni1000 / LG-Ni1000 / Cu100 / Cu50/ 0~300Ω/ 0~3000Ω				
Current excitation	1.53mA / 204.8uA				

Temperature input range	Please refer to the temperature/digital value characteristic curve.			
Digital conversion range	Please refer to the temperature/digital value characteristic curve.			
Resolution	0.1°C	0.18°F		
Overall accuracy	±0.6% of full scale during 0 ~ 55°C (32	~ 131°F)		
Response time	DVP04PT-S: 200ms/channel; DVP06PT-S: 160/ms/channel			
Isolation method (between digital and analog c ircuitry)	There is no isolation between channels. 500VDC between digital/analog circuits and Ground 500VDC between analog circuits and digital circuits 500VDC between 24VDC and Ground			
Digital data format	2's complement of 16-bit			
Average function	Yes (DVP04PT-S: CR#2 ~ CR#5 / DVP06PT-S: CR#2)			
Self diagnostic function	Every channel has the upper/lower limit detection function.			
Supported, including ASCII/RTU mode. Default communication format E, 1, ASCII; refer to CR#32 for details on the communication format. Note1: RS-485 cannot be used when connected to CPU series PLCs. fer to Slim Type Special Module Communications in the appendix E of programming manual for more details on RS-485 communication setu				

^{*1:} The unit of temperature would be displayed as 0.1°C/0.1°F. If the temperature unit is set to be Fahrenheit, the second decimal place would not be shown.

Control Register

CR#	Address	Latche d	Attribut e	Register content	Description
#0	H'4064	0	R	Model name (Set up by the system)	DVP04PT-S model code= H'8A DVP06PT-S model code = H'CA

					b15~12	b11~8	b7~4	b3~0
					CH4	СНЗ	CH2	CH1
					Take CH1 mple.	mode (b3	3,b2,b1,b0) for exa
					1. (0,0,0,0): Pt100 (default)	
					2. (0,0,0,1): Ni100		
					3. (0,0,1,0): Pt1000		
					4. (0,0,1,1): Ni1000		
					5. (0,1,0,0): LG-Ni1(000	
					6. (0,1,0,1): Cu100		
					7. (0,1,1,0): Cu50		
#1	H'4065	x	R/W	CH1~CH4 Mode setting	8. (0,1,1,1): 0~300 Ω	Ω	
#1	114003	^	11/ 44	OTTI TOTIA MODE Setting	9. (1,0,0,0): 0~3000	Ω	
					10. (1,1,1,	1)The cha	annel is dis	sabled.
					Mode 8 ar P04PT-S			ole for DV
					DVP06PT	-S V4.12 d	or later.	
	H'4066			DVP04PT-S: CH1 average number	Number p calculation n CH1. Setting rai is K10.	of "avera	ige" tempe	erature o
#2	_	0	R/W	DVP06PT-S: CH1~CH6 average number	Number p calculation n CH1 ~ 6 Setting ran	of "avera	ige" tempe	erature o
					is K10.			
				DVP04PT-S:	Number p calculation n CH2.		-	
#3	H'4067	0	H'4067	CH2 average number	Setting rail is K10.	nge: K1~k	(20. Defau	ılt setting
					10 1010.			

#4	H'4068	0	H'4068	DVP04PT-S: CH3 average number	Number piece of readings used for the calculation of "average" temperature on CH3. Setting range: K1~K20. Default setting is K10.
#5	H'4069	0	H'4069	DVP04PT-S: CH4 average number	Number piece of readings used for the calculation of "average" temperature on CH4. Setting range: K1~K20. Default setting is K10.

#6	H'406A	х	R	CH1 average degrees	
#7	H'406B	х	R	CH2 average degrees	
#8	H'406C	Х	R	CH3 average degrees	DVP04PT-S: Average degrees for CH1 ~ 4 DVP06PT-S:
#9	H'406D	X	R	CH4 average degrees	Average degrees for CH1 \sim 6 Unit: 0.1°C, 0.01 Ω (0 \sim 300 Ω), 0.1 Ω (0 \sim 3000 Ω)
#10	_	x	R	CH5 average degrees	
#11	_	x	R	CH6 average degrees	
#12	H'4070	х	R	CH1 average degrees	
#13	H'4071	х	R	CH2 average degrees	
#14	H'4072	х	R	CH3 average degrees	DVP04PT-S: Average degrees for CH1 ~ 4 DVP06PT-S:
#15	H'4073	х	R	CH4 average degrees	
#16	_	X	R	CH5 average degrees	
	l	I	I	1	Average degrees for CH1 \sim 6 Unit: 0.1°F, 0.01 Ω (0 $\sim\!300~\Omega),~0.1~\Omega$ (0 $\sim\!3000~\Omega)$

	T	I		I	1
#17	_	x	R	CH6 average degrees	
#18	H'4076	x	R	Present temp. of CH1	
#19	H'4077	х	R	Present temp. of CH2	DVP04PT-S:
#20	H'4078	x	R	Present temp. of CH3	Present temperature of CH 1~4 DVP06PT-S: Present temperature of CH1~6 Unit: 0.1°C, 0.01 Ω
#21	H'4079	x	R	Present temp. of CH4	$(0~300~\Omega),$ 0.1 Ω (0~3000 Ω)
#22	_	x	R	Present temp. of CH5	
#23	_	х	R	Present temp. of CH6	
#24	H'407C	х	R	Present temp. of CH1	
#25	H'407D	х	R	Present temp. of CH2	
#26	H'407E	х	R	Present temp. of CH3	DVP04PT-S: Present temperature of CH 1~4
#27	H'407F	х	R	Present temp. of CH4	DVP06PT-S: Present temperature of CH 1~6 Unit: 0.1°F, 0.01 Ω
#28	_	х	R	Present temp. of CH5	(0~300 Ω), 0.1 Ω (0~3000 Ω)
#29	_	x	R	Present temp. of CH6	
#29	H'4081	Х	R/W	DVP04PT-S: PID mode setup	Set H'5678 as PID mode and other values as norm al mode Default value is H'0000.

			1						
#30	H'4082	x	R	Error status	Data register stores the error status. Refer to ror code chart for details.		er to the er		
	H'4083	0	R/W	DVP04PT-S: Communication addres s setup	Set up the RS-485 communication address; sett range: 01~254. Default: K1		ss; setting		
#31	_	х	R/W	DVP06PT-S: CH5~CH6 Mode settin g		le: b0 ~ b3 CH6 mode: b4 ~ b7 1 for reference			
	H'4084	0	R/W	DVP04PT-S: Communication format setting	For baud rate, the settings are 4,800/9,600/19,200 38,400/57,600/ 115,200 bps. Communication format: ASCII: 7,E,1 / 7,O,1 / 8,E,1 / 8,O,1 / 8,N,1 RTU: 8,E,1 / 8,O,1 / 8,N,1 Factory default: ASCII,9600,7,E,1 (CR#32=H'000) Refer to *CR#32 communication format settings at the end of this table for more information.		:2=H'0002 settings a		
32		X	R/W	DVP06PT-S: CH5~CH6 Error LED indicator sett ing					b2~0 CH5 S ON, the ED indicat

				DVP04PT-S: CH1~CH4	b15~12	b11~9	b8~6	b5~3	b2~0
#33	H'4085	О	R/W	Reset to default setting And Error LED indicato r setting	ERR LED	CH4	СНЗ	CH2	CH1
					If b2~b0 ar 1 will be re		00, all the s	etting valu	es of CH

		X	R/W	DVP06PT-S: CH1~CH4 Reset to default setting And CH1~CH4 Error L ED indicator setting	to the defaults. To reset all channels to defaults, set b11~0 to H'924 (DVP 04PT-S supports single and all chan nels reset; DVP06PT- S supports all channels reset only). b12~15 corres pond to CH1~4, when bit is ON, the scale exceeds the range, and the Error LED indicat or flashes.
#34	H'4086	0	R	Firmware version	Display version in hexadecimal. ex: H'010A = version 1.0A

#35 ~ #48 For system use

Symbols: O means latched. (Supported with RS485, but does not support when connecting to MPUs.)

X means not latched. R means can read data by using FROM instruction or RS-485. W means can write data by using TO instruction or RS-485.

- 1. Added the RESET function is only for 04PT-S modules with firmware V4.16 or later and not available for 06PT-S. Connect the module power input to 24 VDC and write H'4352 into CR#0 and then turn the power off and on again; all parameters in modules, including communication parameters are restored to factory defaults.
- 2. If you want to use Modbus address in decimal format, you can transfer a hexadecimal register to decimal format and then add one to have it become a decimal Modbus register address. For example transferring the address "H'4064" of CR#0 in hexadecimal format to decimal format, to have the result 16484 and then adding one to it, you have 16485, the Modbus address in decimal format.
- 3. CR#32 communication format settings: for DVP04PT-S modules with firmware V4.14 or previous versions,

b11~b8 data format selection is not available. For ASCII mode, the format is fixed to 7, E, 1 (H'00XX) and for RTU mode, the format is fixed to 8, E, 1 (H'C0xx/H'80xx). For modules with firmware V4.15 or later, refer to the following table for setups. Note that the original code H'C0XX/H'80XX will be seen as RTU, 8, E, 1 for modules with firmware V4.15 or later.

b15 ~ b12		b11 ~ b8		b7 ~ b0					
ASCII/RTU, exchange low and high byte of CRC check code		Data format		Baud rate					
Description									
H'0	ASCII	H'0	7,E,1*1	H'01	4800 bps				
	RTU,	H'1	8,E,1	H'02	9600 bps				
H'8	do not exchange low and high byte of CRC check c ode	H'2	reserved	H'04	19200 bps				
	RTU,	H'3	8,N,1	H'08	38400 bps				
H'C	exchange low and high b yte of CRC check code	H'4	7,0,1*1	H'10	57600 bps				
		H'5	8.O,1	H'20	115200 bps				

Note *1: This is only available for ASCII format.


Ex: Write H'C310 into CR#32 for a result of RTU, exchange low and high byte of CRC check code, 8,N,1 and baud rate at 57600 bps.

- 1. RS-485 function codes: 03'H is for reading data from registers. 06'H is for writing a data word to registers. 10'H is for writing multiple data words to registers.
- 2. CR#30 is the error code register.
 - **Note:** Each error code will have a corresponding bit and should be converted to 16-bit binary numbers (Bit0~15). Two or more errors may happen at the same time. Refer to the chart below:

Bit number	0	1	2	3
Description	Power source abnormal	The contact is not connected to anything.	Reserved	Reserved
Bit number	4	5	6	7
Description	Reserved	Reserved	average number error	Instruction error
Bit number	8	9	10	11
Description	CH1 Abnormal conve	CH2 Abnormal conve	CH3 Abnormal conversion	CH4 Abnormal conversion
Bit number	12	13	14	15
Description	CH5 Abnormal conve	CH6 Abnormal conversion	Reserved	Reserved

1. Temperature/Digital Value Characteristic Curve

The mode of measuring Celsius (Fahrenheit) temperature:



Sensor	Temperature range)	Digital value conversion range		
Selisoi	°C (Min./Max.)	°F (Min./Max.)	°C (Min./Max.)	°F (Min./Max.)	
Pt100	-180 ~ 800°C	-292 ~ 1,472°F	K-1,800 ~ K8,000	K-2,920 ~ K14,720	
Ni100	-80 ~ 170°C	-112 ~ 338°F	K-800 ~ K1,700	K-1,120 ~ K3,380	
Pt1000	-180 ~ 800°C	-292 ~ 1,472°F	K-1,800 ~ K8,000	K-2,920 ~ K14,720	
Ni1000	-80 ~ 170°C	-112 ~ 338°F	K-800 ~ K1,700	K-1,120 ~ K3,380	
LG-Ni1000	-60 ~ 200°C	-76 ~ 392°F	K-600 ~ K2,000	K-760 ~ K3,920	
Cu100	-50 ~ 150°C	-58 ~ 302°F	K-500 ~ K1,500	K-580 ~ K3,020	
Cu50	-50 ~ 150°C	-58 ~ 302°F	K-500 ~ K1,500	K-580 ~ K3,020	
Sensor	Input resistor range		Digital value conversion range		
0~300Ω	0~300Ω		0~300Ω	0Ω ~ 320Ω	
0~3000Ω	0Ω ~ 3200Ω	K0 ~ 32000	0~3000Ω	0Ω ~ 3200Ω	

1. When CR#29 is set to H'5678, CR#0 ~ CR#34 can be used for PID settings with DVP04PT-S version V3.08 and above.

FAQ

- Q: Can I connect AC power to any of the I/O terminals?
 - **A:** No, connecting AC power to any I/O terminals can cause serious damage. Always double-check the wiring before powering up.
- Q: How should I handle the device after disconnection?
 - A: After disconnecting the device, avoid touching any terminals for at least a minute to ensure safety.
- Q: What should I do to prevent electromagnetic interference?
 - **A:** Ensure that the ground terminal on the device is correctly grounded to prevent electromagnetic interference.

Documents / Resources



DELTA DVP04PT-S PLC Analog Input Output Module [pdf] Instructions

DVP04PT-S, DVP06PT, DVP04PT-S PLC Analog Input Output Module, DVP04PT-S, PLC Analog Input Output Module, Analog Input Output Module, Input Output Module, Output Module, Module



▲ NELT

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.