



# DieseRC 30V Secure Remote Control Switch Instruction Manual


[Home](#) » [DieseRC](#) » DieseRC 30V Secure Remote Control Switch Instruction Manual 

## Contents

- [1 DieseRC 30V Secure Remote Control Switch](#)
- [2 Specifications](#)
- [3 PRODUCT INFORMATION](#)
- [4 PRODUCT DETAIL](#)
- [5 WIRING DIAGRAM](#)
- [6 WIRING DIAGRAM](#)
- [7 Operating Mode](#)
- [8 CUSTOMER SERVICE](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)



**DieseRC 30V Secure Remote Control Switch**



## Specifications

- **Working voltage:** DC 5V~30V
- **Input/output voltage:** 1~250V
- **Output Type:** Passive output
- **Quiescent Current:** 97dbm
- **Max current:** Not specified
- **RF frequency:** Not specified
- **Working temperature:** Not specified
- **Receiving Sensitivity:** Not specified
- **Amount of storage remote controls:** 20 pieces
- **Support encoding:** 1527 Learning code, 2262 fixed code
- **RF Operating mode:** ASK superheterodyne wireless reception
- **Receiving range:** Open space is more than 50 meters
- **Remote operating mode:** Momentary Mode / Toggle Mode / Latched Mode / Delay Mod

## PRODUCT INFORMATION

### TYPE----2402

Technical Data	
Working voltage	DC 6V~30V
Input/output vlotage	1~250V
Output Type	Passive output
Quiescent Current	<5MA
Max current	10A
RF frequency	433MHz
Working temperature	-30~ +80
Receiving Sensitivity	>97dbm
Amount of storage remote controls	20 pieces
Support encoding	1527 Learning code, 2262 fixed code
RF Operating mode	ASK superheterodyne wireless reception
Receiving range	Open space is more than 50 meters
Remote operating mode	Momentary Mode /Toggle Mode /Latched Mode


## PRODUCT DETAIL

Input / output volts: 1V~250V  
Work volts: DC 6-30V




- **NO** :Normally open pin
- **COM**: Common pin
- **NC**: Normally closed pin

## WIRING DIAGRAM



## WIRING DIAGRAM



### Warning

1. Usually the receiver and transmitter have been paired with each other in factory. If not, please reprogram them.
2. Reset before you want to change the operating mode.
3. After reset, all the remote controls cannot work anymore.
4. Replace the battery in time when the remote transmitter voltage is low. To get the stronger signal transmission.
5. Slightly stretch the antenna on the receiver for better signal reception.
6. The remote transmitter need to have 2 or more buttons, if you want to set up in latched mode.
7. The output type is passive output / potential-free contacts.

### Operating Mode

#### Momentary Mode

1. Press and hold the button, relay will turn on;
2. Release the button, this relay will turn off.

#### How to program

1. Press the learning button (on the receiver) 1 time. The indicator LED on the receiver will light up;
2. Press one button on the remote transmitter. The indicator LED on the receiver will flashing several times and then light down. Succeed.

#### Toggle Mode

1. Press button "A", relay will turn on;
2. Press button "A" again, this relay will turn off.

#### How to program

1. Press the learning button (on the receiver) 2 times. The indicator LED on the receiver will light up;
2. Press one button on the remote transmitter. The indicator LED on the receiver will flashing several times and then light down. Succeed.

### Latched mode

1. Press button "A", relay will turn on;
2. Press button "B", this relay will turn off.

### How to program

1. Press the learning button (on the receiver) 3 times. The indicator LED on the receiver will light up;
2. Press button "A" on the remote transmitter. The indicator LED on the receiver will flashing several times and then light up;
3. Press button "B" on the remote transmitter. The indicator LED on the receiver will light down. Succeed.

### Delay Mode

Press and hold on the button, relay will turn on;

## CUSTOMER SERVICE

- **Work volts:** DC5V~30V
- **Max current:** 10Amp

If there is any questions about the products,please contact us firstly. We will do our best to solve your problem.  
**Thank you.**

- Huizhou Wenqiao Electronic Technology Co., Ltd.
  - **Address:** 1203, Building T19, Fangzhilonghuwan, Sanhuan South Road, Huicheng District, Huizhou City, Guangdong Province, China 516000
  - **WhatsApp :** +86 13502278583 / +86 18138805271
  - **Email :** [dieseelectronic@163.com](mailto:dieseelectronic@163.com)
- 

## Documents / Resources



[DieseRC 30V Secure Remote Control Switch](#) [pdf] Instruction Manual  
30V Secure Remote Control Switch, 30V, Secure Remote Control Switch, Remote Control Switch, Control Switch, Switch

## References

- [User Manual](#)

Manuals+.