



4 Button Digital Watch User Guide

[Home](#) » [Digital Watch](#) » 4 Button Digital Watch User Guide 

Contents

- 1 4 Button Digital Watch
- 2 BUTTON LAYOUT
- 3 DAILY ALARM MODE
- 4 ILLUMINATING THE DISPLAY
- 5 SETTING THE ALARM
- 6 DISPLAYING THE DATE
- 7 SETTING NORMAL TIME
- 8 12/24 HOURS FORMAT
- 9 STOPWATCH MODE
- 10 Related Posts

DIGITAL WATCH

4 Button Digital Watch



BUTTON LAYOUT



This watch is a generic representation of a 4-Button Digital watch. Some models may or may not include Light Button M1.

DAILY ALARM MODE



- In normal time mode, press R2 to display the alarm time.
- Hold R2 and press R1 to select the alarm symbol “●”)” (alarm will sound every day at the pre-set time) and chime symbol “🔔” (chime will sound every hour on the hour) alternatively on or off.

ILLUMINATING THE DISPLAY



In normal time mode, press and hold the R1 or M1 button (when available) to turn on the dial light.

SETTING THE ALARM



- In normal time mode, press and hold L2 first to stopwatch mode and hold 2 seconds to alarm time set mode; the hour digit begins flashing .
- Press R2 to advance the hour.
- Press R1 to switch to the minute digit and advance with R2.
- Press L2 to return to the normal time mode when the alarm is set to the desired time.

DISPLAYING THE DATE



- While in the Normal Time Mode, press R1 to display the Month/Date display.
- Hold R1 and R2 to alternate the Month/Date and Date/Month (when available).

SETTING NORMAL TIME



- In normal time mode, Hold L2 for 2 seconds to alarm time set mode, then L2 again to normal time set mode, the second digits begin flashing.
- Press R2 to reset the seconds to “00”, press R1 to switch to the minute digits.
- Press R2 to advance the minutes. Press R1 to switch to the hour digits.
- Press R2 to advance the hour. Press R1 to switch to the date.
- Once the date is set, press L2 to return to Normal Time Mode.

12/24 HOURS FORMAT



- In normal time mode, press R2 to display the alarm time.
- Hold R2 and press L2 to select 12 or 24-hour format.
- The “PM” or “AM” symbol on the display means both normal time and alarm time are in 12-hour format.
- Otherwise, they are in a 24-hour format.

STOPWATCH MODE



- In normal time mode, press L2 to display the stopwatch mode.
- Press R1 to start, then press R1 again to stop.
- Press R2 to return to zero.

Download PDF: [4 Button Digital Watch User Guide](#)