

DINSTAR SIP Intercom DP9 Series



DINSTAR SIP Intercom DP9 Series Installation Guide


[Home](#) » [DINSTAR](#) » DINSTAR SIP Intercom DP9 Series Installation Guide 

Contents

- [1 DINSTAR SIP Intercom DP9 Series](#)
- [2 Product Usage Instructions](#)
- [3 FAQ](#)
- [4 Packing List](#)
- [5 Physical Specifications](#)
- [6 Front Panel](#)
- [7 DP9 Series](#)
- [8 Interface Description](#)
- [9 Wiring Instructions](#)
- [10 Installation](#)
- [11 Obtaining the device's IP address](#)
- [12 SIP Intercom Setting](#)
- [13 Door Open Setting](#)
- [14 CONTACT](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)

DINSTAR

DINSTAR SIP Intercom DP9 Series



Product Usage Instructions

Interface Description

- **POE:** Ethernet interface, standard RJ45 interface, 10/100M adaptive. It is recommended to use five or five types of network cable.
- **12V+, 12V-:** Power interface, 12V/1A input.
- **S1-IN, S-GND:** To connect the indoor exit button or alarm input.
- **NC, NO, COM:** To connect door lock and alarm.

The DP9 series only supports an external power supply to connect the electronic lock. Wiring instructions:

- **NO:** Normal Open, idle status of the electric lock is opened.
- **COM:** COM1 interface.
- **NC:** Normal Closed, idle status of the electric lock is closed.

1. Drill four holes on the wall with a spacing of 60*60 mm for the frame installation. Insert plastic expansion tubes and use KA4*30 screws to tighten the back panel on the wall.
2. Put the front panel to the frame and tighten it with 4 X M3*8mm screws.

After powering on the device, it will obtain the IP address through DHCP. Press the dial key for ten seconds on the device panel to hear the IP address through voice broadcast.







1. **Log in the Device Web GUI:** Access the device via the IP address in a browser. Default credentials are admin/admin.
2. **Add the SIP account:** Configure SIP account details and server information on the device interface.
3. **Set Door Access Parameters:** Configure door access settings including DTMF codes, RFID cards, and HTTP access.










4. **Open Door by DTMF Code:** Enable this function and set the DTMF code for opening the door in the device settings.

FAQ

- **Q:** How can I reset the device to factory settings?
- **A:** To reset the device to factory settings, press and hold the reset button for 10 seconds until the device restarts.
- **Q:** Can I use this intercom with a VoIP service provider?
- **A:** Yes, this SIP intercom can be configured to work with compatible VoIP service providers. Refer to the user manual for specific settings.

Packing List

SIP Intercom	Installation	Accessories
<p>DP91</p> 		
<p>DP92</p> 		


<p>DP92V</p> 	 <p>100.00mm 60.00mm 170.00mm 60.00mm</p> <p>threading hole</p> <p>4×mounting hole</p> <p>4×screw</p> <p>plug head , can interchange for threading hole</p>	
<p>DP98</p> 	 <p>62.50mm 60.00mm 132.00mm 60.00mm</p> <p>4×mounting hole</p> <p>threading hole</p> <p>4×Screw</p> <p>plug head , can interchange for threading hole</p>	
<p>DP98V</p> 	 <p>62.50mm 60.00mm 132.00mm 60.00mm</p> <p>4×mounting hole</p> <p>threading hole</p> <p>4×Screw</p> <p>plug head , can interchange for threading hole</p>	

Physical Specifications


DP91 Device Dimension(L*W*H)	88*120*35 mm
DP92 Device Dimension(L*W*H)	105*132*40 mm
DP92V Device Dimension(L*W*H)	105*175*40 mm
DP98 Device Dimension(L*W*H)	88*173*37 mm
DP98V Device Dimension(L*W*H)	88*173*37 mm

Front Panel


Front Panel (Part of the models)




DP91




DP92



DP92V



DP98




DP98V

DP9 Series

	Button	HD Camera	4G	Door Access
DP91-S	Single	✖	✖	DTMF tones
DP91-D	Double	✖	✖	DTMF tones
DP92-S	Single	✖	✖	DTMF tones
DP92-D	Double	✖	✖	DTMF tones
DP92-SG	Single	✖	√	DTMF tones
DP92-DG	Double	✖	√	DTMF tones
DP92V-S	Single	√	✖	DTMF tones
DP92V-D	Double	√	✖	DTMF tones
DP92V-SG	Single	√	√	DTMF tones
DP92V-DG	Double	√	√	DTMF tones
DP98-S	Single	✖	✖	DTMF tones
DP98-MS	Double	✖	✖	DTMF tones, RFID card
DP98V-S	Single	√	✖	DTMF tones
DP98V-MS	Double	√	✖	DTMF tones, RFID card

Interface Description





Name	Description
POE	Ethernet interface: standard RJ45 interface, 10/100M adaptive, it is recommended to use five or five types of network cable
12V+, 12V-	Power interface: 12V/1A input
S1-IN, S-GND	To connect the indoor exit button or alarm input
NC, NO, COM	To connect the door lock, alarm

Wiring Instructions

- DP9 series only supports an external power supply to connect the electronic lock.
- NO: Normal Open, idle status of the electric lock is opened
- COM: COM1 interface

- NC: Normal Closed, idle status of the electric lock is closed

External	Power off, door open	Power on, door open	Connections
√	√		
√		√	

Installation

Preparations

Check the following contents

- L-type screwdriver x 1
- RJ45 plugs x2 (1 spare)
- KA4 X30 mm screws x 5
- 6×30mm expansion tube x 5
- M3* 8mm screws x 2



Tools that may be required

- L-type screwdriver
- Screwdriver (Ph2 or Ph3), hammer, RJ45 crimper
- Electric impact drill with a 6mm drill bit

Steps Take DP98V for example)

1. Drill four holes on the wall with a spacing of 60*60 mm for the frame installation, then insert a plastic expansion tube, and next use KA4*30 screws to tighten the back panel on the wall.
2. Put the front panel to the frame. With 4 X M3*8mm screws. Tighten the front panel to the back panel on the

wall.



Obtaining the device's IP address

- After the device is powered on. By default, the device will get the IP address through DHCP.
- Press the dial key for ten seconds on the device panel, the intercom will voice broadcast the IP address.

SIP Intercom Setting

Log in the Device Web GUI

- Access the device by entering the device IP (e.g. <http://172.28.4.131>) through the browser, and the device login interface will open after logging in. The default user name of the interface is admin and the password is admin.

Username

Password

Language

 ▼

☐ Remember Username/Password

Login

Add the SIP account

- Configure the SIP account status, register name, username, password, and SIP server IP and port by assigning the SIP account on the server side respectively, and finally click the submit button.

DINSTAR

StatusAccountNetworkEquipmentPhoneBookMaintenanceSecurityDefault2024/0

BasicAdvancedCodecs

SIP Account

StatusDisabled

AccountAccount1: 1001

ActiveDisabled

Display Name1001

Register Name1001

Username1001

Password*****

SIP Server 1

Server IP172.27.10.5

Port5060

Registration Expires1800

(30~65535s)

Set Door Access Parameters

- Click “Equipment->Access” to set door access parameters. Including open door By DTMF Code, Access Card (RFID card & password) and HTTP (username & password of HTTP door open).

DINSTAR

StatusAccountNetworkEquipmentPhoneBookMaintenanceSecurityDefault password2024/04/15 1

BasicTime&DateCall FeatureVoiceRingtonesDial PlanAction URLMulticastIntercomDoor LockAccessAlarmCamera

Open Door By DTMF Code

ActiveEnabled

Door 11

Door 22

All Doors3

Identify Door Phone

Identify

Submit

Access Card

Door opening methodRFID

Search By Name

Search

Cancel

Index	Name	RFID	Type	Door Number	Register Time	Period	
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>

Door Open Setting

Open Door by DTMF Code

- Click “Equipment->Access”, select “Open Door by DTMF Code” to enable this function, and set the DTMF code for opening the door;
- When the intercom calls the indoor monitor, during the call, the indoor monitor can send a DTMF code to open the door.

DINSTAR Status Account Network **Equipment** PhoneBook Maintenance Security Default passw 2024/04/15 1

Basic Time&Date Call Feature Voice Ringtones Dial Plan Action URL Multicast Intercom Door Lock **Access** Alarm Camera

Open Door By DTMF Code

Active Enabled ▾

Door 1 1

Door 2 2

All Doors 3

Identify Door Phone

Identify Submit

Access Card

Door opening method RFID ▾

Search By Name Search Cancel

Index	Name	RFID	Type	Door Number	Register Time	Period	
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>

Open Door by RFID Card Only supported by some models)

- Click “Equipment->Access”, select “Access Card”, swipe a new card to the intercom, then refresh the web GUI, RFID card number will be displayed on GUI automatically. then click “add”;
- The door can be opened successfully by swiping the card with the corresponding door card.

DINSTAR Status Account Network **Equipment** PhoneBook Maintenance Security Default passw 2024/04/15 1

Basic Time&Date Call Feature Voice Ringtones Dial Plan Action URL Multicast Intercom Door Lock **Access** Alarm Camera

Open Door By DTMF Code

Active Enabled ▾

Door 1 1

Door 2 2

All Doors 3

Identify Door Phone

Identify Submit

Access Card

Door opening method RFID ▾

Search By Name Search Cancel

Index	Name	RFID	Type	Door Number	Register Time	Period	
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>

Open Door By Password Only supported by some models)

- Click “Equipment->Access”, select “Access Card-> password”, and add the correct password to open the door configuration;
- Enter *password# on the device panel to open the door.

DINSTAR

StatusAccountNetworkEquipmentPhoneBookMaintenanceSecurity

Default password2024/04/15 12

Basic

Time&Date

Call Feature

Voice

Ringtones

Dial Plan

Action URL

Multicast

Intercom

Door Lock

Access

Alarm

Camera

Open Door By DTMF Code

Active

Door 1

Door 2

All Doors

Enabled

1

2

3

Identify Door Phone

Identify

Submit

Access Card

Door opening method

Search By Name

Password

Search

Cancel

Index	Name	Password	Type	Door Number	Register Time	Period	
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>
							<input type="checkbox"/>

CONTACT

Shenzhen Dinstar Co., Ltd

- Tel: +86 755 2645 6664
- Fax: +86 755 2645 6659
- Email: sales@dinstar.com, support@dinstar.com
- Website: www.dinstar.com

Documents / Resources

<div><div>DINSTAR</div><div>SIP Intercom DP9 Series</div><div>Quick Installation Guide</div><div><div>Shenzhen Dinstar Co., Ltd</div><div>Tel: +86 755 2645 6664</div><div>Fax: +86 755 2645 6659</div><div>Email: sales@dinstar.com, support@dinstar.com</div><div>Website: www.dinstar.com</div></div></div>	<div><div>DINSTAR SIP Intercom DP9 Series [pdf] Installation Guide</div><div>DP91, DP92, DP92V, DP98, DP98V, SIP Intercom DP9 Series, SIP Intercom, DP9 Series Intercom, Intercom</div></div>
--	---

References

- [D_VoIP Gateway | IP PBX | IP Phone Session Border Controller SIP Intercom DINSTAR](#)
- [D_VoIP Gateway | IP PBX | IP Phone Session Border Controller SIP Intercom DINSTAR](#)
- [User Manual](#)

