



Divine Keystone Operation Control Reference User Manual

[Home](#) » [Divine](#) » Divine Keystone Operation Control Reference User Manual 



Keystone Operation Control Reference Spa Control Manual



Button shapes and labels may vary.

Contents

- [1 Initial Start-up](#)
- [2 Preset Filter Cycles](#)
- [3 Diagnostic Messages](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Initial Start-up

Your spa will enter Priming Mode ('PR') when it is energized. During Priming Mode, press the "Jets" button(s) repeatedly and be sure all pumps are free of air. Priming Mode lasts less than 5 minutes. Press "Temp" to exit.

After Priming Mode, the spa will run in Standard Mode (see Mode section). Some panels may not have a “Temp” button. On these panels, the “Set,” “Warm,” or “Cool” buttons are used.



Temp Control

(80°F-104°F/26°C-40°C) The last measured water temperature is constantly displayed. The water temperature displayed is current only when the pump has been running for at least 2 minutes.

On panels with a single “Temp” or “Set” button, to display the set temperature, press the button once. To change the set temperature, press the button a second time before the display stops flashing. Each press of the button will continue to either raise or lower the set temperature. If the opposite direction is desired, allow the display to revert to the current water temperature. Press the button to display the set temperature, and again to make the temperature change in the desired direction.

On panels with “Warm” and “Cool” buttons, to display the set temperature, press “Warm” or “Cool” once. To change the set temperature, press a temperature button again before the display stops flashing. Each press of “Warm” or “Cool” will adjust the set temperature. After three seconds, the display will stop flashing and begin to display the current spa temperature.



Jets 1

Press “Jets 1” to turn pump 1 on or off, and to shift between low and high speeds (if equipped). The low-speed will turn off after 4 hours. High-speed will turn off after 15 minutes. Low-speed may run automatically at times, during which it cannot be deactivated from the panel, but high-speed may be operated.



Jets 2/Jets 3/Blower

(If equipped) Press the corresponding button once to turn the device on or off. The device will turn off after 15 minutes. Pump 2 may be two-speed on some systems. Some systems use this one button to control two devices. The first button press will activate one device. Press again to have both devices active. Press again to turn off the first device only. Press one more time to turn both devices off. The pump responsible for heating and filtration (pump 1 low-speed on non-circ system, or the circ pump on circ systems) will be referred to simply as the pump. In multi-button sequences, if the buttons are pressed too quickly in In multi-button sequences if the buttons are pressed too quickly in



Light

Press “Light” to operate the spa light. Turns off after 4 hours.

Mode

Depending on system configuration, mode changing may not be available and will be locked in Standard Mode.

Mode is changed by pressing “Temp,” then “Light”.

Standard Mode maintains a set temperature. ‘SE’ will be displayed momentarily when you switch into Standard Mode.

Economy Mode heats the spa to the set temperature only during filter cycles. ‘EC’ will display when the water temp is not current and will alternate with water temp when the pump is running.


Sleep Mode heats the spa to within 20°F/10°C of the set temperature only during filter cycles. ‘SL’ will display when the water temp is not current and will alternate with water temp when the pump is running.

Preset Filter Cycles

The first preset filter cycle begins 6 minutes after the spa is energized. The second preset filter cycle begins 12 hours later. Filter duration is programmable for 2, 4, 6, or 8 hours or for continuous filtration (indicated by ‘FC’). The default filter time is 2 hours for non circ systems and 4 hours for circ systems. To program, press “Temp,” then “Jets 1.” Press “Temp” to adjust. Press “Jets 1” to exit programming.

For non-circ systems, low-speed pump 1 and the ozone generator (if installed) run during filtration.
For circulation systems, the circ pump and the ozone generator (if installed) run

Diagnostic Messages

Message	Meaning	Action Required
LF	No message on display. Power has been cut off to the spa.	The control panel will be disabled until power returns. Spa settings will be preserved until the next power-up.
	Temperature unknown.	After the pump has been running for 2 minutes, the current water temperature will be displayed.
HH	“Overheat” – The spa has shut down.* One of the sensors has detected 118°F/47.8°C at the heater.	DO NOT ENTER THE WATER. Remove the spa cover and allow the water to cool. Once the heater has cooled, reset it by pushing any button. If the spa does not reset, shut off the power to the spa and call your dealer or service organization.
OH	“Overheat” – The spa has shut down.* One of the sensors has detected that the spa water is 110°F/43.5°C.	DO NOT ENTER THE WATER. Remove the spa cover and allow the water to cool. At 107°F/41.7°C, the spa should automatically reset. If spa does not reset, shut off the power to the spa and call your dealer or service organization.
SA	Spa is shut down.* The sensor that is plugged into the Sensor “A” jack is not working.	If the problem persists, contact your dealer or service organization. (May appear temporarily in an overheat condition.)
Sb	Spa is shut down.* The sensor that is plugged into the Sensor “B” jack is not working.	If the problem persists, contact your dealer or service organization. (May appear temporarily in an overheat condition.)
Sn	Sensors are out of balance. If alternating with spa temperature, it may just be a temporary condition. If flashing by itself, spa is shut down.*	If the problem persists, contact your dealer or service organization.
HL	A significant difference between temperature sensors has been detected. This could indicate a flow problem.	If the water level is normal, make sure all pumps have been primed. If the problem persists, contact your dealer or service organization.
LF	Persistent low flow problems. (Displays on the fifth occurrence of HL message within 24 hours.) The heater is shut down, but other spa functions continue to run normally.	Follow action required for HL message. The heating capability of the spa will not reset automatically; you may press any button to reset it.
dr	Possible inadequate water, poor flow, or air bubbles in detected in the heater. The spa is shut down for 15 minutes.	If the water level is normal, make sure all pumps have been primed. Press any button to reset. This message will reset within 15 minutes. If the problem persists, contact your dealer or service organization.

