

[Skip to content](#)

Manuals+

User Manuals Simplified.



DRAPER 41817 200 Series Digital Multimeter Testing Instruction Manual

[Home](#) » [DRAPER](#) » DRAPER 41817 200 Series Digital
Multimeter Testing Instruction Manual

Contents [hide](#)

[1 DRAPER 41817 200 Series Digital Multimeter Testing](#)

[2 INTRODUCTION](#)

[3 GUARANTEE](#)

[4 INTRODUCTION](#)

[5 Temperature](#)

[6 MAINTENANCE](#)

[7 Documents / Resources](#)

[7.1 References](#)

[8 Related Posts](#)

DRAPER



DRAPER 41817 200 Series Digital Multimeter Testing

INTRODUCTION

USER MANUAL FOR:

SERIES 200 MULTIMETER

Stock no. 41817 & 41818. Part no. DMM200 & DMM201.

REVISIONS

Date first published March 2017 Date second published June 2017 As our user manuals are continually updated, users should make sure that they use the very latest version. Downloads are available from:

<http://www.drapertools.com/manuals> DRAPER TOOLS LIMITED HURSLEY ROAD CHANDLER'S FORD
EASTLEIGH HAMPSHIRE SO53 1YF UK

WEBSITE

- drapertools.com

PRODUCT HELPLINE

- + 44 (0) 23 8049 4344

GENERAL FAX

- 44 (0) 23 8026 0784

UNDERSTANDING THIS MANUALS SAFETY CONTENT

WARNING

- Information that draws attention to the risk of injury or death.

CAUTION

- Information that draws attention to the risk of damage to the product or surroundings.

COPYRIGHT © NOTICE

Copyright © Draper Tools Limited. Permission is granted to reproduce this publication for personal & educational use only. Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited. In all cases this copyright notice must remain intact.

GUARANTEE

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship. Should the tool develop a fault, please return the complete tool to your nearest distributor or contact Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF. England. Telephone Sales Desk: (023) 8049 4333 or Product Helpline (023) 8049 4344. A proof of purchase must be provided with the tool. If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee period covering parts/labor is 12 months from the date of purchase except where tools are hired out when the guarantee period is 90 days from the date of purchase. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any person other than the authorised Draper warranty repair agent.

Note

1. If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.
2. This guarantee applies in lieu of any other guarantee expressed or implied and variations of its terms are not authorised.
3. Your Draper guarantee is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the guarantee period.
4. Please note that this guarantee is an additional benefit and does not affect your statutory rights.
5. Draper Tools Limited.

INTRODUCTION

GENERAL SPECIFICATIONS

- Max Voltage between input terminal and Earth Ground.
- CATIII 600V. Over-range Indication display “1” for the significant digit.
- Automatic display of negative polarity “-”.
- Low Battery Indication: ‘ ’ displayed.
- Max LCD display: 1999 (3 1/2 digits).
- Fuse protection: F2-0.2A/250V (Ø5x20mm) F1-10A/500V (Ø6x30mm). Power Supply.
- 9V battery, 6F22 or NEDA 1604.
- Operating Temp.: 0°C to 40°C (relative humidity <85%).
- Storage Temp.: -10°C to 50°C (relative humidity <85%).
- Guaranteed precision Temp.: 23±5°C (relative humidity <85%).
- Dimension 150x74x43mm (covering the protective cover).
- Weight: approx. 233g (including battery).

Range	Accuracy	Resolution
200mV		0.1mV
2V		1mV
20V	±(0.8% of rdg + 4 digits)	10mV
200V	±(0.8% of rdg + 5 digits)	100mV
600V	±(1.2% of rdg + 5 digits)	1V

Input Impedance

- Overload protection: 600V DC and AC 380V effective value

Range	Accuracy	Resolution
200V	±(1.2% of rdg + 20 digits)	100mV
600V	±(1.2% of rdg + 20 digits)	1V

Overload protection

- DC 800V or 600V AC rms. Input Impedance: 1MΩ.

Frequency Range

- 40 to 400Hz.

Display

- average value response (calibrated in rms of sine wave)

DC Current

Range	Accuracy	Resolution
2mA	±(1.0% of rdg + 10 digits)	1μA
20mA	±(1.0% of rdg + 10 digits)	10μA
200mA	±(1.5% of rdg + 20 digits)	100μA
10A	±(3.0% of rdg + 20 digits)	10mA

Overload protection: F1 10A/500V fuse, F2 200mA/250V fuse Maximum input current: 10A (no more then 10 seconds)

Resistance

Range	Accuracy	Resolution
200Ω	±(1.5% of rdg +25 digits)	0.1Ω
2kΩ	±(0.8% of rdg +20 digits)	1Ω
20kΩ	±(0.8% of rdg +20 digits)	10Ω
200kΩ	±(0.8% of rdg +20 digits)	100Ω
2MΩ	±(2.0% of rdg +25 digits)	1kΩ

- Over-load protection: 250V DC or 220V AC rms.

Temperature

Range	Accuracy	Resolution
-20°C~400°C	±(1.2% rdg + 5 digits)	1°C
400°C~1000°C	±(2.0% rdg + 15 digits)	1°C

Transistor hFE Test

Range	Test Range	Test Current/voltage
NPN & PNP	0-1000	I _b =10μA / V _{ce} =3V

Diode

Range	Resolution	Function
	1mV.	Read the moment through the diode's approximate voltage.

- Over-load protection: 250V DC or 220V AC rms. Instantaneous DC current approximate 1mA Reversed DC voltage: approximate 3.0V

Continuity Test

Range	Function
	The built-in buzzer will sound if resistance is lower than 70Ω

- Over-load protection: DC 250V or AC 220V effective value
- Open circuit voltage: approximate 3.0V

HANDLING & STORAGE

- Care must still be taken when handling, dropping this machine will have an effect on the accuracy.
- The environment will have a negative result on its operation if you are not careful.
- If the air is damp, components will rust. If the machine is unprotected from dust and debris; components will become clogged.

HEALTH & SAFETY INFORMATION

This instrument complies with IEC1010 (International Electrotechnical Commission promulgated safety standards). Design and production with an over-voltage category (CAT III) and using the pollution level 2 safety requirements.

Warning

To avoid electrical shock or personal injury. Please read the safety information and “warnings and precautions” before use. When measuring voltage above 30V, current above 10ma, AC power with an inductive load. Use caution not to touch exposed contacts due to the risk of electric shock, only use approved probes or clamps.

1. Before measuring, check whether the measurement function switch is in the correct position, check whether the test probe is connected correctly to avoid electric shock.
2. The meter is only to be used in conjunction with the supplied test leads to comply with safety standards.
3. If the test leads are broken or damaged, replace the test leads of the same type or the same electrical specifications.
4. Do not use an unapproved fuse to replace the fuse inside the meter.
5. Only replace with the same model or the same specifications of the fuse.
6. Before changing, remove the test leads to ensure that there is no signal input.
7. Do not use unapproved batteries to replace the battery inside the meter.
8. Replace only with the same model or the same electrical specifications of the battery.
9. DO NOT mix new and old batteries and do not use re-chargeable batteries.
10. Before changing, remove the test leads to ensure that there is no signal input.
11. During electrical measurements, the body must not be directly in contact with the earth, use insulating materials to keep your body insulated from the earth.
12. Do not store or use in high temperature, high humidity, flammable, explosive and strong magnetic field environments.
13. Measurements exceeding the limit values of the instrument may damage the instrument and endanger the safety of the operator.
14. Do not attempt to calibrate or service the instrument.
15. When the LCD shows “ ”, please replace the battery.
16. Do not insert the test leads to be inserted into the current terminals to measure the voltage.



IDENTIFICATION

- LCD display window.
- HOLD button.
- Measurement function range switch.
- Probe sockets.
- HFE Transistor test – input socket.
- Backlight on and off button.

UNPACKING & CHECKING

PACKAGING


Carefully remove the product from the packaging and examine it for any sign of damage caused during shipping. Lay the contents out and check them. If any part is damaged or missing, do not attempt to use the tool and contact the Draper Helpline immediately (see back page for details). Retain the packaging material at least during the guarantee period: in case the machine needs to be returned for repair.

Warning

Some of the packaging materials used may be harmful to children, keep them out of reach from children. Dispose of any packaging correctly and according to local regulations.

WHAT'S IN THE BOX?

- As well as the product; there are several parts not fitted or attached to it.



Test probe

- 1.
2. Temperature probe (41818 only)
3. Test probe caps

OPERATING INSTRUCTIONS

WARNING

1. DO NOT USE ON VOLTAGES ABOVE 600V.
2. DC VOLTAGE
3. Connect the black test lead to COM probe socket and the red to VΩmA probe socket.
4. Set the measurement function range switch to the desired

• Note

When the measurement is unknown always, set the highest position.

AC VOLTAGE

1. Connect the black test lead to COM probe socket and the red to VΩmA probe socket.
2. Set the measurement function range switch to the desired V~ position.

Note

- When the measurement is unknown always, set the highest position.

DC CURRENT

1. Connect the black test lead to COM probe socket and the red to the V Ω mA probe socket for a maximum 200mA current, for a maximum 10A current, move the red lead to the 10A probe socket.
2. Set the measurement function range switch to the desired range position.

RESISTANCE

1. Connect the black test lead to COM probe socket and the red to V Ω mA probe socket.
 2. Set the measurement function range switch to the desired Ω range position.
- Note**
3. When measuring resistance above 1M Ω , the reading may take a few seconds to become stable.
 4. When the input is not connected, i.e. at open circuit, the figure '1' will be displayed.
 5. When checking in-circuit resistance, be sure the circuit under test is switched off and that all capacitors have been discharged fully.
 6. When the measurement is unknown always set the measurement function range switch to the highest position.
 7. Connect the black temperature probe lead to COM probe socket and the red to V Ω mA probe socket.
 8. Set the measurement function range switch to the desired $^{\circ}$ C position.

TRANSISTOR TESTING

1. Set the measurement function range switch to the 'hFE' position.
2. Determine whether the transistor under testing is NPN or PNP. Insert the leads into the correct holes of hFE socket on the front panel.

DIODE TEST

1. Connect the black test lead to COM probe socket and the red to V Ω mA probe socket.
2. Set the measurement function range switch to F position.

Note

- The meter will show approximate forward voltage drop of the diode.

CONTINUITY TESTING

1. Connect the black test lead to COM probe socket and the red to V Ω mA probe socket.
2. Set the measurement function range switch to the position.

Note

- If the circuit is open, figure '1' will be displayed.

MAINTENANCE

BATTERY REPLACEMENT

- Before attempting to open the battery cover of the meter, be sure the test leads have been disconnected.

EXPLANATION OF SYMBOLS

- WEEE Do not dispose of Waste Electrical & Electronic Equipment in with domestic rubbish
- For indoor use. Do not expose to rain.
- Class II construction (Double insulated)
- Conforms to all relevant safety standards.
- Earth
- Fuse
- Back light
- Warning!
- Read instruction manuals before operating and servicing this equipment.
- Temperature

- Diode test
- hFE (Transistor testing)
- Low battery display
- Attention.
- High voltage / current! Danger.
- Voltage AC
- Voltage DC
- Current DC
- Resistance in Ohms
- Continuity test buzzer
- Data hold / Screen lock
- Auto power off

DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area.


In all circumstances:

- Do not dispose of power tools with domestic waste.
- Do not incinerate.
- Do not abandon in the environment.
- Do not dispose of WEEE* as unsorted municipal waste.
- Waste Electrical & Electronic Equipment.

CONTACT US

Draper Tools Limited, Hursley Road, Chandler's Ford, Eastleigh, Hampshire. SO53 1YF. U.K. Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 Internet: www.drapertools.com E-mail: sales@drapertools.com
 General Enquiries: (023) 8026 6355 Service/Warranty Repair Agent: For aftersales servicing or warranty repairs, please contact the Draper Tools Helpline for details of an agent in your local area.

Documents / Resources



[DRAPER 41817 200 Series Digital Multimeter Testing](#) [pdf] Instruction Manual
 41817, 41818, 200 Series Digital Multimeter Testing

References

- [Draper Tools Official Website | Hand Tools, Power Tools and Accessories](#)
- [Manuals | Draper Tools](#)

[Manuals+](#),

- [home](#)
- [privacy](#)