



DREAME D10 Plus Auto Empty Robot Vacuum and Mop User Manual

[Home](#) » [dreame](#) » DREAME D10 Plus Auto Empty Robot Vacuum and Mop User Manual 

DREAME D10 Plus Auto Empty Robot Vacuum and Mop User Manual



Contents

1 Safety Information
2 Product Overview
3 Product Overview
4 Clearing Home Environment EN
5 Preparation Before Use
6 Connect with Dreamhole or Mi Home/Xiaomi Home App
7 How to Use
8 Routine Maintenance
9 Routine Maintenance
10 Robot does not turn on
11 Robot cannot recharge
12 Robot cannot return to the base
13 Robot is malfunctioning
14 Robot is making a strange noise
15 Robot no longer cleans efficiently or leaves dust behind
16 Robot cannot connect to Wi-Fi
17 Robot does not perform scheduled cleaning
18 Does leaving the robot on the base consume power if it is already fully charged?
19 No water comes out of the mopping module, or only a little bit comes out
20 Robot doesn't resume cleaning after charging
21 Robot returns to the base without performing auto-empty tasks
22 The auto-empty dur
23 The upper cover of base fails to be closed
23.1 Specifications
23.2 Documents / Resources
23.2.1 References
23.3 Related Posts

Safety Information

To avoid electric shock, fire or injury caused by improper use of the appliance, please read the user manual carefully before using the appliance and keep it for future reference.

Usage Restrictions

- This product should not be used by children younger than 8 years old nor persons with physical, sensory, intellectual deficiencies, or limited experience or knowledge without the supervision of a parent or guardian to ensure safe operation and to avoid any risks. Cleaning and maintenance shall not be performed by children without supervision.
- Children shall not play with this product. Ensure children and pets are kept at a safe distance from the robot while it is operating.
- This product is for floor cleaning in a home environment only. Do not use it outdoors, on non-floor surfaces, or in a commercial or industrial setting.
- Do not use the robot in an area suspended above ground level without a protective barrier.
- Do not place the robot upside down. Do not use the LDS cover, robot cover, or bumper as a handle for the robot.
- Do not use the robot at an ambient temperature above 40° C or below 0° C or on a floor with liquids or sticky substances.
- Pick up any cables from the floor before using the robot to prevent it from dragging them while cleaning.

- Remove fragile or small items from the floor to prevent the robot from bumping into and damaging them.
- Keep hair, fingers, and other body parts away from the suction opening of the robot.
- Keep the cleaning tool out of reach of children.
- Do not place children, pets, or any item on top of the robot regardless of whether it is stationary or moving.
- Do not use the robot to clean any burning objects.
- Do not vacuum hard or sharp objects.
- Make sure the robot is turned off and the auto-empty base is unplugged before cleaning or performing maintenance.
- Do not use a wet cloth to wipe or any liquid to rinse the robot and base.
Washable parts must be dried completely before installing and using them.
- Please use this product in accordance with the instructions in the User Manual. Users are responsible for any loss or damage that arise from improper use of this product.

Batteries and Charging

- Do not use any third-party battery or auto-empty base. Use only with RCS7 supply unit.
Do not attempt to disassemble, repair, or modify the battery or autoempty base on your own.
- Do not place the auto-empty base near a heat source.
- Do not use a wet cloth or wet hands to wipe or clean the base's charging contacts.
- Do not improperly dispose of old batteries. Unneeded batteries should be discarded at an appropriate recycling facility.
- If the power cord becomes damaged or broken, stop using it immediately and contact after-sales service.
- Make sure the robot is turned off when being transported and kept in its original packaging if possible.
- If the robot will not be used for an extended period, fully charge it, then turn it off and store in a cool, dry place.
Recharge the robot at least once every 3 months to avoid over-discharging the battery.
- This product contains batteries that can only be replaced by qualified technicians or after-sales service.
- The lithium-ion battery pack contains substances that are hazardous to the environment. Before disposing of the robot vacuum, please first remove the battery pack, then discard, or recycle it in accordance with local laws and regulations of the country or region it is used in.
- When removing the batteries from the product, it is better to use up the batteries and make sure your product is disconnected from power. Uninstall the screw on the bottom, then remove the cover.
- Unplug the battery connector, then remove the batteries. Do not damage the battery case to avoid any risk of injuries.
- Return the batteries to a professional recycling organization.

Laser Safety Information

The laser sensor in this product meets the IEC 60825-1:2014/EN 60825-1:2014/

A11: 2021 Standard for Class 1 laser products. Please avoid direct eye contact with it during use.

CLASS 1 LASER PRODUCT
CONSUMER LASER PRODUCT
EN 50689 :2021

Hereby, Dreame Trading Tianjin Co., Ltd. declares that the radio equipment type RLS3D is in compliance with

Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://global.dreametech.com> For detailed e-manual, please go to <https://global.dreametech.com/pages/user-manuals-and-faqs>

Product Overview


Accessories

Pre-Installed Accessories

- Main Brush




- Dust Bin



- Cleaning Tool




- Dust Collection Bag ×2 (1 pre-installed)




Other Accessories

- Water Tank




- Mop Pad



- Side Brush




- Power Cord



Product Overview

Robot



- **Power/Clean Button**

- Press and hold for 3 seconds
- Press to begin cleaning after the robot is powered on


- **Dock/Spot Clean Button**

- Press to send the robot back to the base
- Press and hold for 3 seconds to start Spot Clean Mode

- **Status Indicator**

- **White:** Cleaning or cleanup is completed
- **Blinking Orange:** Error
- **Breathing White:** Robot is charging when the battery power is not low


Robot




- **Reset Button**

- Press and hold for 3 seconds to restore the robot to factory settings


Robot Sensors




Auto-Empty Base




Open the upper cover




Back





Bottom



Dust Bin




Mopping Module




Clearing Home Environment EN


- To improve the working efficiency of your robot, put away any loose cords , rags, slippers, toys, etc.




- Before cleaning, place a physical barrier at the edge of the stairs and sofa to ensure safe and smooth operation of the robot.



- Open the door of the room to be cleaned, and put the furniture in its proper place to make more space.




- To prevent the robot from not recognizing the area that needs to be cleaned, do not stand in the front of the robot, threshold, hallway, or narrow places.




Preparation Before Use

1. Remove the protective strips




2. Install the side brush



3. Connect to a power outlet and start charging

Place the base on level ground against the wall and connect it to a power outlet. Place the robot onto the base to charge. The robot will turn on automatically and begin charging. It is recommended to fully charge your robot before first-time use.



Note:


- Keep the immediate area 1.5 m in front of the base and 0.5 m to its both sides clear of objects.
- Make sure that no objects might block the signaling area.

Connect with Dreamhole or Mi Home/Xiaomi Home App


This product works with the Dreamhole or Mi Home/Xiaomi Home app, which can be used to control your device.

1. Download the Dreamehome or Mi Home/Xiaomi Home App

Scan the QR code on the robot, or search “Dreamehome”, “Mi Home” or “Xiaomi Home” in the app store to download and install the app based on your needs.



2. **Add Device** Mi Home/Xiaomi Home APP: Open the Mi Home/Xiaomi Home app, tap ” ” in the upper right, and scan the QR code above again to add “Dreame Bot D10 Plus”. Please follow the prompts to finish the Wi-Fi connection. Dreamehome APP: Open the Dreamehome app, tap ” ” in the upper right to go to the “Add Device” page, and then select “Dreame Bot D10 Plus”. Please follow the prompts to finish the Wi-Fi connection.



3. **Reset Wi-Fi**

Simultaneously press and hold the buttons and until you hear a voice prompt saying, “Waiting for the network configuration.” Once the Wi-Fi indicator is blinking slowly, the Wi-Fi has been successfully reset.

Note: If your robot cannot connect to the app successfully, reset the Wi-Fi and add the device again.

Note:

- Only 2.4GHz Wi-Fi is supported.

The version of the app might have been updated, please follow the instructions based on the latest app version.

How to Use


1. **Turn On/Of**

Press and hold the button for 3 seconds to turn on the robot. Once the power indicator turns solid white, the robot is on standby. To turn off the robot, press and hold the button for 3 seconds when the robot is not moving.

2. **Start Cleaning**

Press the button briefly to turn on the robot. Upon activation, the robot will accurately map out a route, methodically clean along the edges and walls, then finish by cleaning each room in an S-shaped pattern to

ensure a thorough job.



3. Cleaning Mode

Dreame Bot D10 Plus has four cleaning modes: Quiet, Standard, Strong, and Turbo. The default mode is Standard. You can specify the cleaning mode in the Dreamehome or Mi Home/Xiaomi Home app.

4. Pause/Sleep Mode

Pause: Press any button briefly to pause the robot during cleaning.

Sleep Mode: If the robot pauses for more than 10 minutes, it automatically enters the sleep mode, and the power indicator and charging indicator will go off. To wake up the robot, press any button.

Note:

- The robot will turn off automatically if left in Sleep Mode for more than 12 hours.
- If the robot is paused and placed onto the base, the current cleaning task will end.

5. Spot Clean Mode

When the robot is paused or in Standby Mode, press and hold the button for 3 seconds to start Spot Clean Mode. In this mode, it will clean a square-shaped area of 1.5×1.5 meters directly around the robot. When the spot cleaning is done, the robot will automatically return to its original location and power off.

Note: Activating Spot Clean Mode will end the current cleaning task of the robot.


6. Additional App Functions

Follow the instructions on the app interface to use more functions. The version of the app might have been updated; please follow the instructions based on the current app version.


7. Use the Mopping Function

It is recommended that all floors are vacuumed at least three times before the first mopping session to achieve a better cleaning effect.

1. Dampen the mop pad and wring out excess water. Insert the mop pad into the slot of the water tank as shown in the figure, and paste the pad firmly.




2. Open the water tank lid, fill the tank with water, then securely close the lid.




Note: Do not use detergent or disinfectant.

3. Align the mopping module as indicated by the arrow, then slide it into the back of the robot until it clicks into place. Press the button or use the Dreamehome or Mi Home/Xiaomi Home app to start cleaning.



Note:

- It is not recommended to use the mopping function on carpets.
 - Use the app to adjust the water flow as required.
4. Press the two side clips inwards and slide the water tank backwards to separate it from the robot.




Note: When the robot is charging or not in use, remove the mopping module, pour out all the remaining water in the tank, and clean the mop pad to prevent mildew or odors.


Routine Maintenance

Clean the Dust Bin Clean after each use


1. Open the robot cover, then press the dust bin clip to remove the dust bin.



2. Open the bin cover and empty the bin as shown in the diagram.




3. Clean the dust intake.




Clean the Filter

1. Remove the filter and tap its basket gently.



Note:


- Do not attempt to clean the filter with brushes or fingers.
 - Rinse the dust bin with clean water only. Do not use any detergent.
 - Use the dust bin and filter when they are completely dry.
 - The filter is recommended to be cleaned every two weeks and replaced every three months.
2. Do not wash the filter. Only the dust bin is washable. Thoroughly dry it before re-installing.




Routine Maintenance

Clean the Mopping Module

1. Press the two release clips on the side of the water tank, remove the mopping module, and pull the mop pad off the mopping module.




2. Clean the mop pad with water only and leave to air dry before re-installing.




3. Pour out the water in the tank. Clean with only water and leave out to air dry before re-installing.

Note: Do not expose the tank to the sun directly.




4. If slow water flow occurs, or the volume is not well-distributed, clean the airhole in the cover of the water tank.




Clean the Main Brush

Press the brush guard clips inwards to remove the brush guard and lift the brush out of the robot.




Pull out the brush covers as shown in the diagram. Use the included cleaning tool to remove any hairs tangled in the brush.

Note: Do not pull out the hair tangled in the main brush excessively. Otherwise, the brush may be damaged.



Clean the Side Brush

Pull out the side brushes and use the cleaning tool to remove any hair tangled on the brush.




Clean the Main Wheel/Universal Wheel


Note: Use a tool such as a small screwdriver to separate the axle and tire of the universal wheel.

Note: Wet cloths can damage sensitive elements within the robot and base. Please use dry rags for cleaning.


- **Clean the Laser Distance Sensor**




- **Clean the Cliff Sensor**




- **Clean the Return-to-Base Sensor**



- **Clean the Charging Contact**




- **Clean the Charging Contact and Dust Intake**



Replace the Dust Collection Bag


It is recommended to replace the bag every 4-6 weeks.

1. Discard the dust collection bag




Note: When taking out the dust collection bag, close the dust bag handle to avoid dust leaking out.


2. Wipe the filter with a dry cloth



3. Install a new dust collection bag



4. Close the upper cover of auto-empty base




Note: Do not close the base forcibly, if the upper cover of base cannot be closed and the dust collection bag is not installed.


Clean the Air Duct

If the air duct is blocked, please clean it according to the following steps.


1. Unscrew mounting screws on the air duct cover and remove the cover plate.



2. Check whether the air duct is blocked by foreign objects. If any, clean them.



3. Reinstall the air duct cover as shown in the diagram.



Robot Restarting

If the robot stops responding or cannot be turned off, press and hold down the button for 10 seconds to forcefully turn it off. Then press and hold the button for 3 seconds to turn the robot on.

Battery

The robot contains a high-performance lithium-ion battery pack. Please ensure that it remains well-charged for daily use to maintain optimal battery performance. If the robot is not used for an extended period of time, turn it off and put it away. To prevent damage from over-discharging, the robot should be recharged at least once every three months.

Robot does not turn on

The battery level is low. Recharge the robot on the base, then try it again. The ambient temperature is too low (below 0° C) or too high (above 40° C). The operating temperature of the robot is 0° C to 40° C.

Robot cannot recharge

The base is not receiving power. Please confirm that both ends of the power cord are plugged in correctly. Poor contact. Clean charging contacts of the base and robot.

Robot cannot return to the base

There are too many obstructions around the base. Place the base in a more open area. Please clean the signaling area of the base. Moving the robot may cause it to re-position itself or re-map its surroundings. If the robot is too far from the base, it might not be able to automatically return on its own, in which case you need to

manually place the robot onto the base.

Robot is malfunctioning

Turn off the robot and then reactivate it

Robot is making a strange noise

A foreign object may be caught in the main brush, side brush, or one of the main wheels. Stop the robot and remove any debris

Robot no longer cleans efficiently or leaves dust behind

The dust bin is full. Please clean the dust bin and dust intake. The filter is blocked. Please clean it. A foreign object is caught in the main brush. Please clean it.

Robot cannot connect to Wi-Fi

There is something wrong with the Wi-Fi connection. Reset the Wi-Fi and download the latest version of the Dreamehome or Mi Home/Xiaomi Home, then try reconnecting. Location permission is not open. Please ensure the location permission on the Dreamehome or Mi Home/Xiaomi Home is enabled. Wi-Fi signal is weak. Make sure the robot is in an area with good Wi-Fi coverage. 5GHz Wi-Fi is not supported. Please ensure your robot connects to 2.4GHz Wi-Fi. The username or password of Wi-Fi is incorrect. Please enter the correct username and password.

Robot does not perform scheduled cleaning

The robot has low battery. Scheduled cleaning will not start unless the robot has been recharged in time.

Does leaving the robot on the base consume power if it is already fully charged?

Leaving the robot on the base after it's fully charged consumes very little electricity and helps maintain optimal battery performance.

No water comes out of the mopping module, or only a little bit comes out

Check whether there is water inside the water tank. Clean the mop if it becomes dirty. Make sure the mop pad is installed correctly according to the user manual. Clean the blowhole on the top of the water tank.

Robot doesn't resume cleaning after charging

Make sure the robot is not set to Do Not Disturb mode (DND), which will prevent it from resuming cleaning. The robot does not resume cleaning when it is manually recharged or placed onto the base.

Robot returns to the base without performing auto-empty tasks

DND mode prevents the robot from performing auto-empty tasks

The auto-empty duration

When the robot has been performing auto-empty tasks for a period of time, or when the air duct does not function smoothly, the auto-empty duration will be extended to prevent blockage.

The upper cover of base fails to be closed

Check whether a dust collection bag is installed. If not, install one.

Specifications

Robot

Model: RLS3D

Battery: 5200 mAh (Nominal Capacity)

Charging Time: Approx. 6 hours

Rated Voltage: 14.4 V

Rated Power: 46 W

Operation Frequency: 2400-2483.5 MHz

Maximum Output Power: 20 dBm

Auto-Empty Base

Model: RCS7

Rated Input: 220-240 V ~ 50-60 Hz

Rated Output: 19.8 V 1 A

Rated Power: 600 W

Under normal use of condition, this equipment should be kept a separation distance of at least 20cm between the antenna and the body of the user.


WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

DreameBot

Documents / Resources

	DREAME D10 Plus Auto Empty Robot Vacuum and Mop [pdf] User Manual D10 Plus Auto Empty Robot Vacuum and Mop, D10, Plus Auto Empty Robot Vacuum and Mop, Empty Robot Vacuum and Mop, Robot Vacuum and Mop, Vacuum and Mop
---	--

References

- [Que Faire de mes Déchets ? Découvrez les solutions pour tous vos déchets et nos conseils pour en produire moins.](#)
- [Dreame Global | Smart Robot Vacuum Cleaners](#)
- [Dreame User Manuals and FAQs | Dreame Official Site – Dreame Global](#)
- [ear-system.de/ear-verzeichnis/sammel-und-ruecknahmestellen](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.