


## Druck UPS-III Loop Calibrator Instruction Manual

[Home](#) » [Druck](#) » Druck UPS-III Loop Calibrator Instruction Manual 

Druck UPS-III Loop Calibrator



## **Contents**

- 1 Introduction**
- 2 Safety**
- 3 Repair**
- 4 Symbols**
- 5 Power Supply**
- 6 Batteries**
- 7 Guide to Supply and Input/Output**
- 8 Operation**
  - 8.1 Keys**
  - 8.2 Operating Modes**
  - 8.3 Measure Mode**
  - 8.4 Source Mode**
  - 8.5 Advanced Options in a Source Mode**
  - 8.6 Example Operation**
  - 8.7 Hart® Application**
- 9 Maintenance**
  - 9.1 Cleaning**
  - 9.2 Battery Replacement**
- 10 Calibration**
  - 10.1 Calibration Equipment**
    - 10.1.1 UPS-III Measure Mode**
    - 10.1.2 UPS-III Source Mode**
  - 10.2 Calibration Check**
  - 10.3 Calibration Adjustment**
- 11 Specification**
- 12 Return Goods/Material Procedure**
- 13 Documents / Resources**
- 14 Related Posts**

## **Introduction**

The Druck UPS-III Intrinsically Safe Loop Calibrator can supply power (source mode) and produce readings (measure mode) to perform field calibrations on 2-wire devices. The set-up menu enables the user to “source” or “measure” in either voltage or current and to perform continuity tests. These instructions detail the requirements and operation of the UPS-III Intrinsically Safe Loop Calibrator in a hazardous area. Read the whole publication before starting.

## **Safety**

The UPS-III has been designed to be safe when operated using the procedures detailed in this manual. Do not use this equipment for any other purpose than that stated, the protection provided by the equipment may be impaired.




Before installing and using the UPS-III, read and understand all the related data. This includes: all local safety procedures and installation standards, and this document.

Before starting an operation or procedure, use only approved engineers who have the necessary skills (if necessary, with qualifications from an approved training establishment). Follow good engineering practice at all times.

## **Repair**

Do not do repairs to this equipment. Return the equipment to the manufacturer or an approved service agent.

## Symbols

Symbol	Description
	This equipment meets the requirements of all relevant European safety directives. The equipment carries the CE mark.
	This symbol, on the equipment, indicates a warning and that the user should refer to the user manual. Ce symbole, sur l'instrument, indique que l'utilisateur doit consulter le manuel d'utilisation. Ce symbole, dans le manuel, indique une situation dangereuse.
	Do not dispose of this product as household waste. Use an approved organization that collects and/or recycles waste electrical and electronic equipment. For more information, contact one of these: <ul style="list-style-type: none"><li>– Our customer service department: <a href="http://Druck.com/essential">Druck.com/essential</a></li><li>– Your local government office.</li></ul>

## Power Supply

The power supply for this loop calibrator can be the internal nonrechargeable batteries or an external universal power supply unit, Druck accessory **IOPSU-1**.

## Batteries



**CAUTION Do not mix cell types. Do not mix old and new cells.**

**Remove cells from the unit when placed in storage for an extended period of time. If a cell has leaked return the unit to an approved Druck Service Centre.**

Use only 4 x AA LR6 manganese alkaline primary cells

## Guide to Supply and Input/Output

**Table 1: Key to Entity Parameter Table Conditions**

Condition	Description
① & ②	Current measurement between mA and COM with external 24V. This mode of operation inserts the apparatus in the current loop by breaking into the circuit and connecting mA (positive) and COM (negative) into the circuit.
③	Current measurement between mA (24V) and mA with internal 24V. Terminal mA (24V) provides the source of power to supply remote sensor. Special condition for safe use – remote sensor MUST be isolated from all other sources of power.
④	Voltage measurement between V and COM.
⑤	Continuity measurement between V and COM. Special condition for safe use – remote sensor MUST be isolated from all other sources of power.
⑥	Current generation between mA and COM with external 24V. This mode of operation inserts the apparatus in the current loop by breaking into the circuit and connecting mA (positive) and COM (negative) into the circuit.
⑦	Current generation between mA (24V) and mA with internal 24V. Terminal mA (24V) provides the source of power to supply the remote sensor. Special condition for safe use – remote sensor MUST be isolated from all other sources of power.




## Operation

### Keys






The  key switches the loop calibrator on and off. Press and hold for 2 seconds.





The  key changes the measure or source operating mode. Pressing the   keys makes menu selections, sets numerical values and controls step and ramp functions (up/down).





The   select advanced functions shown on the bottom of the display. When no key is pressed for 10 minutes, the loop calibrator times out and switches off. To disable this automatic time out, select Aut power down in the set-up menu.




#### Operating Modes

Pressing  switches the instrument on and the display shows the start-up sequence. Pressing , at this time, the display shows the information screen:



Pressing , at this time, the display shows the set-up screen:



The calibrator can be used in two modes measure or source.

#### Measure Mode

The display shows the measured value; depending on the settings made in set-up and advanced settings:


When measuring current pressing **F1** enables linear or flow, pressing **F2** enables mA or % (value of 4 to 20 mA or 0 to 20 mA).

When measuring voltage pressing **F2** changes the resolution between 0.00 V and 0.000 V.

To measure continuity the displays shows an open or closed switch symbol with an audible signal on switch closure. Connect the calibrator to the device to be tested:


#### Measure mA ①

Press the **mode** key and select [Measure mA]. An external power supply supplies a maximum of 60 V for the loop. The calibrator measures the current of the loop.



## Measure mA ②


Closed loop current measurement from transmitter test terminal.



## Measure mA with 24V ③


Press mode key and select [Measure mA and 24V]. The calibrator supplies 24 V (maximum) for the loop, maximum 24 mA.






### Measure Volts ④

Press mode key and select [Measure Volts], measure range 60 V, maximum impedance 1 Mohm.



### Continuity Test ⑤

Press **mode** key and select [Continuity Test]. Pressing switches the audible signal on/off.




### Source Mode

The display shows the source value in mA or % value of 4 to 20 mA or 0 to 20 mA, linear or flow depending on the settings made in set-up and advanced settings.


### Source mA ⑥

Press mode key and select [Source mA]. The calibrator supplies maximum output of: 24 mA;  $V_{max} = 60\text{ V}$ ; receiver input  $R_{max} = 1\text{ k}\Omega$ .



### Source mA with 24V ⑦

Press **mode** key and select [Source mA and 24V]. The calibrator supplies loop power of: 24 V and 24 mA.



### Advanced Options in a Source Mode

Press **MODE** the key and select mA Source or mA Source & 24V.

Use **↑** **↓** and **F2** (Enter) to select the function.

Press **F1** the key (Advanced) and the display shows:

- 'Linear' simulates linear transmitters.
- 'Flow' simulates flow transmitters.
- 'Valve' simulates valve control signals.


Use **↑** **↓** and **F2** (Enter) to select the Advanced option:

**Table 2: Advanced Options**

Option	Description
Step	25% steps for linear and flow – fixed values for valve.
Auto-step	The same as step with a timed step interval.
Span Check	Step between 4 (or 0) mA and 20 mA.
Ramp	Automatic ramp between 4 (or 0) mA and 20 mA.


**Note:** Ramp function not available for valve selection.



Use **F1** to quit. The display returns to the selected source mode with the advanced setting available.





#### Example Operation

Press the **F2** key to switch the advanced setting on and off:

e.g.  on or off

Press  or  to:


- step the output up or down.
- step the span check maximum or minimum.
- start the “ramp”.

Press  then  to start:

- continuous auto-step.
- or
- continuous ramp cycle.

### Hart® Application

This application allows mA measure and source modes to be used through the Hart® communicator.



1. Hart® communicator.
2. UPS-III menu selectable 220  $\Omega$  loop resistor

### Maintenance

- Return the loop calibrator to an authorized repair center for any repairs, it cannot be repaired on-site.
- To keep the loop calibrator accurate a calibration check should be carried out once per year.

### Cleaning


- Clean the loop calibrator case with a moist, lint-free cloth and weak detergent.

## Battery Replacement



This symbol indicates that the batteries are low, replace observing polarity shown below.

Unscrew and remove the securing screw from the battery panel. Replace the batteries, check the polarity of the batteries. Refit and secure the battery panel.



Remove batteries from the loop calibrator immediately when discharged and before storage. Dispose of batteries in accordance with local regulations and battery manufacturers' instructions. When storing and transporting batteries make sure they cannot be short circuited.

## Calibration

The instrument is supplied by the manufacturer, complete with calibration certificate(s).

A calibration period of 12 months is recommended. The actual calibration interval depends on instrument usage and the total measurement uncertainty acceptable for the specified application.

The UPS-III is a very precise measuring instrument and the test equipment and conditions of test must be suitable for the type of work. The calibration check and calibration adjustment should be carried out in a controlled environment by a calibration technician\*

The manufacturer offers a comprehensive and, if required, UKAS accredited calibration service.

#### Calibration Equipment

The following tables give the accuracy requirements for the calibration equipment and the UPS-III. Calibration requires a stable temperature of  $21^{\circ} \pm 1^{\circ}\text{C}$  ( $70^{\circ} \pm 2^{\circ}\text{F}$ ).

#### UPS-III Measure Mode

**Table 3: mA Measure**

Applied mA	Permitted UPS-III Error (mA)	Calibrator Error (mA)
0	0.002	0
4	0.002	0.00014
12	0.002	0.00030
20	0.002	0.00046

**Table 4: V Measure**

Applied V	Permitted UPS-III Error (mV)	Calibrator Error (mV)
0	0.004	0.00040
20	0.004	0.00014
40	0.005	0.00064
50	0.005	0.00070

A calibration technician must have the necessary technical knowledge, documentation, special test equipment and tools to carry out the calibration work on this equipment.

#### UPS-III Source Mode

**Table 5: mA Source**

Applied mA	Permitted UPS-III Error (mA)	Calibrator Error (mA)
0	0.002	0
4	0.002	0.00012
12	0.002	0.00011
20	0.002	0.00015

### Calibration Check


1. Connect the UPS-III to the electrical calibrator. Switch on the electrical calibrator and allow it to thermally stabilize.
2. Switch on the UPS-III and allow the instrument to thermally stabilize.
3. Set the UPS-III to mA measure, adjust the electrical calibrator to apply the first value in the Table 3. Record the reading of the UPS-III.
4. Repeat step 3 for all the values in the Table 3.
5. Compare the recorded values and the applied values if the difference is greater than the permitted error, the instrument requires a calibration adjustment.
6. Repeat this procedure for V measure (Table 4) and mA source (Table 5).

### Calibration Adjustment





**INFORMATION** The UPS-III requires a two-point calibration on the V and mA range.


1. Connect the UPS-III to the electrical calibrator. Switch on the electrical calibrator and allow it to thermally stabilize.
2. Switch on the UPS-III and press **F2**, within two seconds to select Calibration. Enter the access code [9410 factory setting] and allow the instrument to thermally stabilize.
3. Select the parameter required for calibration. Use the display menu to select the calibration values. After a successful calibration enter the new calibration date











## Specification

**Table 6: Physical Specification**

Item	Specification
Dimensions	77 x 129 x 24 mm (3" x 5" x 1")
Weight (nominal)	275 g (9.7 oz.)
Terminals	4 mm sockets
Case	High impact ABS
Environmental	IP40
Relative Humidity	0 to 90%

**Table 7: General Specification**

Item	Specification
Accuracy for one year	17°C to 27°C (63°F to 81°F)
Outside these limits	0.003%/°C (0.0015%/°F)
Reference	22°C ± 1°C; Relative humidity 45% ± 15%
Battery Life	≥ 75 hours in measure mode ≥ 18 hours at 12 mA in source mode
Hart® Communications	Menu selectable 220 Ω loop resistor
Operating Temperature	-10°C to 50°C (14°F to 122°F)
Storage Temperature	-20°C to 70°C (-4°F to 158°F)

**Table 8: Accuracy Specification**

Mode	Range	Resolution	Accuracya
Source mA	0 to 24 mA <sub>b</sub>	0.001	0.01% rdg + 2 lsd
Source mA + 24V	0 to 24 mA <sub>c</sub>	0.001	0.01% rdg + 2 lsd
Measure mA	0 to 24 mA <sub>b</sub>	0.001	0.01% rdg + 2 lsd
Measure mA + 24V	0 to 24 mA <sub>d</sub>	0.001	0.01% rdg + 2 lsd
Measure V	0 to 60 V <sub>e</sub>	0.001	0.02% rdg + 4 lsd
Continuity	<100 Ω <sub>f</sub>	—	—

a. rdg = reading, lsd = least significant digits.

b. V maximum = 75V.

c. R maximum 1 kΩ at 20 mA.

d. R measure = 15 Ω.

e. R measure > 1 MΩ.

f. Audio and visual indication, 1 mA test current

## Return Goods/Material Procedure

If the unit requires calibration or is unserviceable, return it to the nearest Druck Service Centre listed at: [Druck.com/essential](http://Druck.com/essential).

Contact the Service Department to obtain a Return Goods/Material Authorization (RGA or RMA). Provide the following information for a RGA or RMA:

- Product (i.e. UPS-III)
- Serial number.
- Details of defect/work to be undertaken.
- Calibration traceability requirements.
- Operating conditions.

Copyright 2003 Baker Hughes Company. This material contains one or more registered trademarks of Baker Hughes Company and its subsidiaries in one or more countries. All third-party product and company names are trademarks of their respective holders.



## Documents / Resources

<div data-bbox="244 98 280 114" data-label="Image"></div> <div data-bbox="135 134 215 181" data-label="Text"><p>UPS-III Loop Calibrator Instruction Manual</p></div> <div data-bbox="193 219 280 365" data-label="Image"></div> <div data-bbox="135 367 167 376" data-label="Text"><p>Druck.com</p></div>	<div data-bbox="319 244 1037 315" data-label="Text"><p><a href="#">Druck UPS-III Loop Calibrator</a> [pdf] Instruction Manual UPS-III, Loop Calibrator, UPS-III Loop Calibrator, Calibrator</p></div>
---	---