

# **Dunlop JHMS1 Authentic Hendrix Shrine Series Fuzz Face Distortion User Manual**

Home » DUNLOP » Dunlop JHMS1 Authentic Hendrix Shrine Series Fuzz Face Distortion User Manual







JHMS1 **Authentic Hendrix™** '68 Shrine Series Fuzz Face® Distortion

#### **Contents**

- 1 JHMS1 Authentic Hendrix Shrine Series Fuzz Face **Distortion**
- **2 External Controls**
- 3 Basic Operation
- **4 Specifications**
- 5 Documents / Resources
- **6 Related Posts**

## JHMS1 Authentic Hendrix Shrine Series Fuzz Face Distortion

This special edition of the Fuzz Face Distortion pays tribute to the legendary Jimi Hendrix with a custom finish that remixes prolific and celebrated rock artist John Van Hamserveld's famous 1968 Shrine Auditorium concert poster art. Packed into an MXR mini housing, this pedal captures both the aggressive silicon-based crunch that Jimi Hendrix used in the latter part of his career and the the warm, smooth saturation of germanium-based fuzz that he used in the early years.

### **External Controls**



- 1. BUFF switch toggles between high/low input impedance (blue LED indicates high-impedance)
- 2. VOLUME knob sets overall volume of effect
- 3. SI/GE switch toggles between silicon (white LED)/germanium (blue LED) fuzz styles
- 4. FUZZ knob controls intensity of fuzz effect
- 5. FOOTSWITCH toggles effect on/bypass (blue LED indicates on)

## **Basic Operation**

#### **Power**

The Authentic Hendrix ™ '68 Shrine Series Fuzz Face® Distortion is powered by the Dunlop ECB003 9-volt adapter or an MXR® Brick™ Series power supply (each sold separately). This pedal cannot be powered by a battery.

#### **Directions**

- 1. Run a cable from your guitar to JHMS1's INPUT jack and another cable from JHMS1's OUTPUT jack to your amplifier.
- 2. Start with VOLUME and FUZZ controls at 12 o'clock.
- 3. For aggressive silicon-based crunch, set the SI/GE switch to its OUT position, indicated by the white LED. For smooth germanium-based saturation, set the SI/GE switch to its IN position, indicated by blue LED.
- 4. Turn effect on by depressing the footswitch.
- 5. Rotate VOLUME knob clockwise to increase overall volume or counterclockwise to decrease it.
- 6. Rotate FUZZ knob clockwise to increase the amount of fuzz or counterclockwise to decrease it.
- 7. To prevent oscillation when using a wah pedal and preserve high end tone, this pedal's buffer is set to ON by default, indicated by the associated LED. To disable the buffer, set the BUFF switch to its IN position.

## **Specifications**

## SILICON / GERMANIUM FUZZ (BUFF ON)

Input Impedance	800 kΩ		
Output Impedance			
Max Volume	16 kΩ		
Mid Volume	160 kΩ		
Max Output Level	-4 dBV		
Max Gain	55 dB		
Bypass	True Hardwire		

SILICON FUZZ (BUFF OFF)		GERMANIUM FUZZ (BUFF OFF)		
Input Impedance	10 kQ	Input Impedance	10 kQ	
Output Impedance		Output Impedance		
Max Volume	<16 kQ	Max Volume	2 kQ	
Mid Volume	66 kQ	Mid Volume	115 kQ	
Max Gain	55 dB	Max Gain	45 dB	
Bypass	True Hardwire	Bypass	True Hardwire	
POWER REQUIREMENTS				
Current Draw		6.8 mA		
Power Requirements 9 volts D		9 volts DC	volts DC	



JHMS1
AUTHENTIC HENDRIX
1968 SHRINE SERIES FUZZ FACE
DISTORTION

**Documents / Resources** 



<u>Dunlop JHMS1 Authentic Hendrix Shrine Series Fuzz Face Distortion</u> [pdf] User Manual JHMS1 Authentic Hendrix Shrine Series Fuzz Face Distortion, JHMS1, Authentic Hendrix Shrine Series Fuzz Face Distortion, Fuzz Face Distortion, Face Distortion, Distortion

Manuals+,