



## Contents [ [hide](#) ]

- [1 E Plus E Elektronik EE600 Differential Pressure Sensor](#)
- [2 Specifications](#)
- [3 Electrical Connection](#)
- [4 Analogue Outputs](#)
- [5 Installation](#)
- [6 User Interface](#)
- [7 FAQ](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



## **E Plus E Elektronik EE600 Differential Pressure Sensor**



## Specifications

- **Model:** EE600 – Differential Pressure Sensor
- **Analogue Outputs:** 2-wire (15 – 35 V DC), 3-wire
- **Electrical Connection:** P15ow-e3r5sVupDpCly
- **User Interface:** LED Indication – Green LED Flashing, Red LED Flashing
- Mounting Examples Available

## PLEASE NOTE

Find this document and further product information on our website at [www.epluse.com/ee600](http://www.epluse.com/ee600).

## Electrical Connection


**WARNING:** Incorrect installation, wiring or power supply may cause overheating and result in personal injury or property damage. Cables must not be under voltage during electrical installation and connection or disconnection, especially at terminal connections on circuit boards. For correct cabling, always observe the presented wiring diagram for the product version used. The manufacturer cannot be held responsible for personal injury or damage to property caused by incorrect handling, installation, wiring, power supply or maintenance of the device.

## Analogue Outputs

## 2-wire




## 3-wire




## Installation

### Pressure Connection



### Mounting Examples



Use a  $\varnothing 7.5$  mm drill to install the pressure connection nipples into the duct.

## User Interface

### LED Indication

Green LED		Red LED	
Flashing (1 s interval)	EE600 operates normally, the measured data is within the selected measuring range	Flashing (1 s interval)	The measured data is out of the selected range (overload or reversed pressure connection)
One flash (2 s)	Confirms adjustment or return to factory settings	One flash (2 s)	Indicates the failure of the attempt to adjust zero point or span point, or to return to factory a

Off	No power supply or electronics failure			djustment
Fast flashing (0.2 s interval)	Auto-zero is executed (first time 90 min after start / reset)			

### EE600 with 2-wire Analogue Output

1. Measuring range: 100 % = max. / customised range, other MR of max. range
2. No function
3. Auto-zero version only
4. These and further settings can be changed with PCS10 via USB configuration adapter (HA011066) while DIP switch S9 = 1
5. **Measuring range examples:**
  - S1 = 1, S2 = 0, S9 = 0, S10 = 1 0...750 Pa or 0...7 500 Pa
  - S1 = 0, S2 = 0, S9 = 0, S10 = 0  $\pm$ 1 000 Pa or  $\pm$ 10 000 Pa or customised measuring range

### PLEASE NOTE

The 2-wire version allows manual zero-point adjustment at 90-minute intervals if an autozero valve is present.

### EE600 with 3-wire Analogue Output

S1	S2	MR1)	S3	S4	Time	S5	S6	Unit	S7	DPB <sup>2</sup> )
0	0	100 %	0	0	50 m s	0	0	Pa	0	On

1	0	75 %	1	0	500 ms	1	0	mbar	1	Off
0	1	50 %	0	1	2 s	0	1	inch WC		
1	1	25 %	1	1	4 s	1	1	kPa		

S8	Output	S9	Setting <sup>3)</sup>	S10	Measuring Direction <sup>4)</sup>
0	0-10 V / 4-20 mA	0	DIP switches	0	Bidirectional
1	0-5 V / 0-20 mA	1	PCS10	1	Unidirectional

1. **Measuring range:** 100 % = max. / customised range, other MR of max. range
2. Display backlight
3. These and further settings can be changed with PCS10 via USB configuration adapter (HA011066) while DIP switch S9 = 1
4. **Measuring range examples:**
  - S1 = 1, S2 = 0, S9 = 0, S10 = 1 0...750 Pa or 0...7 500 Pa
  - S1 = 0, S2 = 0, S9 = 0, S10 = 0  $\pm$ 1 000 Pa or  $\pm$ 10 000 Pa or customised measuring range

## E+E Elektronik Ges.m.b.H.

- Langwiesen 7 4209 Engerwitzdorf | Austria
- T +43 7235 605-0
- F +43 7235 605-8
- [info@epluse.com](mailto:info@epluse.com)
- [www.epluse.com](http://www.epluse.com)

QG\_EE600 | Version v1.0 | 03-2025 | All rights reserved | 195408

## FAQ

**Q: How can I change the settings of the sensor?**

A: Settings can be changed using DIP switches or PCS10 via USB configuration adapter while ensuring specific switch positions.


**Q: What does the red LED flashing indicate?**

A: The red LED flashing indicates that the measured data is out of the selected range or there is a failure in adjusting zero point or span point.

**Q: How do I know if the sensor is operating normally?**

A: The green LED flashing at specific intervals indicates normal operation and that the measured data is within the selected measuring range.

## Documents / Resources

	<a href="#">E Plus E Elektronik EE600 Differential Pressure Sensor [pdf]</a> User Guide EE600, EE600 Differential Pressure Sensor, Differential Pressure Sensor, Pressure Sensor, Sensor
------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## References

- [User Manual](#)

■ E Plus E

Elektronik

◆ Differential Pressure Sensor, E Plus E Elektronik, EE600, EE600 Differential Pressure Sensor, Pressure Sensor, Sensor

—Previous Post

[E Plus E Elektronik EE160 Humidity and Temperature Sensor for Building Automation User Guide](#)

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.