




E-Tech ID-DF10B Cloud Digital Photo Frame User Manual

[Home](#) » [E-Tech](#) » E-Tech ID-DF10B Cloud Digital Photo Frame User Manual 

E-TECH

ID-DF10B Cloud Digital Photo Frame
User Manual



Thank you very much for purchasing this product. Please read this manual carefully to learn how to use the cloud frame correctly. It allows you to upload pictures, videos or music directly to the picture frame by mobile phone or email, and it would be displayed in the frame.

Contents

- 1 Precautions for a product startup
- 2 Cloud photo frame software instructions
- 3 Software interface introduction
- 4 Wireless network connection of cloud photo frame
- 5 Cloud frame interface
- 6 Other settings
- 7 Product specification
- 8 Troubleshooting guide
- 9 Precautions
- 10 Copyright description of cloud photo frame software
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts

Precautions for a product startup

1. Install the bracket on the bottom of the cloud frame clockwise;
2. Insert one end of the AC adapter into the standard 110-240V AC power socket and the other end into the DC power supply of the slot on the right side of the picture frame;
3. Slowly remove the protective film from the screen.

Cloud photo frame software instructions

Software download

Click the "Setting" icon in the main interface (see Figure 1), enter the setting interface, scan the QR code under "scan QRcode To Download App" with the mobile phone (see Figure 2), and wait for the software installation to be completed.




Figure 1




Figure2

- Download APP for Android Phones: search [Cloud Photo Frame] in the Google play store, and click download to enter the installation interface.
- Download APP for Apple Phones: search [Cloud Photo Frame] in the Apple APP store, and click download to enter the installation interface.

Software login

1. Email verification code login

2. User name&password login

***Note:** if you are using “cloud photo frame” software for the first time, please log in with the verification code.

Verification code login



1. Open the “Cloud Photo Frame” software and click the verification code to log in;
2. Input your own email account and click to get the verification code, check the verification code in the email, fill in the input box and click log in;
3. Then it will jump to the perfect user information interface, fill in the nickname and password information, and click OK to complete the registration and login.

User name&password login

1. Please log in as per the 2.3.1 verification code, and log in with a password after getting the user name and password.
2. Press the prompt to enter the user name and password, and click the login button.

***Note:** if it is the first time to log in, the software will prompt you to get permission for photos and videos. Please click allow, otherwise it will affect the subsequent use.

Software interface introduction

Software interface including Menu  , Scan  , Take a picture, record video, and Local gallery (see Figure 3).




Figure 3

Binding device

1. Enter the software and click Scan on the upper-right corner to open the page of device binding;
2. You can select “Scanning and adding” or “manually add” to bind a new device (in the setting of cloud photo frame, you can find QR code and photo frame ID (see Figure 2);
3. After the application of the binding device is sent, you need to wait for the approval of the administrator (the first user who binds the device is the administrator of the device by default) to use it normally (see Figure 4), or you can see the “To be confirmed user” (see Figure 5) in the “user ” in the setting interface of the cloud photo frame, find the corresponding user, and click accept to bind successfully.




Figure 4




Figure 5

Gallery

1. In the main interface of the software, click “Gallery” (see Figure 2);
2. According to your own needs, choose to send directly or send the puzzle (see Figure 6);
3. Click send to batch and add the description (see Figure 7);
4. Click the picture to cut the single picture according to the original picture, 1:1, 16:9, 9:16, 3:4, 4:3 and other proportions (see Figure 8);
5. After adding a description, click send to send photos to the photo frame. Up to 9 photos can be sent at a time (when sending, please select the photo frame to receive in the sending interface (see Figure 7).

Note: if you choose to send the jigsaw puzzle, you can combine the selected photos according to the preset style, and send them after adding a description and selecting a picture frame.



Figure 6




Figure 7



Figure 8

Video


1. In the main interface of the software, click "Video" (see Figure 2);
2. Click "send" after videos be selected;
3. Select the received frame to upload to the cloud frame;

Photo

1. In the main interface of the software, click "Photo" (see Figure 2);
2. After taking photos, you can directly select "use photos" to add descriptions in batches (see Figure 7);
3. Click the picture to cut the single picture according to the original picture, 1:1, 16:9, 9:16, 3:4, 4:3, and other proportions (see Figure 8);
4. After adding a description, click send to send photos to the photo frame. Up to 9 photos can be sent at a time (when sending, please select the photo frame to receive in the sending interface (see Figure 7).

Note: if you choose to send the jigsaw puzzle, you can combine the selected photos according to the preset style, and send them after adding a description and selecting a picture frame.

Menu

Menu  It consists of seven parts: user image, user name, email, my photo frame, history, message, and settings (as shown in Figure 9).




Figure 9




Figure 10




Figure 11

User profile

Users can click the avatar to set it.

User name and mailbox

That is, the mailbox used for registration and the user name set. If the user name is not set during registration, it is the default name.

My picture frame

You can view the picture frame you bind and the users you bind as the main picture frame (see Figure 4).

History

You can check the history of sending photos and video records, and also check whether the sent objects are successfully sent (see Figure 10).

Notifications

The message list is a message notification such as a binding device.

Set up

Enter the setting interface to change the nickname (i.e. user name), change the password, reset the password, view the user agreement, user guide, privacy agreement, version update, and exit the current account (see Figure 11).

Wireless network connection of cloud photo frame

1. When the frame is connected to the power supply, it will automatically turn on, and then the Wi-Fi setting interface will pop up. Please press the Wi-Fi name to find the corresponding wireless network, and click the Wi-Fi network you want to connect;
2. Use the keyboard to enter the password. Check [display password] to check whether the password you entered is correct. Click [connect] Wi-Fi to connect to the network;
3. After connecting to the available Wi-Fi, this wireless network will be saved in the settings. You can find the relevant information on the historically connected network at [settings → device information].

Cloud frame interface

The main interface consists of pictures, music, calendar, video, settings, wireless network, clock, and suspension ball (see 12).




Figure 12










Figure 13






picture


Click the picture in the main interface to enter the picture interface. It includes internal storage, memory card, USB drive, user's favorite pictures, and pictures uploaded by users who bind cloud photo frames. Click the picture to play the picture in the form of a slide.

Copy and delete pictures

1. Click on the top right corner of the screen , select the picture, and click on the top  Can be deleted.
2. Click on the top right corner of the screen , click above  You can select all the pictures.
3. Click on the top right corner of the screen , select the picture, and click on the top  You can copy pictures from the memory card / USB stick to the internal memory or from the internal memory to the memory card / USB stick.

Slide

1. When playing a picture, click  the rotatable picture.
2. When playing a picture, click  scale up or go back to the original size picture.
3. When playing a picture, click  you can pause or start the slide.
4. When playing a picture, click  delete the picture.
5. When playing a picture, click  you can zoom in or out of the picture.

When playing a picture, click  You can set the background music, interval time, and play mode.

Note: digital photo frame only supports adding pictures to favorite albums from internal storage

Music

Click "music" to enter the music interface, and select music to play. Copy music in the same way as the picture (see 5.1).

Video

Click "video" to enter the video interface and select file play. Copy video in the same way as the picture (see 5.1).

Clock

Click the clock displayed in the main interface to enter the clock selection interface. There are a variety of clocks

to choose from.



Calendar

Click calendar to enter the calendar on the Menu. There is a sliding window on the right to play pictures in a circular manner.

Set up

There are device information, user management, wireless network, album settings, system settings and machine details.

Device information

You can view the number, QR code, and software download QR code.

User management

You can receive the information of the user binding the device and choose whether to add the request or not. After adding, you can also delete the user (see Figure 5).Note: Each device can bind up to 30 users. When the number of bound users exceeds the limit, please delete some users.

Wireless network

Turn on or off the Wi-Fi connection and check for available Wi-Fi networks.

Album settings

You can set a full screen, slide time, background music, slide mode, slide transition effect, delete photos, and restore the default settings.

System settings

Can set voice, display, date and time, language, and restore factory settings.

Suspension ball

The suspension ball can be turned on or off in settings → system settings → display.

The functions of the suspension ball are: return to the previous layer, return to the main interface, volume +, volume -.

Other settings

Gravity induction

It can automatically rotate the screen according to the screen placement direction. This function can be turned on or off in settings → system settings → display.

Software online upgrade

In Settings > about, you can view the version information. Click this column. If there is a new version, the updated information will pop up automatically. Click download to get the latest version of the software.

Email upload file

1. Fill in the mailbox of the recipient in the mail: cloud_frame@eningqu.com
2. Frame the cloud photo in the theme number is filled in [] ([] is a symbol in English)
3. The image and video formats are jpg and MP4 formats
4. Pictures can only be added at most 9Video cannot be greater than 50m

Note: due to the transmission through the server, it is normal to stop for a few minutes.

Product specification

Product model	ID-DF1OB	Input power	AC 100-240V 50/60HZ
Output power	DC 5V/2A	Picture format	JPEG/BMP /GIF/PNG
Product memory	16 GB	Music format	Mp3 / WMA / APE / FLAC / WAV
Screen size	10.1inch	Video format	MP4,MKV,MOV,AVI,MPG,VOB,FIV,3GP,M2TS
Resolving power	1280*800	Memory card type	SD/SDHC/MMC Up to 32GB
Screen size	16:10	Interface	SD card / Mini USB / USB host / DC charging / headset
Screen brightness	200-300 cd/m2	Screen view	175 ° (left / right / vertical / horizontal)
Saturation	500:1	working temperature	0E-40t
Response speed	20ms	Humidity	10-85%

Troubleshooting guide

If you are having trouble using picture frames, please refer to the following solutions:

1. Unable to power on

Check that the power adapter and socket are energized

2. Unable to read memory card or USB stick

Please make sure that your memory card or USB stick is inserted properly. This product cannot read the empty device.

3. Unable to play the file

Please check whether the file format is compatible with the player of this product.

4. The screen display is too bright or too dark

Please adjust the brightness in the settings menu.

5. No sound

Please check whether the playing file has sound or whether the player is in mute mode.

6. Unable to upload the video to the device

Please check whether the required upload file has been uploaded.

7. Unable to find device ID or receive pushed videos and files

Please check whether the digital photo frame is connected to a normal wireless network.

Precautions

For indoor use only:

- To avoid the risk of water leakage or electric shock, do not expose the cloud frame to humidity or condensation.
- To avoid high temperatures, do not place the cloud frame in direct sunlight.
- Nonprofessionals are not allowed to dismantle the cloud photo frame, which may cause electric shock; if they dismantle the cloud photo frame without permission, they will not provide a warranty service.

Screen cleaning tips:

- Please protect the screen. Because the screen is made of glass, it is easy to be damaged or scratched.
- If fingerprints or dust accumulate on the LCD screen, it is recommended to use a dust-free cloth or non-abrasive cloth, such as a camera lens cloth, to clean the LCD screen.

Warning:

Please cut off the power before inserting or removing the memory card or USB device.

Avoid any damage to the memory card, USB, and machine.

To reduce the risk of fire or electric shock, do not expose the equipment to rain or dampness.

Copyright description of cloud photo frame software

1. The cloud photo frame software provided by Concept International Group (Hong Kong) Co., Ltd. is all self-developed and designed.
2. Concept International Group (Hong Kong) Co., Ltd. has the right to update, release and modify the system.
3. Any content in the original code of the system shall not be released, transmitted or modified without the permission of Concept International Group (Hong Kong) Co., Ltd. Any violator shall be punished.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, This equipment should be installed and operated with a minimum distance of 20cm the radiator of your body: Use only the supplied antenna.

Documents / Resources

<div data-bbox="156 107 268 224"><p>Cloud Digital Photo Frame</p><p>Instruction User Manual</p><p>ID-DF10B</p></div> <div data-bbox="143 241 280 264"><p>*These are not checked for your device photo product. Please read the manual carefully and use the photo frame according to the instructions and avoid any damage. Please refer to the manual for more details about the photo frame and its functions.</p></div>	<div data-bbox="319 145 1452 250"><p>E-Tech ID-DF10B Cloud Digital Photo Frame [pdf] User Manual</p><p>ID-DF10B, IDDF10B, 2AW2NID-DF10B, 2AW2NIDDF10B, ID-DF10B, Cloud Digital Photo Frame, ID-DF10B Cloud Digital Photo Frame, Digital Photo Frame, Photo Frame</p></div>
---	--

References

[Manuals+.](#)