



# Elitech STC-9100 Double Sensor Temperature Thermostat User Guide

[Home](#) » [Elitech](#) » Elitech STC-9100 Double Sensor Temperature Thermostat User Guide 

## Contents

- [1 Elitech STC-9100 Double Sensor Temperature Thermostat](#)
- [2 Wiring Diagram](#)
- [3 Set the temperature](#)
- [4 Configure the Defrosting](#)
- [5 Set the External Alarm?](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)




**Elitech STC-9100 Double Sensor Temperature Thermostat**



STC-9100 defrosting temperature controller controls three loads: the refrigeration device, the defrosting unit, and the External Alarm.




## Wiring Diagram



## Set the temperature

Please learn that the room temperature was supposed to keep at the range from “F1” to “F1 + F2” (“**SET**” to “**SET + HY**”).

You can set them in both the user interface and the Admin Interface. Below is the 2nd method.

- Step 1: Enter the Admin Interface: hold the [SET] key and the [  ] key at the same time for 10s; you will see the code “F1” (“**SET**”).
- Step 2: Press the [SET] key to check current value, and press the  key or the [  ] key to change the F1 value;
- Step 3: Press the [SET] key to save the new data, and back to the menu list, you will see the code “F1” (“**SET**”) again.
- Step 4: Switch to the “F2” (“HY”) code by press the key.  
Repeat the above 2-4 steps to update all the code you want to. Repeat the above 2-4 steps to update all the

code you  
want to.

**At last: Just leave the unit alone; it will auto quit from setting mode back to normal status in 10s.**

1. F1 ("SEt"): SP (Temperature Set-Point)
2. F2 (HY): Temperature Hysteresis / Return Difference
3. F3 (U5): Upper limit for SP
4. F4 (L5): Lower limit for SP
5. F5 (AC): Delay Time for the Compressor and Delay time for defrosting if it was Hot Gas mode

F10 = 1 (EdF = HEG)

If you found the "F1" ("SEt") value cannot be modified to the value you need, please adjust the F3 and F4 (the US and the L5), which are the limitation for F1 ("SEt")

## Configure the Defrosting

This unit controls the defrosting by Time and Temperature.

- **Temperature Condition:** the evaporation sensor temperature is lower than the preset "defrosting Stop temperature" F8 (dte), which is a significant value to prevent over defrost.
- **Time Condition 1:** the real-time passes the preset interval time F6 (i d f), a regular parameter for almost all defrosting thermostats.
- **Time Condition 2:** If the "defrosting method" you take is the hot gas from the compressor reverse rotary when F10 = 1 (t d f = HEG), it will count the compressor's last stops moment plus F5 (ac), which is a protective value to avoid the compressor frequently startup and stops.

**The operates method is just like page 1 shows;**

- F6 (i d f): Defrosting Cycle / Interval Time
- F7 (AdF): Defrosting Lasting/Running Time
- F8 (dte): Defrosting Stop Temperature
- F9 (Fdte): Defrosting Water Dripping Time
- F10 (EdF): Defrosting Mode:
  - 0 (EL): Electric-Heating.
  - 1 (CoH): Hot Gas from the compressor.
- F11 (dCE): Count mode of defrost cycle:

- **0 (rt)**: Cumulative time from the controller power on.
- **1 (CoH)**: Cumulative time of the compressor working.
- **F 12 (dFd)**: Display mode when defrosting:
  - **0 (rt)**: Shows the room sensor temperature display.
  - **1 (lt)**: Shows the evaporator sensor temp. (continue showing 10 minutes once defrosting over)

### Set the External Alarm?

Check the Alarm output options in **F 13 (dño)**:

Code	Description
<b>n-C/0</b>	The alarm output's function was banned.
<b>A-C/1</b>	The alarm follows
<b>A-A/2</b>	the buzzer status

press any key to stops  
It cannot be canceled before fixed all errors.

And then check below items

Sensor Position	EN Code	F code	Meaning
Evaporator	<b>ELL</b>	<b>F 14</b>	Lower Limit
	<b>Eod</b>	<b>F 15</b>	Time delay
	<b>ELU</b>	<b>F 16</b>	Upper Limit
Room	<b>ALU</b>	<b>F 17</b>	Upper Limit
	<b>ALL</b>	<b>F 18</b>	Lower Limit
	<b>ALd</b>	<b>F 19</b>	Time delay

This is not a step-by-step user manual; It just shows the key points. The new user should read the Full-Content Version User Manual



**Haswill Electronics**

STC-9100 Temperature Control & Monitor System Copyright Haswill-Haswell All Rights Reserved

<https://www.thermo-hygro.com>

**Documents / Resources**

STC-9100 Thermostat

Quick Start Guide

(Version 2.0.000.000)

STC-9100 defrosting temperature controller controls

three loads: the refrigeration device, the defrosting unit,

and the External Alarm.

1. **Wiring Diagram**

2. **Set the temperature**

Please bear in mind that the room temperature can be adjusted to

keep at the range from  $F_1$  to  $F_2$  or  $F_2$  to  $F_1$  to

[Elitech STC-9100 Double Sensor Temperature Thermostat](#) [pdf] User Guide  
STC-9100, Double Sensor Temperature Thermostat

References

- [Haswill Electronics - An exporter of digital temperature devices from China](#)
- [STC-9100 Defrost Temperature controller with External Alarming](#)

Manuals+.