



emos P5660SH Thermostatic and Timer Socket User Manual

[Home](#) » [EMOS](#) » emos P5660SH Thermostatic and Timer Socket User Manual 

emos P5660SH Thermostatic and Timer
Socket User Manual

2106000200_31-P5660SH_00_01_WEB


75 × 148 mm


P5660SH

Thermostatic and Timer Socket




www.emos.eu






2



3



4

Thermostatic and Timer Socket

This digital socket combines a switch socket for timed activation/ deactivation of home appliances with a thermostatic socket for automatic regulation of electrical heating and cooling systems (convector heaters, ladder radiators, infrared heating panels, air-conditioning).

Technical Specifications

Power supply: 230 V~, 50 Hz, 16 A max.

IP rating: IP30

Operating temperature: 0 °C to 55 °C increment for setting time: 1 minute

Switched load: max. 230 V AC, 3,680 W; 16 A for resistive load; 4 A for inductive load

Temperature measurement: 0 °C to 45 °C with 0.1 °C resolution; accuracy ± 1 °C at 20 °C

Temperature setting: 5 °C to 40 °C in 0.5 °C increments

Temperature differential setting: 0.2 °C to 2 °C, in 0.1 °C increments

Back-up power supply: 1 × 3 V CR2032 battery (included)

Dimensions: 82 × 62 × 146 mm

Description of Control Elements (See Fig. 1)

1. socket for connecting an appliance
2. BOOST button
3. „-“ button
4. - TIME button
5. - screen

6. temperature sensor
7. PROG button
8. „+“ button
9. RESET
10. MODE button

On-Screen Indicators in Thermostatic Mode (See Fig. 2)

1. time mode
2. programme number
3. mode icon
4. day number
5. room temperature
6. time/set temperature
7. back-up battery low


On-Screen Indicators in Timer Mode (See Fig. 3)

1. time mode
2. mode icon
3. day number
4. time
5. programme number
6. back-up battery low

Back-Up Battery Replacement

The back-up battery is used to power the socket's memory.
The expected battery life is 2 years.



When  appears on the screen, replace the battery.

1. Remove the 4 screws on the back and take off the front cover (see fig. 4).
2. Remove the drained battery and insert a new one.
3. Make sure you observe the correct polarity: + side up.
4. Replace the cover and screw it back on.

A) USE IN THERMO-SWITCH SOCKET (THERMOSTAT) MODE

Socket Placement

Choose a spot preferably on an inside wall where air circulates freely and there is no direct sunlight.

The connected heating appliance should be at a sufficient distance from the socket to prevent the devices from influencing each other.

Otherwise, the socket may activate the appliance when not needed.

Putting the Device into Operation

Plug the socket into a 230 V/50 Hz socket; the screen will activate.

Plug the appliance into the thermostatic socket.

Activating Thermo-Switch Socket (Thermostat) Mode

Long-press the TIME and MODE buttons at the same time to access settings.

THE
01

Repeatedly press the + and – buttons to select the mode marked as „THE“ 01 .

Confirm by pressing the TIME button and continue with further settings.

The settings below are only available when in thermostat mode!

Heating or Cooling Mode

Long-press the TIME and MODE buttons at the same time and then press the TIME button 1 x.

HEAT
02



COOL
02



Use the + and – buttons to choose between heating or cooling mode.

Confirm by pressing TIME; this will open:

Temperature Differential Setting

Use the + and – buttons to set a value of 0.2 °C to 2 °C, with 0.1 °C resolution.

Confirm by pressing TIME; this will open:

Room Temperature Calibration

Use the + and – buttons to set a value of -3 °C to +3 °C, with 0.5 °C resolution.

Wait 30 seconds or press MODE to save the setting and return to the main screen.

Explanation of functions:

Temperature Differential Setting

The temperature differential (hysteresis) is the difference in temperature required for switching the system on and off.

If, for example, you set the temperature in heating mode to 20 °C and differential to 0.2 °C, the thermostat activates heating as soon as room temperature drops to 19.8 °C and switches heating off when temperature reaches 20.2 °C.

Room Temperature Calibration

The temperature sensor in the thermostat is calibrated from production, but additional calibration can be done to optimise the thermostat further, for instance by comparing the measured room temperature with a reference thermometer.

Setting Day and Time

Press the TIME button; the day number will begin flashing.

Use the + and – buttons to set the current day and press TIME to confirm.

The month number will start flashing. Use the + and – buttons to set the current month and press TIME to confirm.

The year will start flashing. Use the + and – buttons to set the current year and press TIME to confirm.

The hour will start flashing. Use the + and – buttons to set the current hour and press TIME to confirm.

The minute will start flashing. Use the + and – buttons to set the current minute and press TIME to confirm.

Wait 30 seconds or press MODE to save the setting and return to the main screen.

Table of Factory Preset Programmes (Max. 6 Temperature Changes a Day)

		Time	Temperature
Monday–Sunday Monday–Friday Mon/Tue/Wed/Thu/Fri	P1	6:00	20 °C
	P2	8:00	15 °C
	P3	12:00	15 °C
	P4	14:00	15 °C
	P5	17:00	21 °C
	P6	22:00	15 °C
		Time	Temperature
Saturday–Sunday Sat/Sun	P1	7:30	20 °C
	P2	9:30	20 °C
	P3	11:30	20 °C
	P4	13:30	20 °C
	P5	16:30	21 °C
	P6	22:30	15 °C

Setting Programmes – Automatic Mode

If the factory preset programmes do not suit your needs, you can adjust their timing and temperatures. The day can be divided into a maximum of 6 time periods = 6 temperature changes.

1. Press the PROG button; the day number will begin flashing. 1 to 7 = Monday to Sunday.
2. Use the + and – buttons to select the days: individual days in the week/workdays – 1, 2, 3, 4, 5/weekend – 6, 7/whole week – 1, 2, 3, 4, 5, 6, 7.
3. Confirm by pressing TIME; the time value will start flashing and P1 will appear on the screen (indicating the 1st temperature change in the day).
4. Use the + and – buttons to set the time (1 minute resolution) when the 1st temperature change should start and confirm with the TIME button.
5. The temperature value will start flashing; use the + and – buttons to set the temperature of choice and confirm with TIME.
6. The time value will start flashing and P2 will appear on the screen (indicating the 2nd temperature change in the day).
7. Use the + and – buttons to set the time when the 2nd temperature change should start and confirm with the TIME button.
8. The temperature value will start flashing; use the + and – buttons to set the temperature of choice and confirm with TIME.
9. Repeat the process for the remaining temperature changes (P3/4/5/6) in the day.

To end setting, wait 1 minute or press the MODE button.

Note: If you wish to delete a set programme, long-press the TIME button when the time is flashing. Move forward in settings by pressing the TIME button; pressing the PROG navigates one step back in settings.

Manual Temperature Mode

Press the MODE button until SET and a temperature value appear on the right of the screen. Use the + and – buttons to set the temperature and wait 5 seconds for the setting to automatically save. The set temperature will be maintained until you cancel manual mode.

Short-Term Manual Temperature Change

When in automatic mode, where temperature is controlled by the selected programme, it is possible to make a short-term change to the current temperature setting.

While in automatic temperature control mode (AUTO and P – programme number displayed on the left side of the screen) use the + and – buttons to set the new temperature and wait 5 seconds for the setting to automatically save.

P – programme number will disappear from the screen; AUTO will remain.

The manually set temperature will be maintained until the programmed temperature change.

OFF Mode

Press the MODE button until OFF appears on the screen.

The room temperature and clock will be displayed, but current output from the socket will be turned off.

To reactivate the socket, press MODE repeatedly to set the socket to either the automatic or manual temperature control mode.

BOOST Mode

The BOOST feature can be used to heat up a room in a short time.

Press the BOOST button repeatedly to choose the time frame (30 min to 9 hours, 30 min resolution).

Then, use the + and – buttons to choose temperature; the setting will be saved automatically.

The chosen temperature will be valid for the entire set period.

The time and temperature remaining will flash on the screen along with the room temperature and the clock.


Once the time elapses, the system will automatically switch back to the previous temperature mode and the previously set temperature.

To end the BOOST function prematurely, use the MODE button to select a different temperature mode or press the BOOST button repeatedly until the time setting reaches 9 hours; the next press will deactivate the BOOST function.

B) USE IN TIMER SWITCH SOCKET MODE

Activating Timer Switch Socket Mode

Long-press the TIME and MODE buttons at the same time to access settings.

Repeatedly press the + and – buttons to select the mode marked as „PrO“ .

Wait 30 seconds or press MODE to automatically save the setting and return to the main screen.

Setting Day and Time

Press the TIME button; the day number will begin flashing.

Use the + and – buttons to set the current day and press TIME to confirm.

The month number will start flashing. Use the + and – buttons to set the current month and press TIME to confirm.

The year will start flashing. Use the + and – buttons to set the current year and press TIME to confirm.

The hour will start flashing. Use the + and – buttons to set the current hour and press TIME to confirm.

The minute will start flashing. Use the + and – buttons to set the current minute and press TIME to confirm.

Wait 30 seconds or press MODE to automatically save the setting and return to the main screen.

Table of Factory Preset Times

		Activation time (ON)	Deactivation time (OFF)
Monday–Sunday Monday–Friday Mon/Tue/Wed/Thu/Fri Saturday–Sunday Sat/Sun	P1	6:00	8:00
	P2	12:00	14:00
	P3	17:00	22:00

Setting Programmes – Automatic Mode

If the factory settings do not suit your needs, you can adjust the timing of the programmes.

You can set a maximum of 24 time programmes.

1. Press the PROG button; the day number will begin flashing. 1 to 7 = Monday to Sunday.
2. Use the + and – buttons to select days: individual days in the week/workdays – 1, 2, 3, 4, 5/weekend – 6,

7/whole week – 1, 2, 3, 4, 5, 6, 7.

3. Confirm with the TIME button; the time value will start flashing and P1 – ON (activation of the 1st programme) will appear on the screen.
4. Use the + and – buttons to set the time (1 minute resolution) when the 1st time programme should start and confirm with the TIME button.
5. The time value will start flashing and P1 – OFF (deactivation of the 1st programme) will appear on the screen.
6. Use the + and – buttons to set the time when the 1st time programme should turn off; confirm by pressing TIME.
7. The time value will start flashing and P2 – ON (activation of the 2nd programme) will appear on the screen.
8. Repeat this process for the other programmes.

To end setting, wait 1 minute or press the MODE button.

While a program is on, the screen will display AUTO ON.

While a program is off, the screen will display AUTO OFF.



Note: If you wish to delete a set programme, long-press the TIME button when the time is flashing.
Move forward in settings by pressing the TIME button; pressing the PROG navigates one step back in settings.

BOOST Mode (Countdown)

The countdown function enables turning off an appliance after a preset time.

Press the BOOST button repeatedly to choose the time frame (30 min to 9 hours, 30 min resolution).

The countdown from the set time will start automatically.



The time remaining will be flashing on the screen alongside the mode icon ( or ) and clock.

Once the set time elapses, the system will automatically switch to the previous mode.

To end the BOOST function prematurely, use the MODE button to select a different mode or press the BOOST button repeatedly until the time setting reaches 9 hours; the next press then deactivates the BOOST function.

Note: The BOOST function cannot be used in manual mode (ON).

Manual Mode (ON)

Press the MODE button repeatedly until ON and the mode icon ( or ) appear in the left of the screen.

The socket will remain operational.

The set mode will be active until you switch to another one using the MODE button.

OFF Mode

Press the MODE button until OFF appears on the screen.

The clock will remain on the screen but the current output from the socket will be turned off.

To reactivate the socket, press MODE repeatedly to set the socket to either the automatic (AUTO) or manual (ON) temperature control mode.

Screen Illumination

Pressing any button activates screen illumination for 15 seconds.

Factory Reset

If the socket is not working properly, you can reset it to factory settings.

Long-press the PROG button and insert e.g. a straightened paper clip into the RESET hole; you will hear a click. The screen will display all segments/icons; release the PROG button.



Safety Warnings

- The device is intended for use in dry, indoor environments only. Do not expose the device to rain, snow or other extreme conditions. Do not use the product outdoors!
- Do not overload the device.
- The device must only be connected to and used with 230 V AC (~)/50 Hz electrical wiring fitted with a protective contact in line with valid electrical regulations.
- Pay attention to the data on the type plate of the appliances connected to the device. Maximum input power of all connected electrical appliances must not exceed 3,680 W (max. current 16 A). Max. inductive load: 4 A.
- Any use of the device not listed in the previous sections of the manual will result in damage to the product and could present danger in the form of a short circuit, injury by electric current, etc. The device must not be modified or otherwise restructured! Safety warnings must be followed unconditionally.
- Make sure that the lead-in earth pin is not damaged – a damaged earth pin could endanger the life of the user.
- The recommended operating temperature is from 0 °C to +55 °C.
- The device must not be used in hostile environments such as environments with flammable gases, vapours or dust.
- Never tamper with the electrical circuits of the device or disassemble it! If the device is damaged or non-functional, contact the seller.
- Only clean the device and the LCD screen using a soft dry cloth.
Do not use any cleaning agents or immerse the device in water!
- The device is not intended for use by children or persons whose physical, sensory or mental disability or lack of experience and expertise prevents safe use, unless they are supervised by a person responsible for their safety. Keep the device out of reach of children. Children must be supervised to ensure they do not play with the device.



Do not dispose with domestic waste. Use special collection points for sorted waste. Contact local authorities for information about collection points. If the electronic devices would be disposed on landfill, dangerous substances may reach groundwater and subsequently food chain, where it could affect human health.

Contents

[1 Documents / Resources](#)

[1.1 References](#)

[2 Related Posts](#)

20240202_11_P5660SH_01_01_WEB 75 x 148 mm

P5660SH

1	1. Úvod
2	2. Bezpečnostní pokyny
3	3. Instalace
4	4. Použití
5	5. Údržba
6	6. Přílohy
7	7. Záruka
8	8. Kontaktní údaje
9	9. Příloha
10	10. Příloha
11	11. Příloha
12	12. Příloha
13	13. Příloha
14	14. Příloha
15	15. Příloha
16	16. Příloha
17	17. Příloha
18	18. Příloha
19	19. Příloha
20	20. Příloha
21	21. Příloha
22	22. Příloha
23	23. Příloha
24	24. Příloha
25	25. Příloha
26	26. Příloha
27	27. Příloha
28	28. Příloha
29	29. Příloha
30	30. Příloha
31	31. Příloha
32	32. Příloha
33	33. Příloha
34	34. Příloha
35	35. Příloha
36	36. Příloha
37	37. Příloha
38	38. Příloha
39	39. Příloha
40	40. Příloha
41	41. Příloha
42	42. Příloha
43	43. Příloha
44	44. Příloha
45	45. Příloha
46	46. Příloha
47	47. Příloha
48	48. Příloha
49	49. Příloha
50	50. Příloha
51	51. Příloha
52	52. Příloha
53	53. Příloha
54	54. Příloha
55	55. Příloha
56	56. Příloha
57	57. Příloha
58	58. Příloha
59	59. Příloha
60	60. Příloha
61	61. Příloha
62	62. Příloha
63	63. Příloha
64	64. Příloha
65	65. Příloha
66	66. Příloha
67	67. Příloha
68	68. Příloha
69	69. Příloha
70	70. Příloha
71	71. Příloha
72	72. Příloha
73	73. Příloha
74	74. Příloha
75	75. Příloha
76	76. Příloha
77	77. Příloha
78	78. Příloha
79	79. Příloha
80	80. Příloha
81	81. Příloha
82	82. Příloha
83	83. Příloha
84	84. Příloha
85	85. Příloha
86	86. Příloha
87	87. Příloha
88	88. Příloha
89	89. Příloha
90	90. Příloha
91	91. Příloha
92	92. Příloha
93	93. Příloha
94	94. Příloha
95	95. Příloha
96	96. Příloha
97	97. Příloha
98	98. Příloha
99	99. Příloha
100	100. Příloha

CE

www.emos.cz

[emos P5660SH Thermostatic and Timer Socket](#) [pdf] User Manual

P5660SH Thermostatic and Timer Socket, P5660SH, Thermostatic and Timer Socket, Timer Socket, Socket

References

- [E EMOS | Elektro eshop a velkoobchod](#)[EMOS | Elektro eshop a velkoobchod](#)