

FAQs What can I do if the hard drive enclosure cannot be detected? User Manual

Home » FAQs » FAQs What can I do if the hard drive enclosure cannot be detected? User Manual



Contents

- 1 FAQs What can I do if the hard drive enclosure cannot be detected
- 2 Troubleshooting Guide
- 3 Documents / Resources
- **4 Related Posts**



FAQs What can I do if the hard drive enclosure cannot be detected



• What can I do if the hard drive enclosure cannot be detected?

- 1. Check if your SSD is NGFF but not NVMe one.
- 2. Re-plug the enclosure to ensure it is connected properly.
- 3. Recheck in "My Computer-Device Manager-Universal Serial Bus Controller" to see if the enclosure still cannot be detected. If not, please upgrade the USB driver of your computer for a try.
- 4. Test the hard drive enclosure with another computer.

• What can I do if the enclosure can be detected, while the hard drive cannot?

- Re-plug the hard drive to ensure it is connected properly with the enclosure.
- Check in "My computer-computer management -storage -disk management disk to see if the hard drive still cannot be detected. If not, please test this enclosure with another hard drive.

· How can I troubleshoot if hard drives can be detected while it cannot be read and wrote properly?

- Back up the data first if it is not a new hard drive and then format it.
- Make a partition if it is a new hard drive.
- Make sure the format of the hard drive is supported by the PC system.

How can I troubleshoot if the read and write speed is slower than I expected?

- Connect the enclosure to the USB A 3.0 rather than the USB A 2.0 port.
- Use the included cable for connecting the enclosure and computer.
- · Test it with another hard drive if possible.

· What can I do if the hard drive enclosure gets disconnected?

- Test it with another cable to see if it is the cable issue.
- Re-plug the devices to ensure every part is connected properly.
- Try the enclosure with another hard drive and computer if possible.

Documents / Resources



FAQs What can I do if the hard drive enclosure cannot be detected? [pdf] User Manual What can I do if the hard drive enclosure cannot be detected, What can I do if the enclosure can be detected, while the hard drive cannot

Manuals+,