



FIELDMANN FZP 2000-E Chainsaws User Guide

[Home](#) » [FIELDMANN](#) » FIELDMANN FZP 2000-E Chainsaws User Guide 

FIELDMANN FZP 2000-E Chainsaws



Contents

1 GENERAL SAFETY INSTRUCTIONS
1.1 Important safety notice
1.2 Packaging
1.3 Operating instructions
2 SYMBOLS
3 SAFETY INSTRUCTIONS
3.1 Safety in the work area
3.2 Safety when working with power tools
3.3 Using power tools and their maintenance
3.4 Service
3.5 Storage
4 DESCRIPTION OF THE CHAIN SAW
5 INSTALLING THE GUIDE BAR AND CHAIN
6 FILLING THE CHAIN SAW OIL TANK
7 OPERATING THE CHAIN SAW
7.1 Securing the extension cord.
7.2 Checking chain lubrication
8 CHAIN BRAKE
8.1 Checking the working order of the brake.
9 ADJUSTING THE CHAIN TENSION
10 USING THE CHAIN SAW
11 CUTTING
11.1 Safety brake (protection against kickback)
11.2 Cutting trees
11.3 Cutting logs
12 CLEANING AND MAINTENANCE
12.1 Maintaining the guide bar
12.2 Normal maintenance of the guide bar
13 SHARPENING THE SAW CHAIN
13.1 Equipment necessary for sharpening a saw chain
13.2 Sharpening the teeth on the chain
13.3 Filing the depth gauge
14 REPLACING THE SAW CHAIN
15 STORAGE
16 TECHNICAL SPECIFICATIONS
17 DISPOSAL
18 Conditions of guarantee
19 Documents / Resources
19.1 References
20 Related Posts

GENERAL SAFETY INSTRUCTIONS

Important safety notice

- Carefully unpack the product and take care not to throw away any part of the packaging before you find all the parts of the product.
- Store the product in a dry place out of reach of children.
- Read all warnings and instructions. Not following warnings or instructions may lead to injury by electrical shock, a fire and/or serious injuries.

Packaging

The product is packed in a package that prevents damage during transport. This package is a resource and so can be handed over for recycling.

Operating instructions






Before you start working with the power tool, read the following safety and usage instructions. Understand the operating elements and the correct use of the power tool. Keep the user's manual in a safe place where it can be easily retrieved for future use. Save the original packaging, including the internal packing material, warranty card and proof of purchase receipt, at least for the duration of the warranty. If you need to ship this power tool, pack it in the original cardboard box to ensure maximum protection during shipping or transport (e.g. when moving or when you need to send this power tool for repair to a service centre).









Note: If you hand over the power tool to somebody else, do so together with this user's manual. Following the instructions in the included user's manual is a prerequisite for the proper use of the power tool. The user's manual also contains operating, maintenance and repair instructions.

The manufacturer takes no responsibility for accidents or damages resulting from not following the instructions in this manual.

SYMBOLS

	Do not expose the power tool to rain.
	Before using the power tool, carefully read the user's manual.
	In the event that the power cord is damaged, immediately disconnect it from the power supply.
	When working, always use a safety helmet, safety glasses and ear protection.
	Careful: danger of kickback.

	DANGER! Do not use the power tool if there are children, other persons or animals in your vicinity.
	While working use protective gloves.
	Use solid insulating work footwear.
	Use hearing protection.
	Use work gloves.
	Be careful of falling branches,

SAFETY INSTRUCTIONS

ATTENTION!

Acquaint yourself with all warnings and safety instructions and with operation instructions for the power tool.

ATTENTION!

Not adhering to warnings or safety instructions may result in injury by electrical shock, a fire and/or serious injury.

ATTENTION!

Store all warnings and safety instructions in a practical location for future reference.

Note: The term “power tool” in all hereafter provided warnings is defined as an electric power tool powered from the power grid (via a flexible power cord).

Safety in the work area

- Keep the work area tidy and well illuminated. Untidiness and dark locations in the workplace are sources of accidents.
- Do not use the power tool in environments where there is an explosion hazard, where there are flammable liquids, gases or dust. The power tool generates sparks which could ignite dust or vapours.
- When using the power tool, prevent children and other persons access to the power tool. If you become

distracted, you may lose control over the power tool.

Safety when working with power tools

- The plug on the flexible power cord must correspond to the power socket outlet. Never modify the plug in any way. Never use any socket adapters with power tools that have a safety earth grounding connection. Plugs that are not damaged by modifications and that correspond to the power socket will limit the danger of injury by electrical shock.
- Prevent your body from coming into contact with grounded objects, such as pipes, central heating radiators, stoves and refrigerators. The risk of injury by electrical shock is greater when your body is connected to the ground.
- Do not expose the power tool to rain, dampness or wetness. The entry of water into the power tool increases the danger of injury by electrical shock.
- Do not use the flexible power cord for other purposes. Never carry or pull the power tool by its power cord or pull the plug out of the socket by the power cord. Protect the power cord against heat, grease, sharp edges and moving parts. Damaged or tangled power cords increase the danger of injury by electrical shock. If the power tool is used outdoors, use an extension cord suitable for outdoor use. Using extension cords designed for outdoor use limits the risk of injury by electrical shock.
- If you will be using the power tool in a damp environment, use a residual current device (RCD) in the power supply circuit. The use of a residual current device reduces the risk of injury by electrical shock.



Note: The “residual current device” (RCD) may be substituted for by the term “ground fault circuit interrupter” (GFCI) or “earth leakage circuit breaker” (ELCB).

- Safety of people When working with the power tool, always stay alert, watch what you are doing and use common sense. Do not use power tools if you are tired or under the influence of drugs, alcohol or medication. A moment of carelessness when working with power tools may result in serious injury.
- Use personal protective aids. Always use eye protection. Use protective aids, e.g. respirator, safety footwear with anti-slip soles, hard head cover or hearing protection appropriately to the work conditions; they reduce the risk of injury to persons.
- Avoid accidentally starting up the power tool. Before connecting to a power source, before connecting the battery, before storage or before carrying the power tool, make sure that the start/stop trigger is in the off position. Carrying the power tool with a finger on the trigger or connecting the power tool’s plug with the trigger engaged may cause an accident.
- Remove all adjustment tools and spanners before turning on the power tool. An adjustment tool or spanner left attached to a rotating part of the power tool may result in injury to persons.
- Only work in locations that you can reach safely. Always maintain a stable stance and balance. In this way you will have better control over the power tool in unexpected situations.
- Dress in an appropriate manner. Do not wear loose clothing or jewellery. Make sure that your hair, clothing and gloves are at a sufficient distance from moving parts. Loose clothing, jewellery and long hair may become caught in the moving parts.
- If there is equipment available for the extraction and collection of dust, make sure that such equipment is connected and used correctly. The use of such equipment may limit the danger posed by the created dust.

Using power tools and their maintenance

- Do not overload the power tool. Only use power tools that are appropriate for the work being performed. Appropriate power tools for the given task will do the job better and more safely.
- Do not use power tools that cannot be turned on and off with a switch. Any electric power tools that cannot be controlled using a switch are dangerous and must be repaired.
- Before adjusting the power tool, before replacing accessories or if you will not be using the power tool, pull the power plug out of the power socket. These preventative safety measures limit the danger of accidentally turning on the power tool.
- When not used, store the power tool out of children's reach and do not permit person not acquainted with the power tool or these instructions to use the power tool. A power tool in the hands of inexperienced users is dangerous.
- Perform maintenance on the tool. Check the adjustment of moving parts and their movement, focus on cracks, broken parts or any other circumstances that may threaten the proper operation of the power tool. If the power tool is damaged, have it repaired before using it again. Many accidents are caused by insufficiently maintained power tools.
- Keep cutting power tools clean and sharp. Correctly maintained and sharpened cutting power tools are less likely to get stuck on material or to jam and they are also easier to control.
- Use power tools, accessories, working tools, etc. in accordance with these instructions and in such a manner as prescribed for the specific power tool with respect to the given work conditions and the type of work being carried out. Using power tools for tasks other than for which they are designed may lead to dangerous situations.

Service

- Have your power tool repaired by a qualified person that will use original spare parts. In this manner, the same level of safety will be ensured as before the repair of the power tool.


Storage

- only move or store the power tool with the protective cover attached
- carefully clean and perform appropriate maintenance before storing the power tool
- before transporting the power tool, secure it against oil leakage, damage or injury hazard

DESCRIPTION OF THE CHAIN SAW

1. Start/stop trigger
2. Power cord safety hook
3. Rear handle
4. Oil tank cap
5. Front handle
6. Safety chain brake
7. Guide bar with chain
8. Guide bar fastening nut
9. Sprocket cover
10. Oil tank window

Fig. 1



Included contents:

Electric chain saw, 35 cm guide bar, chain, plastic guide bar cover, spare brushes set, mounting wrench.

INSTALLING THE GUIDE BAR AND CHAIN


⚠ ATTENTION!

The chain saw must be disconnected from the power grid.

⚠ ATTENTION!


Always wear protective gloves when installing and inspecting the chain to prevent injury from the sharp cutting edges on the chain.

Fig. 2



- The safety brake lever (fig. 1 point 6) must be disengaged (pull it towards the top handle)
Using the included socket wrench, screw out the guide bar fastening nut (fig. 1, point 8) and remove Fig. 3 the sprocket cover (fig. 1, point 9)
Put the chain (fig. 2, point 1) on to the drive sprocket (fig. 2, point 2)
- Put the guide bar (fig. 2, point 3) on to the guide bolts (fig. 2, point 4) and push it towards the drive sprocket. It is very important that during the installation the adjustment pin (fig. 2, point 5) fits into the hole in the guide bar.
The pin can be moved forward and backwards by turning the adjustment bolt (fig. 3, point 1)

Fig. 3



- Seat the chain into the guiding groove on the guide bar. The correct seating direction is indicated on the chain saw and in chapter “Changing the saw chain”
- Put on the cover (fig. 1, point 9) and fasten it by lightly tightening the guide bar fastening nut.

⚠ ATTENTION!

Never fully tighten the nut before the chain is fully tensioned, there is a risk of damaging the chain saw

Tension the chain using the tensioning screw (fig. 3, point 1) and then tighten the guide bar fastening bolt (fig. 1, point 8)

⚠ ATTENTION!

The chain is correctly tensioned if it is possible to lift chain off the guide bar and its height in the horizontal position in the middle of the guide bar is 3 to 4 mm.

FILLING THE CHAIN SAW OIL TANK

⚠ ATTENTION!

- A new chain requires a certain running-in period, which is usually 5 minutes. The lubrication of the chain is very

important during this phase. After this running-in period, check the chain tension and readjust if necessary.

The oil tank on the supplied chain saw is empty. Fill this oil tank with oil prior to first use of this chain saw.

- Only use oil specified for total-loss lubrication
- Screw off the oil tank cap (fig. 1, point 4).
- Pour the oil into the tank (take care to prevent the oil from becoming dirty while filling the tank).
- Screw on the oil tank cap

ATTENTION!

Do not use oil that has already been used or processed because this could damage the oil pump. Only use oil specified for total-loss lubrication

OPERATING THE CHAIN SAW

Securing the extension cord.

ATTENTION!

When working with this chain saw, only use extension cords designed for outdoor use. The wire crosssections on the extension cord must be at least 1.5 mm².

- To ensure safe operation of this chain saw, it is necessary to secure the power cord in place. Bend the power cord approximately 20 cm before the socket. Thread the bend through the rear handle and fit it into the hook. (fig. 1, point 2)

ATTENTION!

If you use an extension cord longer than 30 m, the power of the chain saw will be reduced.

Turning on / off

ATTENTION!

The voltage in the power grid must correspond to the voltage on the rating label of the chain saw.

ATTENTION!

Hold the chain saw firmly with both hands when starting and working with it

Starting

- Press the trigger safety lock button located on the left above the start/stop trigger and then press the start/ stop trigger (fig. 1, point 1) . When started, the chain saw will run at maximum speed.

ATTENTION!

If the chain saw does not start, disengage the brake lever (fig. 1, point 6).

Turning off

- Release the start/stop trigger (fig. 1, point 1).

ATTENTION!

The chain saw is equipped with a safety chain brake, which will immediately stop the chain when the start/ stop trigger is released. If the chain does not immediately come to a stop when the trigger is released, please contact an authorised service centre without delay.

Checking chain lubrication

Attention: adhere to safety provisions and prevent the guide bar from coming into contact with the surface of the terrain. Use this power tool safely and maintain a minimum distance of 20 cm from the ground.

- Before starting work, check the chain lubrication and the amount of oil in the oil tank. Start the chain saw and hold it above the ground. If you see a growing oil stain then chainlubrication is working properly. If there are no oil stains on the ground, clean the oil outlet, the top chain tensioning hole and the oil lines or contact an authorised service centre.

CHAIN BRAKE

- This chain saw is equipped with an automatic brake that stops the chain in the event of kickback. The brake is automatically engaged as soon as the force of inertia acts on the ballast located inside the brake box.
- The chain brake may also be engaged manually when the brake lever (fig. 1, point 6) is moved downwards towards the guide bar. The activation of the brake stops the chain movement within 0.12 seconds.

Checking the working order of the brake.

Check that the brake works properly before every use. Place the running chain saw on to the ground and for 1 to 2 seconds leave it at full speed. Push the brake lever (fig. 1, point 6) forward. The chain should stop immediately.

ATTENTION!

If the chain stops slowly or does not stop at all, do not use the chain saw and contact an authorised service centre.

If you wish to disengage the brake, pull the brake lever towards the top handle (fig. 1, point 5) so that you hear the typical sound for the disengagement of the brake.

ATTENTION!

Check that the chain brake is in order. A correctly functioning chain brake will protect you against potential injury, which could result from kickback. If the brake is not working properly, have it adjusted or repaired at an authorised service centre.

ADJUSTING THE CHAIN TENSION

ATTENTION!

Due to the effect of higher temperatures, during operation the saw chain has a tendency to lengthen. A longer

chain becomes loose and could slide off the guide bar.

- Loosen the guide bar fastening nut (fig. 1, point 8).
- Make sure that the chain is seated in the guiding groove of the guide bar.
- Use a screwdriver to turn the chain tensioning screw (fig. 3, point 1). Turn the tensioning screw until the required tension is achieved (you should lift the chain in the middle of the guide bar in the horizontal position to a height of 3 to 4 mm).
- Firmly tighten the guide bar fastening nut (fig. 1, point 8).

ATTENTION!

Do not tension the chain excessively. Excessive tension of a warm chain may result in excessively tension when it cools down.

USING THE CHAIN SAW

- Before starting any kind of work, thoroughly acquaint yourself with the sections describing the safety instructions for the operation of the chain saw. We recommend that you acquire experience by practising on waste wood. In this way you will learn about the operating parameters of this chain saws.
- Always adhere to safety instructions.
- Only use this chain saw for cutting wood. Cutting any other materials is forbidden.
- The vibration intensity and type of kickback on this chain saws depends on the type of wood being cut.
- Do not use this chain saw as a lever for lifting, moving or splitting material. If the chain jams in the material that is being cut, stop the chain saw and knock a wooden or plastic wedge into the cut to release the chain. Restart the chain saw and carefully commence cutting.

CUTTING

ATTENTION!

Before proceeding, please read the chapter "Safety instructions". We recommend that you gain experience by cutting smaller logs. In this way you will also get to know the chain saw.

- Always adhere to safety instructions. The chain saw may only be used for cutting wood.
- It is forbidden to cut any other materials. Vibrations and kickback differ for various materials. Do not use the chain saw as a lever for lifting, moving or splitting material. It is forbidden to attach any parts or jigs other than those specified in the technical documentation. It is not necessary to push the chain saw into the cut. When the motor is running at full speed, push the chainsaw down lightly.
- If the chain jams in the cut, do not attempt to free it by pulling, rather stretch open the cut using a wedge or crowbar.


Safety brake (protection against kickback)

- This chain saw is equipped with an automatic chain brake that, if it works correctly, immediately stops the chain in the event of kickback. It is necessary to check the working order of the chain brake before every use of the chain saw. Run the chainsaw at full speed for 1 – 2 seconds and then tilt the front protective cover. The chain

must stop immediately even when the motor is running at high speed. If the chain stops slowly or does not stop at all, please contact an authorised service centre.

- It is extremely important to check the working order of the chain brake and the sharpness of the chain before every use to ensure that the necessary level of safety in the event of a kickback is maintained. Removing safety accessories, incorrect maintenance or when using unsuitable guide bars or chains may, in the event of kickback, result in serious injuries.

Cutting trees



- Decide about the direction in which the tree will fall, respecting the wind direction, incline angle of the tree and location of the branches, and consider all other factors before cutting.
- The area around the tree must be clear, without obstacles, and must enable a stable stance. The escape route must be passable.
- Cut a wedge into one third of the tree's diameter on the side to which the tree should fall. (see fig. Cutting trees, point 1)
- From the opposite direction perform a separation cut at a level above the wedge cut. (see fig. Cutting trees, point 2)
- The tree will fall in the direction towards the wedge cut. (see fig. Cutting trees, point 3)

⚠ ATTENTION!

When cutting trees, inform other people in the area about the potential danger. Cutting trees requires experience and we do not recommend performing this task without the necessary experience.

Cutting logs

⚠ ATTENTION!

Always maintain a stable stance. Do not step on logs.


⚠ ATTENTION!

Before starting work, check that all components are in their place and that all nuts and bolts are tightened.

- The log being cut may roll away. Especially when cutting on a slope, always stand above the log being cut.
- Prevent kickback of the saw by following the instructions in chapter “Safety instructions”.
- Before starting work, assess the direction of the force causing the cut trunk to bend. The final cut needs to always be done from the opposite side of where the bending force is acting to prevent the guide bar from being clamped inside the cut.
- Only carry the chain saw with the motor turned off and the guide bar protected by the protective cover.


Log lying on the ground

- Cut it halfway through, then roll it over and complete the cut from the other side.




Log above the ground

- In part “A” make a cut from below to a third of the log and then complete the cut from above. In part “B” make a cut from above to a third of the log and then complete the cut from below.



Removing a fallen tree

- First find out to which side the branch is bent. Then make the initial cut from the side of the bend and then complete the cut from the opposite side.



⚠ ATTENTION!

A bent branch may spring up.


CLEANING AND MAINTENANCE

Cleaning the body of the chain saw

Keep the body of the chain saw clean. When cleaning, use a soft cloth dipped in a soap solution. Use this cloth to meticulously clean the body of the chain saw.

Maintaining the guide bar

- Most problems with the guide bar arise due to uneven wear.
Uneven wear occurs mainly as a result of an incorrectly sharpened chain or an incorrectly set depth gauge. When the guide bar is worn out unevenly, the guiding groove is widened (see Picture). The result is a rattling chain and rivets falling off.
The chain saw cannot be used for straight cuts. In such a case, replace the guide bar for a new one.
- Always check the condition of the guide bar before sharpening the chain. Using a worn out or damaged guide bar is very dangerous. Using a worn out or damaged guide bar will result in damage to the chain. Cutting with such a power tool will also be much more difficult and demanding.



Normal maintenance of the guide bar

- Remove the guide bar from the body of the chain saw.
- Regularly remove sawdust from the guide bar groove. For cleaning use a spatula or a wire.
- Clean oily grooves at the end of every work day.
- Replace the guide bar if:
 - it is bent or cracked
 - its groove is very damaged or worn out



Note: To replace the guide bar, follow the instruction contained in this user's manual. You will find the correct guide bar type in the technical specifications.

SHARPENING THE SAW CHAIN

Keep the saw chain sharp. Cutting will be significantly faster and most importantly safer. A blunt saw chain increases wear on the sprocket, guide bar, chain and motor. If you need to push on the saw and only sawdust with

a few splinters are produced then this means that the chain is blunt.

For this task, we recommend that you contact an authorised service centre

Equipment necessary for sharpening a saw chain

- Round file as per technical specifications
- Depth gauge
- File guide
- Vice
- Medium-size flat file

Sharpening the teeth on the chain

Use the file guide set at an angle of 30° (mark A, see figure).

- Set the saw chain tension to the correct level.
- Fasten the guide bar in a vice so that you have the chain in a stable position.



Note: Do not fasten the chain itself.

- Push the round file, inserted in the file guide, into the groove between the top plate and the depth gauge on the chain. The chain should be touching both the top plate as well as the depth gauge (see figure)



Note: File in the middle of the guide bar.



Note: In the figure you can see the position of the file guide and the direction for filing the teeth on the left side of the chain.

- Place the file guide at the required angle (mark A, see figure).

Check that the mark is at 30° on the file guide aligned with the centre of the guide bar. This will ensure that you will file at an angle of 30°.



- File the tooth in the direction from inside out (in direction B, see figure) until it is sharp. File only in this direction.

Note: Two to three passes of the file should be sufficient to sharpen the tooth.

Filing the depth gauge

As a result of sharpening the teeth on the chain, the depth gauge tolerance is reduced. After every second or third sharpening, it is necessary to adjust the depth gauge setting.

- Place the depth gauge adjustment jig (see fig., point 1) firmly on the top edge of two teeth. Make sure that the groove of the jig is in the groove of the depth gauge (see fig., point 2.)
- Use a medium-sized flat file (see fig., point 3).
File the depth gauge (see fig., point 4) to the level of the depth gauge adjustment jig.
- Remove the depth gauge adjustment jig. Using a flat file, round the front edge of the depth gauge (see figure).
When filing, adhere to the prescribed values (see fig., point 5).



Note: After the chain has been sharpened by hand several times, have the saw chain sharpened at an authorised service centre or sharpen it on a special sharpening machine. This will renew the even sharpness of all teeth.

REPLACING THE SAW CHAIN

 **ATTENTION!**

When replacing the saw chain, do not clamp the chain saw or the guide bar in a vice

Always replace the chain if the teeth are excessively worn out and they cannot be sharpened or if the chain snaps. Use only an original spare chain according to the specifications in this user's manual. When replacing the saw chain, always also replace the cogged wheel of the sprocket. This will ensure the correct position of the chain during movement. (Note: You will find the specifications of the correct chain type and the cogged wheel in the technical specifications.)

- Loosen and remove the bar guide bolt.
- Remove the sprocket cover.
- Remove the saw chain.
- Wind the new chain around the cogged wheel, then along the top groove of the guide bar and around the guide bar nose.



Note: Check that the saw teeth are facing in the correct direction.

Put on the chain so that the teeth on the top side of the guide bar are facing towards the guide bar nose (see figure).

- Before placing the sprocket cover into position, check that the chain tensioning pin is inserted into the adjustment hole on the guide bar.
- Put the sprocket cover back on to the body of the chain saw.
- Fasten the sprocket cover using the guide bar bolt.



ATTENTION!

Only tighten the bolt by hand.

- Adjust the tension of the saw chain.
- Tighten the guide bar bolt.

ATTENTION!

Check that you have not placed the saw chain on the guide bar in the opposite direction.
Otherwise, the chain saw will exhibit excessive vibrations and will not cut.

STORAGE

If you will not use the chain saw for longer than 30 days, proceed as follows.

- Drain the oil tank.
- Remove and clean out the guide bar and chain. Submerge the guide bar and chain into a kerosene-based or soap cleaning solution.
- Then dry the guide bar and the chain.
- Put the chain into a container filled with oil. This will prevent it from corroding.
- Gently coat the guide bar with oil.
- Wipe the body of the chain saw with a cloth. When cleaning, use a soft cloth dipped in a soap solution.
- Store the chain saw
 - In higher shelves or in locked areas out of children's reach
 - Store in a dry location

TECHNICAL SPECIFICATIONS

Power input	1800 W
Voltage/frequency	230 V – 240 V / 50 Hz
Chain pitch	3/8"
Guiding groove width	1.3 mm
Number of chain links	52 links
Length of the guide bar	35 cm
File diameter	4 mm
Cutting speed	12 m/s
Oil tank capacity	220 ml
Weight (with guide bar and chain)	5.0 kg
Level of acoustic power LWA	measured 112 dB(A)

User's manual in original language.

DISPOSAL

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of used packaging material at a site designated for waste in your municipality.



The machine and its accessories are manufactured from various materials, e.g. metal and plastic. Take damaged parts to a recycling centre. Inquire at the relevant government department. Changes in the text, design and technical specifications may be made without prior notice and we reserve the right to make these changes.

Conditions of guarantee


This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end-user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation...

This warranty is void especially if apply as follows:

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.
- The product was damaged by dirt, accident of force majeure (natural disaster, fire, flood, ...).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall...).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes,...).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product can not be identified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

FAST ČR, a. s.
Černokostelecká 1621 CZ 251 01 Říčany Česká republika
Tel.: +420/ 323 204 120
Fax: +420/ 323 204 121
servis.praha@fastcr.cz
www.fastcr.cz

Documents / Resources

 <p>FZP 2000-E</p>	<p>FIELDMANN FZP 2000-E Chainsaws [pdf] User Guide FZP 2000-E Chainsaws, FZP 2000-E, Chainsaws</p>
---	--

References

- [ARCONET Sieæ Serwisowa](#)
- [FAST ČR, a.s. | Úvod](#)
- [FAST ÄÆR | Honlap](#)
- [FAST PLUS | Úvod](#)