



FleetSharp Long-Term Asset Tracker Devices User Guide

[Home](#) » [FleetSharp](#) » FleetSharp Long-Term Asset Tracker Devices User Guide 



Long-Term
Asset Tracker
Quick Start Guide



Contents

- [1 Welcome to FleetSharp!](#)
- [2 Account Activation](#)
- [3 Device Activation](#)
- [4 Installing Your Battery-Powered](#)
- [5 Install Positioning Matters](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Welcome to FleetSharp!

This simple step-by-step guide will walk you through activating your account and installing your GPS tracker. You'll also find easy instructions to customize your Customer Portal for tracking vehicles and equipment, monitor reports, set alerts, and much more. Let's get started!

Account Activation

1. Open your web browser (Chrome is recommended) and go to: <https://activate.fleetsharp.com>
2. You will be directed to the Activation Page where you will finish your account registration. Fill out the following information:
 - Activation Code: You can enter either the Activation Code found on your device OR your Billing Account Number (BAN) provided in your confirmation email.
 - Email Address: Please use the email address you provided when completing the order.
 - Create/Confirm Your Password: Make it strong and secure!
 - Read through our Terms & Conditions and then click the radio box to agree before clicking "Next".

New Customers

Fill out the following to complete your registration:

Activation Code* Tracker Purpose*

Email Address*

Create Your Password*

Confirm Password*

☐ I agree to the [Terms and Conditions*](#) CONTINUE

Already a Customer?

Simply log in and we'll walk you through the process of adding your new units.

Email Address*

Your Password*

FORGOT YOUR PASSWORD? SIGN IN

Device Activation

1. Welcome to your portal!
 - If you entered in your activation code on the previous screen it will auto populate here.
 - If you entered your Billing Account Number (BAN), you will need to enter the activation code shown on your device here.

New Tracker Activation

What would you like to activate?

Tracker

6-digit activation code on the sticker or card

Camera

11-digit activation code on the screen or box

Activation Code

A 7 R — Q 2 S

CONTINUE

2. Name your tracker based on the naming convention you use to manage your vehicles.

- Some common ways to name your vehicle: Blue Truck, Van ##, Sophie's Car, Ford F150, Tractor ###, etc.

Name Your Tracker

Give your tracker a name so that it is easily identifiable. It can be anything, such as a driver's name, a type of vehicle, or a fleet ID.

First Name **Last Name**

Scott

BACK **CONTINUE**

3. Enter in any optional information you would like to add for your tracker.

- Tip! If you are adding trackers into multiple groups, complete Group Setup before activating the remainder of your devices.

New Tracker Activation

Tracker Details (Optional)

You may specify the tracker's group, VIN, odometer, camera, and any notes about the vehicle.

Group (optional)

Southern Illinois

VIN (optional) ? **Odometer (optional) ?** **Camera (optional) ?**

1GNDT13S932400716 67,418 None

Notes (optional)

BACK **CONTINUE**

4. Congratulations! You have now set up your first device and your portal has been activated for use. From here, you can either choose to Activate More Trackers or Complete the process and begin using your system.

Installing Your Battery-Powered

Long Term Asset Tracker

The ATLT device will ship with an activated data plan.

Insert the batteries where there is a clear view to the sky so that when the device recognizes power, it has a strong cell signal to successfully report in. Do not install inside of a building or places where there isn't a strong cell signal.

If your device does not check in within 30 minutes of battery installation, remove the batteries, wait 30 seconds and then re-insert.

1. Install The Included Batteries

It is very important to use 1.5V Lithium, or 3.6V Lithium thionyl chloride (LTC) AA batteries. LTC batteries not only offer a longer life, but can withstand higher temperatures. We do not recommend the use of normal alkaline batteries, which will only power the ATLT for a few weeks of operation.


INSTALL THE BATTERIES CAREFULLY. The tracker does not have reverse voltage protection, so installing batteries backwards can damage your device. The springs are the negative terminals.

Once the batteries are inserted, the internal LED will come on and flash.

2. Attach Your Tracker

The long term asset tracker can be attached to your equipment with magnets (sold separately) or with #10 (5mm) screws (not included). If possible, choose a mounting point that will give the top of the device a clear line to the sky, and one that will not result in elevated temperatures. Once installed and activated, your tracker will check in every 12 hours.




Install Positioning Matters



Not Intended For Use:

- Indoors
- Inside of metal casings
- Underground
- In remote, "no cell coverage" areas


Performance and results will vary if used in the above environments.

	Strong signal: Installed with clear line to sky
	Weak signal: Installed vertically
	Limited signal: Installed under asset



Account and Device Activation
If you need help or have any questions,
contact us at 1-844-498-9450 or
support@fleetsharp.com

Documents / Resources

	<p>FleetSharp Long-Term Asset Tracker Devices [pdf] User Guide Long-Term, Long-Term Asset Tracker Devices, Asset Tracker Devices, Tracker Devices</p>
--	--

References

- [🌐 Activate Your Devices](#)

Manuals+.