



fullwat PDA3000 Series Power DC AC Inverter Instructions

[Home](#) » [FULLWAT](#) » fullwat PDA3000 Series Power DC AC Inverter Instructions 



PDA1500-STATION / PDA3000-STATION series


pure sine wave



Power DC-AC Inverter
Multi-function INVERTER/CHARGER:
inverter + MPPT solar charger + battery charger

Contents

1 INTRODUCTION

2 FEATURES

3 BASIC SYSTEM ARCHITECTURE

4 PRODUCT OVERVIEW

5 INSTALLATION

6 OPERATION

7 SPECIFICATIONS

8 TROUBLE SHOOTING

9 APPENDIX: Approximate Back-up Time Table

10 Documents / Resources

10.1 References

11 Related Posts

INTRODUCTION

This is a multifunction inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterrupted power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

FEATURES

- Pure sine wave inverter
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting.
- Compatible to mains voltage or generator power.
- Auto restart while AC is recovering.
- Overload Over temperature/ short circuit protection.
- Smart battery charger design for optimized battery performance.
- Cold start function.
- MPPT mode regulation charger

BASIC SYSTEM ARCHITECTURE

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system

- Generator or Utility.
- PV modules (option).

Consult with your system integrator for other possible system architectures depending on your requirements. This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as tube light, fan, refrigerator and air conditioner.





Fig. 1 - Hybrid power system

PRODUCT OVERVIEW



Indication

1. AC Input
2. AC Output
3. Circuit breaker
4. Safety (Earth) ground
5. Battery positive
6. Battery negative
7. PV Input
8. ON/OFF
9. RS232 communication

INSTALLATION


5.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- The unit x 1
- User manual x 1
- Communication cable x 1
- Software CD x 1

5.2 Preparation

Before connecting allwings, please fake off batiom cover by removing two screws s shown below.



5.3 Mounting the unit

Consider the following points before seleciing where fo install


- Do not mount fhe inverter on flammable constuction materials
- Mount on a sofd surface.
- Install this inverter t eye level in order fo allow the LCD display fobe read t all times.
- For proper air citculafion to dissipate heaf, alow a clearance of appiox. 20 om fo the side and approx. 50 cm above and below the unt
- The ambient femperaure should be befwsen 0°C and 55°C fo ensure opiimal operation.
- The recommended installation posifion is fo be adhered fo the: wall vertically
- Be sure fo keep othet abjects and sufaces s shown in he diagram to guarantee sufficient heat dissipation and fo have enough space for removing wires



SUITABLE FOR MOUNTING ON CONCRETE OR NON-COMBUSTIBLE SURFACE ONLY.

Insiall the unit by screwing fhee screws.

It's recommended fo use M4 or M5.



5.4 Battery connection

Caution:


For safety operation and regulation compliance, it's requested to install separate DC over-current protector or disconnect device between battery and inverter.

It may not be requested to have a disconnect device in some applications, however, it is requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

Ring terminal





Recommended battery cable and terminal size:

Model	Input voltage	Typical amperage	Battery capacity	Wire size	Ring terminal			Torque value
					Cable mm2	Dimensions		
						D (mm) L (mm)		
PDA3000-STATION	24V	100A	100AH 200AH	2*8AWG	14	6.4	29.2	2-3 Nm
PDA1500-STATION	12V			1 *4AWG	22	6.4	33.2	
	24V	50A	100AH	1 *6AWG	14	6.4	29.2	
				2*10AWG	8	6.4	23.8	

Please follow below steps to implement battery connection:


1. Assemble battery using terminal based on recommended battery cable and terminal size.
2. PDA1500-STATION model supports 12VDC or 24VDC system. Connect all battery packs as below chart. It is suggested to connect at least **100Ah**.



Note: Please only use sealed lead acid battery or sealed GEL AGM lead-acid battery.

3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2-3 Nm. Make sure polarity of both the battery and the inverter/charge is correctly

connected and iing feminals are fightly screwed to the battery temminals.



Warning: Shock Hazard

Installation must be performed with care due fo high battery voliage in series.



Caution!! Do not place anything between the flat part of the inverter terminal and the fing tenminal. Other wise, overheating may ocout

Caution!! Do not apply anti-oxidant substance on the tenminals before feminals are connected fightly.

Caution!! Bsfore making the findl DC connection or closing DC breaker/disconnector, be sure postive (+) must be connected fo pasilive (+) and negaive (-) must be connected fo negaive [-].

5.5 AC Input/Output connection

'Caution!! Before connecting fo AC input power source, please install a separate AC breaker between inverter and AC input power sourc. This will ensure the inverer can be securely disconnected duing maintenance and fully protected ffrom over curent of AC input. The recommended spec of AC breaker is 104 for PDAT500-STATION, 32 Afor PDA3000-STATION.

Caution!! There are two teminal blocks with IN* and *OUT" markings. Please do NOT mis-connect input and ouput connectors.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation fo use appropriate cable for AC input connection. Toreduce fisk of injury, please use he proper recommended cable size as below.

Suggested cable requirement for AC wires.

Model	Gauge	Torque value
PDA1500-STATION	14AWG	0.5~0.6 Nm
PDA3000-STATION	12AWG	1.2~1.6Nm

Please follow below steps fo implement AC input/output connection:

1. Before making AC inpui/ouput connection, be sure fo open DC profector or dsconnector first.
2. Remmove insulation skeeve 10mm for sk conductors. And shoren phase L and neutral conductor N 3mm.
3. Insert AC input wires according to polartiiies indicated on ferminal block and fighten the ferminal screws.

Be sure fo connect PE protective conductor () first.




→ Gound (yelow-green}

L →

→ UNE (brown or black}

N → Neutal (blue)



Warning: Shock

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.


Be sure to connect PE protective conductor (⏏) first.



→ Ground yellow-green

L → LINE (brown or black)

N → Neutal (blue)



5. Make sure the wires are securely connected.

Caution: Important!!

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause a safety hazard or short circuit when these inverters are worked in parallel operation.

Caution:

Appliances such as air conditioner are required at least 2~3 minutes of restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in a short time, it may cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter/charger will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

5.6.PV CONNECTION

PV Module selection for MPPT mode.


Inverter model	PDAI500-STATION		PDA3000-STATION
Rated out power	12V	24V	24V
Charging current (PWM)	40A max.		
Max PV Array open circuit voltage	102		
MPPT operating voltage range:	17-80V	30-80VDC	


Take 300Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed below table.

Inverter model		PDA1 500-STATION		PDA3000-STATION
Rated out power	300W	12V	24V	24V
Maximum power (Pmax)	32175A	2 pieces in serial	2 pieces in serial and 2 sets in parallel	
Max. Power current Impp (A)	8.93A			
Open circuit voltage Voc (V)	39184A			
Short circuit current Isc (A)	9.78A			

Please follow below steps to implement PV module connection:


1. Remove insulation sleeve 10mm for positive and negative conductors.
2. Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector, Connect negative pole [of connection cable to negative pole (-) of PV input connector.
3. Make sure the wires are securely connected.





5.7.Final Assembly

After connecting all wirings, please put bottom cover back by screwing two screws as shown below.




5.8.Communication connection

Please use supplied communication cable to connect to inverter and PC. Insert bundled CD into a computer and follow on-screen instruction to install the monitoring software. For the detailed software operation, please check user manual of software inside of CD.

5.9 Dry contact signal


There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit status	Condition			Dry contact port:	
					
				NC & C	NO & C
Power OFF	Unit is off and no output is powered.			Close	Open
Power ON	Output is powered from Utility			Close	Open
	Output is powered from Battery or Solar	Program 01 set as Utility	Battery voltage < LowDC warning voltage	Open	Close
			Battery voltage > Setting value in Program 13 or battery charging reaches floating stage:	Close	Open
		Program 01 is set as SBU or solar first	Battery voltage < Setting value in Program 12	Open	Close
			Battery voltage > Setting value in Program 13 or battery charging reaches floating stage:	Close	Open

OPERATION


6.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well simply press ON/OFF switch (located on the bottom of the case) to turn on the unit.



6.2 Operation and Display panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LD display, indicating the operating status and input/output power information.




LED Indicator

Led indicator			Messages
	Green	Solid ON*	Output is powered by utility in Line mode.
		Floshing	Output is powered by battery or PV in battery mode.
	Green	Solid ON	Battery is fully charged.
		Floshing	Battery is charging.
	Red	Solid ON	Fault occurs in the inverter.
		Floshing	Warning condition occurs in the inverter.



Function KEVs





Function Key	Description
ESC	To exit setting mode.
UP	To go to previous selection.
DOWN	To go to next selection.
ENTER	To confirm the selection in setting mode or enter setting mode.









6.3 LCD Display Icons















Icon	Function description
Input source information	
AC	Indicates the AC input.
PV	Indicates the PV input.
INPUTBATT 	Indicate input voltage, input frequency, PV voltage, battery voltage and charger current.
Configuration program and fault information	
	Indicates the setting programs.
	Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code.
Output information	

	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.	
Battey information		
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.	
In AC mode, it will present battery charging status.		
Status	Battery voltage	LCD Display
Constant current mode / Constant voltage mode	<2V/cell	4 bars will flash in turns.
	2 ~ 2.083V/cell	Bottom bar will be on and the other three bars will flash in turns.
	2.083 ~ 2.167V/cell	Bottom two bars will be on and the other two bars will flash in turns.
	2.167V/cell	Bottom three bars will be on and the top bar will flash.
Floating mode. Batteries are fully charged.		4 bars will be on.

In battery mode, it will present battery capacity.		
Load percentage	Battery voltage	LCD Display
Load>50%	<1.717V/cell	
	1.717V/cell ~ 1.8V/cell	
	1.8 ~ 1.883V /cell	
	>1.883 V /cell	











50%>Load >20%	<1.817V/cell	
	1.817V/cell ~ 1.9V/cell	
	1.9 ~ 1.983V/cell	
	>1.983	
Load<20%	<1.867V /cell	
	1.867V/cell ~ 1.95V/cell	
	1.95 ~ 2.033V/cell	
	>2.033	

Load information				
		Indicates overload.		
	Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%.			
	0%~25%	25%~50%	50%~75%	75%~100%
				
Mode operation information				
		Indicates unit connects to the mains.		
		Indicates unit connects to the PV panel.		
		Indicates load is supplied by utility power.		
		Indicates the utility charger circuit is working.		
		Indicates the DC/AC inverter circuit is working.		
Mute operation				
		Indicates unit alarm is disabled.		

6.4 LCD Settings

After pressing and holding ENTER button far 3 seconds, the unit will enter seffing mode. Press “UP” or “DOWN” button to select seffing programs. And hen, press “ENTER” button fo confirm the selection or ESC bution to ext.

Setting Programs		
Program	Description	Selectable option

00	Exit setting mode	Escape 	
01	Output source priority: To configure load power source priority	Solar first 	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when any one condition happens: – Solar energy is not available – Battery voltage drops to low-level warning voltage or the setting point in program 12.
		Utility first (default) 	Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.
		SBU priority 	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.
02	Maximum charging current: To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current)	10A (Only available for PDA1500-STATION (12V) model) 	20A 
		30A 	40A 
		50A 	60A 

		70A 02 70 A	80A (Only for PDA3000-STATION model) 02 80 A
--	--	----------------	---

Setting Programs			
Program	Description	Selectable option	
03	AC input voltage range	Appliances (default) 03 APL	If selected, acceptable AC input voltage range will be within 90-280VAC.
		UPS 03 UPS	If selected, acceptable AC input voltage range will be within 170-280VAC.
04	Power saving mode enable/disable	Saving mode disable (default) 04 SDS	If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.
		Saving mode enable 04 SEN	If enabled, the output of inverter will be off when connected load is pretty low or not detected.
05	Battery type	AGM (default) 05 AGN	Flooded 05 FLd
		User-Defined 05 USE	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.
06	Auto restart when overload occurs	Restart disable (default) 06 LId	Restart enable 06 LIE







07	Auto restart when over temperature occurs	Restart disable (default) 	Restart enable
09	Output frequency	50Hz (default) 	60Hz
11	Maximum utility charging current. Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging current from program 02 for utility charger.	Available options in PDA1500-STATION (12V) model:	
		10A 	20A (default)
		Available options in PDA1500-STATION (24V) / PDA3000-STATION model:	
		20A 	30A (default)

Setting Programs		
Program	Description	Selectable option
		Available options in PDA1500-STATION (12V) model:

Setting voltage point back to utility source when selecting “SBU priority” or “Solar first” in program 01.

<div>11.0V</div> <div><div>12</div><div>BATT</div><div>11.0^v</div></div>	<div>11.3V</div> <div><div>12</div><div>BATT</div><div>11.3^v</div></div>
<div>11.5V (default)</div> <div><div>12</div><div>BATT</div><div>11.5^v</div></div>	<div>11.8V</div> <div><div>12</div><div>BATT</div><div>11.8^v</div></div>
<div>12.0V</div> <div><div>12</div><div>BATT</div><div>12.0^v</div></div>	<div>12.3V</div> <div><div>12</div><div>BATT</div><div>12.3^v</div></div>
<div>12.5V</div> <div><div>12</div><div>BATT</div><div>12.5^v</div></div>	<div>12.8V</div> <div><div>12</div><div>BATT</div><div>12.8^v</div></div>
Available options in PDA1500-STATION (24V) / PDA3000-STATION model:	



		<div>22.0V</div> <div>12 ^{BATT} 22.0_v</div>	<div>22.5V</div> <div>12 ^{BATT} 22.5_v</div>
		<div>23.0V (default)</div> <div>12 ^{BATT} 23.0_v</div>	<div>23.5V</div> <div>12 ^{BATT} 23.5_v</div>
		<div>24.0V</div> <div>12 ^{BATT} 24.0_v</div>	<div>24.5V</div> <div>12 ^{BATT} 24.5_v</div>
		<div>25.0V</div> <div>12 ^{BATT} 25.0_v</div>	<div>25.5V</div> <div>12 ^{BATT} 25.5_v</div>
13	Setting voltage point back to battery mode when selecting “SBU priority” or “Solar first” in program 01.	<div>Available options in PDA1500-STATION (12V) model:</div> <div>Battery fully charged</div> <div>13 ^{BATT} FUL</div>	<div>12.0V</div> <div>13 ^{BATT} 12.0_v</div>
		<div>12.3V</div> <div>13 ^{BATT} 12.3_v</div>	<div>12.5V</div> <div>13 ^{BATT} 12.5_v</div>
		<div>12.8V</div> <div>13 ^{BATT} 12.8_v</div>	<div>13.0V</div> <div>13 ^{BATT} 13.0_v</div>

Program	Description	Selectable option	
13	Setting voltage point back to battery mode when selecting “SBU priority” or “Solar first” in program 01.	13.3V 	13.5V (default) 
		13.8V 	14.0V 
		14.3V 	14.5V 
		Available options in PDA1500-STATION (24V) / PDA3000-STATION model:	









		<div>Battery fully charged</div> <div><div>13</div><div><div>BATT</div>FUL</div></div>	<div>24V</div> <div><div>13</div><div><div>BATT</div>24.0^v</div></div>
		<div>24.5V</div> <div><div>13</div><div><div>BATT</div>24.5^v</div></div>	<div>25V</div> <div><div>13</div><div><div>BATT</div>25.0^v</div></div>
		<div>25.5V</div> <div><div>13</div><div><div>BATT</div>25.5^v</div></div>	<div>25V</div> <div><div>13</div><div><div>BATT</div>26.0^v</div></div>
		<div>26.5V</div> <div><div>13</div><div><div>BATT</div>26.5^v</div></div>	<div>27V (default)</div> <div><div>13</div><div><div>BATT</div>27.0^v</div></div>
		<div>27.5V</div> <div><div>13</div><div><div>BATT</div>27.5^v</div></div>	<div>28V</div> <div><div>13</div><div><div>BATT</div>28.0^v</div></div>
		<div>28.5V</div> <div><div>13</div><div><div>BATT</div>28.5^v</div></div>	<div>28V</div> <div><div>13</div><div><div>BATT</div>29.0^v</div></div>

Setting Programs		
Program	Description	Selectable option
16	Charger source priority: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:
		<div>Solar first</div> <div>16 C50</div> <div>Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.</div>
		<div>Utility first</div> <div>16 CUE</div> <div>Utility will charge battery as first priority. Solar energy will charge battery only when utility power is not available.</div>
		<div>Solar and Utility</div> <div>16 SNU</div> <div>Solar energy and utility will charge battery at the same time.</div>
		<div>Only Solar</div> <div>16 050</div> <div>Solar energy will be the only charger source no matter utility is available or not.</div>
		If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.
18	Alarm control	Alarm on (default)
19	Auto return to default display screen	Alarm off
20	Backlight control	<div>Return to default display screen (default)</div> <div>18 60N</div> <div>19 60F</div>
22	Beeps while primary source is interrupted	<div>If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage / output voltage) after no button is pressed for 1 minute.</div> <div>Stay at latest screen</div> <div>19 ESP</div> <div>19 LEP</div>
		<div>Backlight on (default)</div> <div>20 LON</div> <div>20 LOF</div>
		<div>Alarm on (default)</div> <div>22 AON</div> <div>22 AOF</div>
		<div>Backlight off</div> <div>20 LON</div> <div>20 LOF</div>

Setting Programs		
Program	Description	Selectable option
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	<div>Bypass disable (default)</div> <div>23 64d</div> <div>Bypass enable</div> <div>23 64E</div>
25	Record fault code	<div>Record enable</div> <div>25 FEN</div> <div>Record disable (default)</div> <div>25 FdS</div>
26	Buck charging voltage (CV voltage)	<div>PDA1500-STATION (12V) model default setting: 14.1V</div> <div>CV 26 14.1^{BATT}v</div> <hr/> <div>PDA1500-STATION (24V) / PDA3000-STATION model default setting: 28.2V</div> <div>CV 26 28.2^{BATT}v</div> <hr/> <div>If self-defined is selected in program 5, this program can be set up. Setting range is from 12.0V to 14.6V for PDA1500-STATION (12V) model, 24.0V to 29.2V for PDA3000-STATION model. Increment of each click is 0.1V.</div>
27	Floating charging voltage	<div>PDA1500-STATION (12V) model default setting: 13.5V</div> <div>FLV 27 13.5^{BATT}v</div> <hr/> <div>PDA1500-STATION (24V) / PDA3000-STATION model default setting: 27.0V</div> <div>FLV 27 27.0^{BATT}v</div> <hr/> <div>If self-defined is selected in program 5, this program can be set up. Setting range is from 12.0V to 14.6V for PDA1500-STATION (12V) model, 24.0V to 29.2V for PDA1500-STATION (24V) / PDA3000-STATION model. Increment of each click is 0.1V.</div>

29	Low DC cut-off voltage	<p>PDA1500-STATION (12V) model default setting: 10.5V</p> 
		<p>PDA1500-STATION (24V) / PDA3000-STATION model default setting: 21.0V</p> 
		<p>If self-defined is selected in program 5, this program can be set up. Setting range is from 10.0V to 12.0V for PDA1500-STATION (12V) model, 20.0V to 24.0V for PDA1500-STATION (24V) / PDA3000-STATION model. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.</p>

Setting Programs			
Program	Description	Selectable option	
33	Battery equalization	<div><div><div>33</div><div>EEN</div></div><div><div>33</div><div>EdS</div></div></div>	
		If “Flooded” or “User-Defined” is selected in program 05, this program can be set up.	
34	Battery equalization voltage	<div>PDA1500-STATION (12V) model default setting: 14.6V</div> <div><div><div>EV</div><div>34</div></div><div><div>BATT</div><div>14.6</div><div>v</div></div></div>	
		Setting range is from 12.5V to 15V. Increment of each click is 0.1V.	
		<div>PDA1500-STATION (24V) / PDA3000-STATION model default setting: 29.2V</div> <div><div><div>EV</div><div>34</div></div><div><div>BATT</div><div>29.2</div><div>v</div></div></div>	
		Setting range is from 25.0V to 30V. Increment of each click is 0.1V.	
35	Battery equalized time		Setting range is from 5min to 900min. Increment of each click is 5min.

36	Battery equalized timeout	60min (default) 	Setting range is from 5min to 90 min. Increment of each click is 5 min.
37	Equalization interval	120min (default) 	Setting range is from 0 to 90 days. Increment of each click is 1 day
39	Equalization activated immediately	30 days (default)  If Enable  If "e f" activated equalization time arrives based on program 35 setting. At this time,  will not be shown in LCD main page.	Disable (default)  ed in program 30, this program can be used in this program, it's to activate battery. If LCD main page will shows  . If equalization function until next activated equalization time arrives based on program 35 setting. At this time,  will not be shown in LCD main page.


6.5 Display Settings

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, charging current, battery voltage, output voltage, output frequency, load percentage load in Watt, load in VA load in Watt, DC discharging current, main CPU Version and second CPU Version.


Selectable information	LCD display
Input voltage/Output voltage (Default Display Screen)	
Input frequency	
PV voltage	
Charging current	
Battery voltage/DC discharging current	

Output frequency


Input Voltage= 230V, output voltage=230V




Input frequency= 50Hz




PV voltage= 60V




Charging current= 50A



Battery voltage= 25.5V, discharging current= 1A




Output frequency= 50Hz




--	--

Selectable information	LCD display
Load percentage	
Load in VA	
Load in Watt	


Load percent=70%




When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.




When load is larger than 1kVA ($\geq 1\text{kVA}$), load in VA will present x.xkVA like below chart.




When load is lower than 1 kW, load in W will present xxxW like below chart.










When load is larger than 1kW(≥ 1 kW), load in W will present x.xkW like below chart.



Main CPU version 00014.04.









Main CPU version checking

Operation mode	Description	LCD display
<p>Standby mode / Power saving mode</p> <p>Note:</p> <p>* Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output.</p> <p>* Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.</p>	<p>No output is supplied by the unit but it still can charge batteries.</p>	<p>Charging by utility and PV energy.</p>  <hr/> <p>Charging by utility.</p>  <hr/>
<p>Fault mode Note:</p> <p>* Fault mode: Errors are caused</p>		<p>Charging by PV energy.</p>  <hr/> <p>No charging.</p>  <hr/> <p>Charging by utility and PV energy.</p>  <hr/> <p>Charging by utility.</p>  <hr/> <p>Charging by PV energy.</p> 

by inside circuit error or external reasons such as over temperature, output short circuited and so on.

PV energy and utility can charge batteries.

Operation mode	Description	LCD display
Fault mode Note: * Fault mode: Errors are caused by inside circuit error or external reasons such as over temperature, output short circuited and so on.	PV energy and utility can charge batteries.	No charging 
	Utility can power loads when the unit starts up with out battery.	
Line Mode	The unit will provide output power from the mains. It will also charge the battery at line mode.	Power from utility 
Battery mode	The unit will provide output power from battery and PV power.	Charging by utility and PV energy. 
		Charging by utility 
		Power from battery and PV energy. 
		Power from battery only. 

Battery equalization description

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like sulfation, a condition where acid concentration is lower at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it is recommended to equalize battery periodically."


How to apply equalization function

You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:

1. Setting equalization interval in program 35.
2. Active equalization immediately in program 36.


When to equalize

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage rises to battery equalization voltage. Then, constant voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.













However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.













6.7 Fault reference code

Fault code	Fault Event	Icon on
01	Fan is locked when inverter is OFF.	
02	Over temperature.	
03	Battery voltage is tooo high.	
04	Battery voltage is too low.	
05	Output short circuited ar over temperature is detected by internal conv erter components.	
06	Output voltage is abnormal.	
07	Overload time out.	
08	Bus voltage is tooo high.	
09	Bus soft start failed.	

		
		
		
		
		
		
11	Main relay failed.	
		
		
		

6.8 Warning indicator flashing

Warning code	Warning event	Audible alarm	Icon flashing
01	Fan is locked when inverter is ON .	Beep three times every second.	
03	Battery is over-charged.	Beep once every second.	
04	Low battery.	Beep once every second.	
07	Overload.	Beep once every 0.5 second.	
10	Output power derating.	Beep twice every 3 seconds.	
12	Solar charger stops due to low battery.		
13	Solar charger stops due to high P V voltage.		
14	Solar charger stops due to overload.		
	Battery equalization		

SPECIFICATIONS

Table 1- Line mode specifications


Inverter model	PDA1500-STATION		PDA3000-STATION
Input voltage	12V	24V	24V
Input voltage waveform	Sinusoidal (utility or generator)		
Nominal input voltage	230Vac		
Low loss voltage	170Vac \pm 7V (UPS); 90Vac \pm 7V (Appliances)		
Low loss return voltage	180Vac \pm 7V (UPS); 100Vac \pm 7V (Appliances)		
High loss voltage	280Vac \pm 7V		
High loss return voltage	270Vac \pm 7V		
Max AC input voltage	300Vac		
Nominal input frequency	50Hz / 60Hz (Auto detection)		
Low loss frequency	40 \pm 1Hz		
Low loss return frequency	42 \pm 1Hz		
High loss frequency	65 \pm 1Hz		
High loss return frequency	63 \pm 1Hz		
Output short circuit protection	Circuit Breaker		
Efficiency (Line mode)	95% (Rated R load, battery full charged)		
Transfer time	10ms typical (UPS); 20ms typical (Appliances)		
Output power derating: When AC input voltage drops to 170 V, the output power will be derated.			

Table 2 – Inverter mode specifications

Inverter model	PDA1500-STATION		PDA3000-STATION
Nominal DC input voltage	12V	24V	24V
Rated output power	1200W		2400W
Output voltage waveform	Pure sine wave		
Output voltage regulation	230Vac±5%		
Output frequency	50Hz		
Peak efficiency	95%		
Overload protection	5s@≥c150% load; 10s@110%~150% load		
Surge capacity	2*rated power for 5 seconds		
Cold start voltage	11.5Vdc	23.0Vdc	
Low DC Warning voltage			
@load<20%	11.0Vdc	22.0Vdc	
@20%≤load<50%	10.7Vdc	21.4Vdc	
@load≥50%	10.1Vdc	20.2Vdc	
Low DC Warning return voltage			
@load<20%	10.5Vdc	21.0Vdc	
@20%≤load<50%	10.2Vdc	20.4Vdc	
@load≥50%	9.6Vdc	19.2Vdc	
High DC cut-off voltage	15.5Vdc	31.0Vdc	
No load power consumption	<15W		<20W
Saving mode power consumption	<5W		<10W

Table 3 – Inverter mode specifications


Inverter model		PDA1500-STATION		PDA3000-STATION
Nominal DC input voltage		12V	24V	24V
Charging algorithm		3-step		
AC Charging current		10/20Amp	20/30Amp (@VI/P=230Vac)	
Bulk charging voltage	Flooded battery	14.6	29.2	
	AGM / Gel battery	14.1	28.2	
Floating charging voltage		13.5Vdc	27Vdc	
Charging curve				

Table 4 – General specifications

Inverter model	PDA1500-STATION		PDA3000-STATION
Rated out power	12V	24V	24V
Max. current	40A max.		
Max. PV array open circuit voltage	102V		
MPPT operating voltage range	17-80V	30-80V	
Max. charging current (utility charging + solar charging)	60A	70A	

TROUBLE SHOOTING

Problem	LCD / LED / Buzzer	Explanation / Possible cause	What to do
---------	--------------------	------------------------------	------------

Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91V/Cell) .	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. (<1.4V/Cell) 2. Battery polarity is connected reversed.	1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped.	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator).	1. Check if AC wires are too thin and/or too long. 2 Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS → Appliance)
	Green LED is flashing.	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing.	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07.	Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
	Fault code 05.	Output short circuited.	Check if wiring is connected well and remove abnormal load.
		Temperature of internal converter component is over 120°C.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 02.	Internal temperature of inverter component is over 100°C.	
	Fault code 03.	Battery is over-charged.	Return to repair center.
		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
	Fault code 01.	Fan fault.	Replace the fan.
	Fault code 06.	Output abnormal (inverter voltage below than 190Vac or is higher than 260VAC).	1. Reduce the connected load. 2. Return to repair center.
	Fault code 08/09.	Internal components failed.	Return to repair center.

APPENDIX: Approximate Back-up Time Table

Model	Load (VA)	Backup Time @ 12Vdc 100Ah (min)	Backup Time @ 12Vdc 200Ah (min)
PDA1500-STATION (12V)	100	766	1610
	200	335	766
	300	198	503
	400	139	339
	500	1112	269
	600	95	227
	700	81	176
	800	62	140
	900	55	125
	1000	50	112
PDA1500-STATION (24V) PDA3000-STATION	300	449	1100
	600	222	525
	900	124	303
	1200	95	227
	1500	68	164
	1800	56	126
	2100	48	108
	2400	35	94
	2700	31	74
	3000	28	67


Note: Backup time depends on the quality of the battery, age of battery and type of battery. Specifications of batteries may vary depending on different manufacturers.



<http://fullwat.com/cargadores-baterias/>

Agente importador
A48.139.786
UKAISA.
Ribera de Elorrieta, 7C
48015 – Bilbao- SPAIN

Documents / Resources

 <p>fullwat professional powerEnergy</p> <p>PDA3000 SERIES / PDA3000 SERIES INVERTER PDA3000</p> <p>Power DC AC Inverter Multi-function INVERTER/CHARGER Inverter + MPPT solar charger + battery charger</p>	<p>fullwat PDA3000 Series Power DC AC Inverter [pdf] Instructions</p> <p>PDA3000 Series Power DC AC Inverter, PDA3000 Series, Power DC AC Inverter, AC Inverter, I nverter</p>
---	--

References

- [FULLWAT - Fabricante de iluminación led, conversores y acumuladores de energía](#)