

Global Cache FLC-RS Flex Link Relay and Sensor Cable



Global Cache FLC-RS Flex Link Relay and Sensor Cable User Guide


[Home](#) » [Global Cache](#) » Global Cache FLC-RS Flex Link Relay and Sensor Cable User Guide 

Contents

- [1 Global Cache FLC-RS Flex Link Relay and Sensor Cable](#)
- [2 Getting Started](#)
- [3 Relay Outputs](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)



Global Cache FLC-RS Flex Link Relay and Sensor Cable



Getting Started


Once the Flex is connected to the network (see Flex Quick Starts), plug the Flex Link Relay & Sensor cable (FLC-RS) into the Flex Link Port.

To configure the FLC-RS, right-click on the unit entry in iHelp and select Configure, or enter the Flex unit's IP address into a web browser to access the Flex Configuration page.



To access the settings, select the Flex Link Cable tab. Then select Relay & Sensor from the Change Flex Link cable field. The page will update and display the current saved configuration or default settings if the cable is not yet configured.

The setup webpage provides the basic configuration and control interface to demonstrate and test relay and sensor functionality.



Relay Outputs

The four Relay outputs on the left side of the cable can be configured as a variety of relay types for controlling a wide range of devices. To configure a relay, select the desired mode on the webpage using the Relay Type dropdown menus. Then install the hardware jumpers as indicated in the diagram and press Save Changes. Connect your device to the connector terminals as indicated (the webpage displays a conceptual diagram of the selected relay type). The relay outputs can now be controlled by using the Current State.

Max: 24V, 0.5A

Relay & Sensor Cable Configuration

Relay Type: SPDT

Jumper Settings:

Current State: On 1

Relay Type: SPST, SPST

Jumper Settings:

Current State: Off Off

Sensors

	1	2	3	4
Sensor Input States (two connector blocks on the right):	0	0	0	0
Sensor Notify Port:	<input type="text" value="9146"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
Timer:	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>

Mode: Relay & Sensor (Standard)

Save Changes
Refresh

Voltage Sense Mode

Set jumpers at the positions nearest the connector terminals, then connect the voltage/current source to the pair of adjacent pins (pins 1-2 in the example above).

Contact Closure Mode

Set jumpers in the positions farthest away from the connector terminals, then connect the contact closure switch at the two adjacent corresponding pins (pins 3-4 in the example above).

When Relay & Sensor mode is enabled, the sensor can be polled through the TCP API or HTTP/RESTful API for each sensor's state.

The Flex also supports iTach Sensor and iTach Sensor Notify compatibility modes for iTach IP2IR sensor drivers, which allow drivers designed for iTach to work with the Flex Sensor module.

These can be selected under Mode and be applied by clicking Save Changes.

For detailed info on configuring and using the Flex and Flex Link Cables, consult the User Guide: Flex and Flex Link Cables at www.globalcache.com/docs

Scan for APIs, user guides, docs, and utilities.



Global Caché, Inc.

160 East California Street

PO Box 1659

Jacksonville, Oregon 97530


Phone [541-899-4800](tel:541-899-4800)

www.globalcache.com

support@globalcache.com

Copyright ©2024 Global Caché, Inc. All rights reserved.

Documents / Resources

 <p>Quick Start Guide Flex Link Cable Flex Link Relay & Sensor Cable (FLC-RS)</p> <p>Getting Started Once the Flex is connected to the network (see Flex Quick Start), plug the Flex Link Relay & Sensor cable (FLC-RS) into the Flex Link Port.</p> <p>To configure the FLC-RS, right-click on the unit entry in WebUp and select Configure, or enter the Flex unit's IP address into a web browser to access the Flex Configuration page.</p> <p>To access the settings, select the Flex Link Cable tab. Then select Relay & Sensor from the Change Flex Link cable field. The page will update and display the current saved configuration or default settings if the cable is not yet configured.</p> <p>The setup webpage provides the basic configuration and control interface to demonstrate and test relay and sensor functionality.</p> <p>Relay Outputs The four relay outputs on the left side of the cable can be configured as a variety of relay types for controlling a wide range of devices. To configure a relay, select the desired mode on the webpage using the Relay Type dropdown menu. Then install the hardware jumpers as indicated in the diagram and press Save Changes. Connect your device to the connector terminals as indicated and the webpage displays a conceptual diagram of the selected relay type. The relay outputs can now be controlled by using the Current State.</p>	<p>Global Cache FLC-RS Flex Link Relay and Sensor Cable [pdf] User Guide FLC-RS, FLC-RS Flex Link Relay and Sensor Cable, Flex Link Relay and Sensor Cable, Relay and Sensor Cable, Sensor Cable, Cable</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.