



globe Suite App User Guide

[Home](#) » [globe](#) » globe Suite App User Guide 

Contents

- 1 [Globe Suite App](#)
 - 1.1 [1 Get started](#)
 - 1.2 [2 Verify your network](#)
 - 1.3 [3a Add a device](#)
 - 1.4 [3b AP mode](#)
 - 1.5 [3c Scan mode](#)
 - 1.6 [4 Setup voice assistance](#)
 - 1.7 [Did you know?](#)
 - 1.8 [Have a question? We can help!](#)
- 2 [Documents / Resources](#)
- 3 [Related Posts](#)

Globe Suite App

GUIDE START QUICK

Welcome



1 Get started

- Download the Globe Suite™ app from the App Store or Google Play to your mobile device
- Launch the Globe Suite app.
- To register, enter your email address. Create a password, then login to the app
oR
- Login if you already have an account.



2 Verify your network

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel.
- Consult your router documentation for detailed instructions on how to change wireless settings.
- Once your devices have been successfully paired, you can switch back to mixed mode or use a cellular data network to control your smart products.

3a Add a device

- Power on your device.
- Select the “+” symbol on the top right hand corner.
- Select your product type and follow the instructions within the app.
- If the connection fails, try using AP mode.

3b AP mode

- On the “add a device” page select AP mode on the top right-hand corner and follow the instructions within the app.
- If the connection fails, try using Scan mode

3c Scan mode

- Select the “+” symbol on the top right hand corner.
- Select “Scan”,
- Follow instructions within the app.
- You’re good to go!

4 Setup voice assistance

- Instructions in the Globe Suite™ app: Select “Profile”, select “Integration”, choose your voice assistant, and follow instructions.

Did you know?

Most modern routers are dual band meaning they support both 2.4 GHz and 5 GHz channels,

The most common wireless options are:

- Mixed: The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to router etc.)
- 2.4 GHz: Broadcast only on this channel.
- 5 GHz: Broadcast only on this channel.
- Dual 2.4 and 5 GHz using Separate SSIDs: Router will broadcast both channels and the user manually decides which to connect to.

Have a question? We can help!



www.globe-electric.com/smart



smartsupport@globe-electric.com



Visit the FAQ page in the app



Check us out on YouTube



scan me

Documents / Resources

	<p>globe Suite App [pdf] User Guide GB34982, 2AQUQGB34982, 34982 Wifi LED Lamp, 34982, Wifi LED Lamp, Suite App</p>
	<p>globe Suite App [pdf] User Guide GB35850, 2AQUQGB35850, Suite App, Suite, App</p>

