



# Goldair GCTF300 80cm Tower Fan With Remote Control Instruction Manual

[Home](#) » [GOLDAIR](#) » Goldair GCTF300 80cm Tower Fan With Remote Control Instruction Manual 

## Contents

- [1 Goldair GCTF300 80cm Tower Fan With Remote Control](#)
- [2 General Care and Safety Guide](#)
- [3 TECHNICAL SPECIFICATION](#)
- [4 Components](#)
- [5 Assembling your Fan](#)
- [6 Operating your Fan](#)
  - [6.1 Remote control](#)
- [7 Cleaning](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)



**Goldair GCTF300 80cm Tower Fan With Remote Control**



## **General Care and Safety Guide**

Thank you for choosing this Goldair product. This Goldair appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully and keep them for future reference.

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. Ensure that the fan is switched off from the supply mains before removing the guard.
5. Use only the voltage specified on the rating plate of the appliance.
6. Keep all objects at least 1 Metre from the front, sides and rear of the appliance
7. This appliance is intended for household use only and not for commercial or industrial use.
8. Use this appliance only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock or injury.

9. The common cause of overheating is deposits of dust or fluff in the appliance. Ensure these deposits are removed regularly by unplugging the appliance and vacuum cleaning the air vents and grills.
10. Always unplug appliance when not in use.
11. When the appliance has been unpacked, check it for transport damage and ensure all parts have been delivered. If parts are missing or the appliance has been damaged, contact the Goldair Customer Services Team.
12. If your appliance does not work, or is not working properly, contact the place of purchase. Repair work on the appliance by unqualified persons can cause serious risk to the user.
13. Ensure hands are dry before handling the plug or the main unit.
14. Carry out regular checks of the supply cord to ensure no damage is evident.
15. Ensure that the cord is fully extended (not coiled) while in use.
16. Avoid contact with the moving parts. Keep hands, hair, clothing, away from blade of the fan during operation to reduce the risk of injury to person and/or damage to the unit.
17. Switch off and use handles provided when moving.
18. It is recommended that this fan is plugged directly into the wall socket.
19. A correctly specified, undamaged extension cord may be used with this fan provided it is used in a safe manner.
20. Never place appliance close to radiant heat source.
21. Never operate in areas where petrol, paint or other flammable liquids are used or stored.
22. Never use the appliance to dry clothes.
23. Never insert or allow foreign objects to enter any ventilation or exhaust opening, as this may cause an electric shock, fire or damage to the appliance.
24. Never use abrasive cleaning products on this appliance. Clean with a damp cloth (not wet) rinsed in hot soapy water only. Always remove plug from the mains supply before cleaning.
25. Never connect the appliance to mains supply until completely assembled and adjusted.
26. Never remove plug from power socket until the appliance has been switched off.
27. Never remove plug from power socket by pulling cord – always grip plug.
28. Never twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split. Always ensure that all cord has been removed from any cord storage area and is unrolled before use.
29. Never use this appliance in the immediate surrounds of a bath, a shower, or a swimming pool or other liquids. The appliance must not be immersed in any liquids.
30. Due to the risk of injury, never use this appliance for any purpose other than its intended use. This appliance is intended for use in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses, by clients in hotels, motels, bed and breakfast type environments and other residential type environments
31. Never use this appliance outdoors.
32. Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner. Have the appliance checked and repaired by a qualified electrician if repair is necessary.
33. Never place the unit in wardrobes or other enclosed spaces as this may cause fire hazards.

## **TECHNICAL SPECIFICATION**

**Model:** GCTF300

**Supply:** 220- 240VAC 50Hz

**Wattage:** 55 W

The remote control supplied with this heater uses a CR2025 coin type battery.

**DANGER IF SWALLOWED**

Keep batteries out of reach of children. Swallowing may lead to serious injury or death in as little as 2 hours due to internal burns. If swallowed, go straight to a hospital emergency room. Dispose of used batteries immediately.


**WARNING!**

**DANGER IF SWALLOWED**

Keep batteries out of reach of children. Swallowing may lead to serious injury or death in as little as 2 hours due to internal burns. If swallowed, go straight to a hospital emergency room. Dispose of used batteries immediately.


## Components

1. Remote
2. Carry Handle
3. Rear Grill
4. Front Grill
5. Rear Base
6. Front Base




## Assembling your Fan


Pass the cord through the base.



Assemble the two base halves together.



Position the base half with the alignment pin, over the other base half with the alignment sockets. Press the two halves together until flush. Assemble the base to the tower bottom. With the tower on its side, align the 4 base sockets onto the tower bottom pins. Tighten the screws securely but do not over tighten.



## Operating your Fan

Always choose a safe location for the fan, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the unit before use. This appliance requires no installation, it should be used solely as a portable appliance.


### **WARNING:**

Keep all objects at least 1 metre from the front, sides and rear of the appliance.

Place the fan on a dry, level and sturdy surface.

Ensure the fan speed control is on the OFF position before plugging the power cord into the socket.

### **Fan control**



**Power (A)** The fan functions ON and OFF by pressing the power button. Lights on the fan's control panel indicate the power is ON.

**Fan Speed (B)** The fan speed can be adjusted by pressing the SPEED button. Press the button to switch between the low, medium & high speed settings.

**Timer (C)** The fan has an automatic timer to turn the unit OFF at intervals of 1, 2, 4 or 8 hours. To set the timer, turn the unit on at the required speed, press the timer button until the desired run time is illuminated. The fan will turn off once the time has expired.

**Oscillation (D)** The oscillation feature can be activated by pressing the Oscillation button. The fan can be set to a stationary position by pressing the button again.

#### Remote control

The remote requires a line-of-sight path to allow for the signal to be received by the unit. Position the unit so the receiver lens is visible from the remote control.

The symbols on the Remote correspond to the symbols on the main unit.

**Remote control battery** The remote control comes with a CR2025 lithium coin cell battery.

To install, remove the battery cover on the bottom of the remote control. Remove any plastic protection from the battery and place it in the remote with the + side facing out. Then reposition the cover onto the bottom of the remote. If your remote no longer works, please try replacing with a new CR2025 battery.

**The remote control supplied with this heater uses a CR2025 coin type battery.**

#### **DANGER IF SWALLOWED**

Keep batteries out of reach of children. Swallowing may lead to serious injury or death in as little as 2 hours due to internal burns. If swallowed, go straight to a hospital emergency room. Dispose of used batteries immediately.



#### Cleaning

The fan requires regular cleaning to ensure trouble free operation. Unplug the fan from the mains supply before cleaning. Use a damp cloth (not wet) to wipe the exterior of the fan to remove dust and dirt. Use a vacuum cleaner to remove dust and fluff from around the grills. Ensure the fan is dry before plugging back into the mains supply. Do not attempt to dismantle the fan. There are no user serviceable parts. For service or repair, contact an authorised electrical service technician.

### One Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of one year. In non-domestic use Goldair limits the voluntary warranty to three months. Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period. This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits to you given by this warranty are in addition to other rights and remedies available to you under a law in relation to the goods or services to which this warranty relates. In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

### Goldair – New Zealand

CDB Goldair  
PO Box 100-707  
N.S.M.C  
Auckland, 0745  
Phone +64 (0)9 917 4000  
Phone 0800 232 633


[www.goldair.co.nz](http://www.goldair.co.nz)

### Goldair – Australia

CDB Goldair Australia Pty  
PO Box 574  
South Morang  
Victoria, 3752  
Phone +61 (0)3 9365 5100  
Phone 1300 GOLDAIR (1300 465 324)

[www.goldair.com.au](http://www.goldair.com.au)

## Documents / Resources

	<p><a href="#">Goldair GCTF300 80cm Tower Fan With Remote Control</a> [pdf] Instruction Manual GCTF300, 80cm Tower Fan With Remote Control, 80cm Tower Fan, Tower Fan, Fan With Remote Control, GCTF300, Fan</p>
---	--

## References

- [G Goldair – Goldair.nz](#)
- [G Goldair – Goldair.nz](#)
- [G Goldair Australia](#)
- [G Goldair Australia](#)