



GWINSTEK Three Phase Power Controller ASR-002 User Manual

[Home](#) » [GWinsTek](#) » GWINSTEK Three Phase Power Controller ASR-002 User Manual 



Three-Phase Power Controller ASR-002 USER MANUAL Rev. A



ISO-9001 CERTIFIED MANUFACTURER

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced, or translated to another language without the prior written consent of Good Will company. The information in this manual was correct at the time of printing.

However, Good Will continues to improve products and reserves the right to change specifications, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.

No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Contents







- [1 SAFETY INSTRUCTIONS](#)
- [2 Safety Guidelines](#)
- [3 GETTING STARTED](#)
- [4 Front Panel](#)
- [5 OPERATION](#)
- [6 APPENDIX](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.

 WARNING	Warning: Identifies conditions or practices that could result in injury or loss of life.
 CAUTION	Caution: Identifies conditions or practices that could result in damage to the ASR-002 or to other properties.
	DANGER High Voltage
	Attention Refer to the Manual
	Protective Conductor Terminal
	Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General
Guideline



CAUTION

- Do not place any heavy objects on the ASR-002.
- Avoid severe impact or rough handling that leads to damaging the ASR-002.
- Do not discharge static electricity to the ASR002.
- Use only mating connectors, not bare wires, for the terminals.

- Do not block the cooling fan opening.
- Do not disassemble the ASR-002 unless you are qualified.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.




WARNING

Power Supply

- AC Input voltage range:
230 Vac ± 15%
- Frequency: 50/60 Hz
- To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.

Cleaning the ASR002

- Disconnect permanently connected power input before cleaning.
- Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
- Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.

<div>Operation Environment</div>	<ul style="list-style-type: none"> • Location: Indoor, no direct sunlight, dust-free, almost non-conductive pollution (Note below) • Relative Humidity: 20%~ 80%, no condensation • Altitude: < 2000m • Temperature: 0°C to 40°C
<div>Storage environment</div>	<ul style="list-style-type: none"> • Location: Indoor • Temperature: -10°C to 70°C • Relative Humidity: ≤90%, no condensation
<div>Disposal</div> <div>  </div>	<div>Do not dispose of this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.</div>

GETTING STARTED


This chapter describes the ASR-002 power controller in a nutshell, including its main features and front/rear panel introduction.






ASR-002 Overview	7
Front Panel	8
Rear Panel	10














ASR-002 Overview


ASR-002, which is a three-phase power controller, is able to control up to 3 single-phase power supply units (ASR series only). It effectively makes AC output conformed to 1P3W/3P4W that generally unit requires, and also turns output into 3P3W via designated wire method. When the select single-phase power is greater than the capacity of 2kVA, it is suggested that output should be connected to an external terminal for safety consideration.

Front Panel




Section	Figure	Description
Header Displays		FREQUENCY: It displays frequency.
		VOLTAGE: It displays voltage.
		MULTIMETER: It displays A current / W power / PF power factor.
Function Keys	<p>A / W / PF</p> 	It changes header display A → W → PF.
	<p>ON / OFF</p> 	ON: Output on. OFF: Output off.

	<p>V Set: It configures voltage.</p>
	<p>Range: It toggles between 100V and 200V Auto: It enters Auto range by long press.</p>
	<p>F Set: It configures frequency.</p>
	<p>P Set: It configures L2 / L3 phase.</p>
	<p>L1 / L2/ L3: It changes among L1 → L2 → L3.</p>
	<p>Mode: It toggles between 1P3W → 3P4W. Func: It configures advanced settings by long press.</p>
	<p>Local: It cancels connection and enters the local operation mode.</p>
	<p>Knob Key: It adjusts value by scroll. Also, it switches input adjusting position by press.</p>
<p>Display Icons</p> 	<p>It indicates remote control mode.</p>
	<p>It indicates that error of control occurs.</p>
	<p>It indicates output phase.</p>
	<p>It indicates output mode.</p>
	<p>It indicates output range.</p>



It indicates measurement unit display.

Rear Panel



Section	Figure	Description
USB Port		USB B-type port for remote control.
RS232C Port		RS232C port for remote control.
SIG OUT		SIG OUT for phase control signal output.
Phase Terminal		The phase terminals for L1/L2/L3.
Output Terminal		1P3W: Single phase 3 wire. 3P4W: Three-phase 4 wire.
Power Voltage Input		Voltage Input: AC 220V. Power Frequency: 47 – 63Hz.

OPERATION

Basic Operation	12
Output Mode Setting Process	12
Voltage Range Setting Process	12
Voltage Value Setting Process	12
Frequency Setting Process	13
Phase Shift Setting Process	13
Advance Setting	14
Voltage Amplification Setting Process	14
Slew Reate Setting Process	14
RS232 Baudrate Setting Process	15
Factory Default Setting Process	15
Phase Angle Setting	16
Phase Angle Setting Process	16
Voltage Ramp Setting	17
Voltage Ramp Setting Process	17
Frequency Sweep Setting	18
Frequency Sweep Setting Process	18
Unit Setting Value Display	19
Unit Setting Value Display Setting Process	19
Wire Connection & Accessories	20
ASR-2000 Series example	20
Accessories	20

Basic Operation

Output Mode Setting Process

Steps 1. Press the Mode key.

2. Toggle between 1P3W →3P4W.

Voltage Range Setting Process

Steps 1. Press the Range key.

2. Toggle between 100V →200V.

Press and hold the Range key to enter Auto.

Voltage Value Setting Process

Steps

1. Press the V Set key.

2. Scroll the Knob key to adjust voltage value.

3. 100V: 0 – 175V

200V: 0 – 350 V

Auto: 0 – 350V

4. After adjustment, press the V Set key again to

upload the set value to ASR series unit.

Frequency Setting Process

Steps

1. Press the F Set key.
2. Scroll the Knob key to adjust frequency value.
3. Frequency range: 40 – 999.9Hz.

Phase Shift Setting Process

Steps

1. Press the P Set key.
2. Scroll the Knob key to adjust phase.L2 setting range: 85° – 155°.

PSet 1200 000

3. Press the P Set key to enter the next step. L3 setting range: 205° – 275°.

PSet 2400 000

4. Press the P Set key to exit.

Advance Setting

Voltage Amplification Setting Process

Steps

1. Press and hold the Mode key to enter the setting.
2. Adjust L1/L2/L3 based on voltage amplification.
3. Scroll the Knob key to adjust amplification. The setting range: 0 – 3.5. Press L1/L2/L3 key to enter next step.

L1 8rEF 1000

L2 8rEF 1000

L3 8rEF 1000

4. After configuration, press the Range key to enter the next step.

RS232 Baudrate Setting Process

Steps

1. RS232 interface transmission speed setting (9600 by default). Setting range: (9600 → 19200 38400 57600 →115200).

baud 9600

Factory Default Setting Process

Steps

1. Restore to the factory default setting. Press the Range key, and the system exits automatically.

FACT DEFA

Slew Rate Setting Process

Steps

1. Slew Rate setting. Setting range: 0.001 – 0.5.

SLEW RATE 0.200

2. After configuration, press the Range key to enter the next step.

Phase Angle Setting Phase Angle Setting Process Steps

1. Press and hold the P Set key to enter the phase angle setting.
2. Set the starting angle.
3. The default setting is OFF.

on PHAS off

4. Press the Range key to enter next step or scroll the Knob key to adjust to ON for angle setting. The setting range: 0° – 359°.

on PHAS on

5. Press the Range key to enter the next step and exit from starting angle setting.
6. Set the ending angle.
7. The default setting is OFF.

off PHAS off

8. Press the Range key to finish the phase angle setting or scroll the Knob key to adjust to ON for angle setting. The setting range: 0° – 359°.

off PHAS on

9. After configuration, press the Range key to finish phase angle setting.
10. Press and hold the Mode key and display will be shown as the right figure.
- 11.

SAVE FUNC Set

12. Press the Range key to save the setting and exit.

Voltage Ramp Setting

Voltage Ramp Setting Process

Steps

1. Press and hold the V Set key to enter the Ramp setting.
2. The default setting is OFF.

VOLT rAMP off

3. Press the Range key to exit from Ramp setting or scroll the Knob key to Ramp ON followed by pressing Range key to enter the Ramp value setting.4. The setting range: 0.001 – 9.999

VOLT rAMP on

4. The setting range: 0.001 – 9.999
5. Press the Range key to exit.
6. Press and hold the Mode key and display will be shown as the right figure.
- 7.

SAVE FUNC SET

Press the Range key to save the setting and exit.

Frequency Sweep Setting

Frequency Sweep Setting Process

Steps

1. Press and hold the F Set key to enter the Sweep setting.
2. The default setting is OFF.

FREQ SWEEP OFF

3. Scroll the Knob key to Sweep ON followed by pressing the Range key to enter the Sweep value setting.
4. The setting range: 0.001 – 9.999
5. Press the Range key to exit.
6. Press and hold the Mode key and display will be shown as the right figure.

FREQ SWEEP ON

7. Press the Range key to save the setting and exit.


Unit Setting Value Display

Unit Setting Value Display Setting Process

Steps	1. Press and hold the Mode key to enter the setting.	
	2. Press the L1/L2/L3 key to browse the default settings as follows.	
	L1 Vref 1.000	L1 VREF 1000
	L2 Vref 1.000	L2 VREF 1000
	L3 Vref 1.000	L3 VREF 1000
	SLEW RATE 0.200	SLEW RATE 0200
	BAUD 9600	BAUD 9600
	FACT DEFA	FACT DEFA
	SOFT VER T101	SOFT VER T101
	SAVE FUNC SET	SAVE FUNC SET
	EXT ASR SET	EXT ASR SET
	EXIT FUNC SET	EXIT FUNC SET

Wire Connection & Accessories

ASR-2000 Series Example




ASR-2100 A1 to ASR-002 A1	B1 to B1	C1 to C1
ASR-2100 A2 to ASR-002 A2	B2 to B2	C2 to C2
ASR-2100 A3 to ASR-002 A3	B3 to B3	C3 to C3

Accessories




Part Number	Description
GTL-232 x 3	RS232C cable, approx. 2M
GTL-110 x 3	BNC test lead, approx 1.1M
GTL-246 x 1	USB Cable (USB 2.0 Type A- Type B Cable, Approx. 1.2M)
40WC792030011 x 3	C1/C2/C3 Cable, 4M Max Length, UL1015 12AWG, RV5-5, Hirose DF22-4S- 7.92C(2 8) 3P + DF22A-1012SCFA

APPENDIX

ASR-002 Dimension	21
Using the Rack Mount Kit	22
Command-List	23
ASR-002 Error Messages	24
ASR-002 Dimension	



Using the Rack Mount Kit

Background	The ASR-002 assembled with ASR-2000 has the following optional Rack Mount kits.
ASR-002 Rack-EIA	
ASR-002 with ASR2000 assembled with rack EIA	
ASR-002 Rack-JIS	
ASR-002 with ASR2000 assembled with rack JIS	
 CAUTION	Ensure adequate ventilation is provided when using the rack mount. Ensure that a gap is given for air intakes. Failure to do so may cause the instrument to overheat.

Command List

Source Commands

[SOURce:]VOLTage[:LEVel][:IMMediate][:AMPLitude]
 [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPLitude]?
 [SOURce:]VOLTage:RANGe 100/200/AUTO
 [SOURce:]VOLTage:RANGe?
 [SOURce:]VOLTage:MODE FIXed/STEP
 [SOURce:]VOLTage:MODE?
 [SOURce:]VOLTage:SLEW xxx
 [SOURce:]VOLTage:SLEW?
 [SOURce:]FUNction[:SHApe][:IMMediate] SIN/SQU/TRI
 [SOURce:]FUNction[:SHApe][:IMMediate]?
 [SOURce:]FREQuency[:IMMediate] xxx
 [SOURce:]FREQuency[:IMMediate]?
 [SOURce:]PHASe:PHASe L12,xxx/L13,xxx
 [SOURce:]PHASe:PHASe? L12/L13
 [SOURce:]PHASe:STARt:ENABle ON/OFF/1/0
 [SOURce:]PHASe:STARt:ENABle?
 [SOURce:]PHASe:STARt xxx
 [SOURce:]PHASe:STARt?
 [SOURce:]PHASe:STOP:ENABle ON/OFF/1/0
 [SOURce:]PHASe:STOP:ENABle?
 [SOURce:]PHASe:STOP xxx
 [SOURce:]PHASe:STARt?

Output Commands OUTPut[:STATe] ON/OFF/1/0 OUTPut[:STATe]?

Display Commands DISPlay[:WINDow]:INSTrument:NSElect 0/1/2

DISPlay[:WINDow]:INSTrument:SElect L1/L2/L3

Measure Commands MEASure[:SCALar]:FREQuency?

MEASure[:SCALar]:CURRent[:RMS]?

MEASure[:SCALar]:CURRent:AVErage?


MEASure[:SCALar]:VOLTage[:RMS]?

MEASure[:SCALar]:VOLTage:AVErage?
 MEASure[:SCALar]:POWer[:AC][:REAL]?
 MEASure[:SCALar]:POWer[:AC]:APParent?
 MEASure[:SCALar]:POWer[:AC]:REACTive?
 MEASure[:SCALar]:POWer[:AC]:PFACTOR?
 System Commands SYSTem:ERRor?
 SYSTem:CONFigure:NPU 3P4W/1P3W
 SYSTem:CONFigure:NPU?
 Common Commands *IDN?
 *CLS
 *RST

ASR-002 Error Messages

The following error messages may appear on the ASR-002 screen display during varied operations.

Section	Error Messages	
Command Error	0	"No error"
	-101	"Invalid character"
	-102	"Syntax error"
	-103	"Invalid separator"
	-108	"Parameter not allowed"
	-109	"Missing parameter"
	-113	"Undefined header"
	-121	"Invalid character in numb
	-148	"Character data not allowed"
	-151	"Invalid string data"
Execution Error	-203	"Command protected"
	-222	"Data out of range"
	-224	"Illegal parameter value"
Device-Specific Error	-330	"Self-test failed"
	-350	"Error queue overflow"
Query Error	-410	"Query INTERRUPTED"
	-420	"Query UNTERMINATED"
	-521	"Input buffer overflow"
	-522	"Output buffer overflow"

<div>Three Phase Power Controller</div> <div>ASR-002</div> <div>USER MANUAL</div> <div>1.0.0</div> <div> GWINSTEK</div>	<div>GWINSTEK Three Phase Power Controller ASR-002 [pdf] User Manual</div> <div>GWINSTEK, Three Phase, Power, Controller, ASR-002</div>
--	---