




## hama 00014170 FM Transmitter with Bluetooth Function User Manual

[Home](#) » [Hama](#) » hama 00014170 FM Transmitter with Bluetooth Function User Manual 

# ***hama***

00014170 FM Transmitter with Bluetooth Function  
User Manual





## Contents

- 1 Controls and Displays
- 2 Explanation of Warning Symbols and Notes
- 3 Package Contents
- 4 Safety Notes
- 5 Product Features
- 6 Getting Started and Operation
- 7 Bluetooth® pairing
- 8 Care and Maintenance
- 9 Warranty Disclaimer
- 10 Technical Data
- 11 Declaration of Conformity
- 12 Documents / Resources
- 13 Related Posts

## Controls and Displays

1. USB-C charging connection, 5 V/2.1 A
2. Connector for USB flash drive
3. Display/Frequency indicator
4. Previous track/volume down/lower frequency
5. Play/start/pause/activate frequency
6. microSD card slot
7. Next track/volume up/higher frequency

Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

## Explanation of Warning Symbols and Notes



### **Risk of electric shock**

This symbol indicates product parts energized with a dangerous voltage of sufficient magnitude to constitute a risk of electric shock.



### **Warning**

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



### **Note**

This symbol is used to indicate additional information or important notes.

## Package Contents

- FM-Transmitter with Bluetooth® function
- These operating instructions

## Safety Notes

- The product is intended for private, non-commercial use only.
- Use the product for its intended purpose only.
- Do not operate the product outside the power limits given in the specifications.
- Protect the product from dirt, moisture and overheating, and only use it in a dry environment.
- Do not use the product in moist environments and avoid splashes.
- Do not bend or crush the cable.
- Always pull directly on the plug when disconnecting the cable, never on the cable itself.
- Do not drop the product and do not expose it to any major shocks.
- Dispose of packaging material immediately according to locally applicable regulations.
- Do not modify the product in any way. Doing so voids the warranty.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Use the item only in moderate climatic conditions.
- Keep this product, as all electrical products, out of the reach of children!
- Do not use the product in areas where the use of electronic devices is not permitted.



### **Note**

- When using this product, observe the applicable local traffic laws and regulations.
- Take care that components such as airbags, safety areas, controls, instruments, etc. and visibility are not blocked or restricted.
- Check that the product is safely mounted before beginning your journey.
- Do not allow yourself to be distracted by the product when driving a vehicle. Always pay attention to the surrounding traffic and your environment.



### **Risk of electric shock**

- Do not open the device or continue to operate it if it becomes damaged.
- Do not use the product if the charging cable, adapter cable or power cable is damaged.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.

## Product Features

The FM transmitter is used to transmit music or voice from a mobile device (smartphone, tablet, etc.) to an FM playback device (such as a car radio) in high quality in a car, caravan or boat. At the same time, up to two terminal devices can be charged simultaneously using the USB connections. The FM transmitter is compatible with all terminal devices that have a Bluetooth® function. The FM transmitter can also transmit music or voice directly from a USB stick (maximum of 32 GB) or a microSD card (maximum of 32 GB).

## Getting Started and Operation

- Plug the FM transmitter into a power socket of your vehicle's electrical system, and then establish the Bluetooth® connection between the mobile device and the FM transmitter as described below.
- Alternatively, audio files can be transferred directly from a USB stick or microSD card.

### Note

- For some vehicle types, the ignition has to be switched on to supply power to the 12 V car socket. For more information, please refer to your vehicle's operating instructions.
- Disconnect all cable and on-board connections after use.

## Bluetooth® pairing



### Note

- Check whether your mobile device (MP3 player, mobile phone, etc.) is Bluetooth® capable.
- If not, the only way you can use the FM transmitter for playback is with a USB stick or microSD card.
- Note that the maximum range for Bluetooth® is 10 metres without obstacles such as walls, people, etc.
- Make sure that your Bluetooth® capable terminal device is on and Bluetooth® is activated.
- Plug the FM transmitter into a car socket located near the car radio.
- Make sure that the FM transmitter is within the maximum Bluetooth® range of 10 metres.
- Open the Bluetooth® settings on your terminal device and wait until **BT21MC** appears in the list of Bluetooth® devices found.
- Select **BT21MC** and wait until the FM transmitter is listed as connected in the Bluetooth® settings on your terminal device. A transmission frequency is now shown on the display.



### Note – Bluetooth® password

Some terminal devices require a password in order to connect to another Bluetooth® device.

- If your terminal device requests a password for connection to the speaker, enter 0000.






### Note – Connection impaired

After the FM transmitter and terminal device have been paired, a connection is established automatically. If the Bluetooth® connection is not established automatically, check the following:


- Check the Bluetooth® settings of your terminal device to see whether **BT21MC** is connected. If not, repeat the steps listed under Bluetooth® pairing.
- Check whether your terminal device and the FM transmitter are less than 10 metres apart. If not, move the devices closer together.
- Check whether obstacles are impairing the range. If so, move the devices closer together.

### 6.2 Audio playback (via Bluetooth®)

Start and control audio playback on the connected terminal device accordingly. Alternatively, audio playback can also be controlled on the FM transmitter (if the connected device supports this function).

- Press the  function button to start or pause audio playback.
- Press the  function button to jump forward one title.
- Press the  function button to jump backward one title.




### 6.3 Audio playback (via USB stick or microSD card)

- Plug the USB stick into the USB socket marked with  (2); playback will start automatically.
- Insert a microSD card into the card slot (6) on the FM transmitter; playback will start automatically.

### Note

- The capacity of the USB stick or microSD card must not exceed 32 GB.
- The following formats are supported for audio playback: MP3.

### 6.4 Manual station search

- Search for an available frequency on your car radio (static without partial signals).
- Set the same frequency on the FM transmitter. To do this, press and hold the  button (5) for 2 seconds until the frequency indicator on the display (3) begins to flash.
- Then press the  or  button to set the desired frequency.
- The FM transmitter always stores the last frequency set.



### Note – Automatic standby

- After 50 to 60 seconds without a music signal or button being pressed, the FM transmitter switches to standby.
- If it receives a music signal or a button is pressed, the FM transmitter is activated again.

### 6.5 Charging function

The FM transmitter has a USB charging socket. This supplies the charging currents specified in Point 7.

'Technical specifications'.



### Note – Connecting terminal devices

- Before connecting a terminal device, check whether the power output of the charger can supply sufficient power for the device.
- Ensure that the total power consumption of all connected terminal devices does not exceed 2100 mA.
- Please refer to the instructions in the operating manual of your terminal device.
- Disconnect all cable and mains connections after use.



### Note – Car battery

With some vehicles, it can happen that power continues to be supplied even though the ignition has been switched off. Therefore, when not using the product, disconnect it from the power supply to protect your car battery from discharge.

## Care and Maintenance

Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning agents.







### Note

Disconnect the device from the power supply before cleaning or if it will not be used for a long period of time.

## Warranty Disclaimer

Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

## Technical Data

	FM transmitter with Bluetooth® function
Bluetooth® technology	Bluetooth® v5.3
Input voltage	12 – 16 V
Input current	2:00 AM
Output voltage and current on USB 1 (marked with  symbol)	5 V  2.1 A
Output current, USB 2 (marked with  symbol)	No charging function; suitable for USB sticks only

## Declaration of Conformity

Hereby, Hama GmbH & Co KG declares that the radio equipment type [00014170] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://uk.hama.com> ➡  ➡ [00014170](#) ➡ [Downloads](#)

Frequency for the Bluetooth® transfers	2,402 GHz ~ 2,480 GHz
Bluetooth® transmitting power	max. 4 dBm
FM frequency range	87.6 – 107.9 MHz
Transmitting power	max. -44.54 dBm

***hama***

**Hama GmbH & Co KG**

86652 Monheim/Germany

**Service & Support**



[www.hama.com](http://www.hama.com)



+49 9091 502-0




00014170/07.23

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hama GmbH & Co KG is under license. Other trademarks and trade names are those of their respective owners.

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

**Documents / Resources**

	<p><a href="#">hama 00014170 FM Transmitter with Bluetooth Function</a> [pdf] User Manual</p> <p>00014170, 00014170 FM Transmitter with Bluetooth Function, FM Transmitter with Bluetooth Function, Transmitter with Bluetooth Function, Bluetooth Function</p>
---	---