

HAMRON 334113 Lever Block Instruction Manual

Home » HAMRON » HAMRON 334113 Lever Block Instruction Manual



Contents

- 1 HAMRON 334113 Lever
- **Block**
- **2 TECHNICAL DATA**
- **3 DESCRIPTION**
- **4 OPERATION**
- **5 OPERATING INSTRUCTIONS**
- **6 MAINTENANCE**
- 7 Documents / Resources
- **8 Related Posts**



HAMRON 334113 Lever Block



Read the Operating Instructions carefully before use. Save these instructions for future reference.

TECHNICAL DATA

- Lifting height 7m
- Max. load 250 kg
- Weight 2 kg
- Chain dimension 4mm

DESCRIPTION

The transmission consists of two gear stages and a sprung ratchet coupling. The main components are made of high quality steel for best functionality and service life.

- Safe, operationally reliable and durable.
- First-rate performance and minimum maintenance.
- Compact, lightweight and portable.
- asily operated levers and high mechanical efficiency.

· Advanced and attractive design.

OPERATION

USE

Effective and versatile lever block for lifting and towing outdoors and indoors, even in confined spaces.

Disengaged position

The selector is set to the middle position when the hook is unloaded. The spring coupling is disengaged, so that the load chain can be pulled out or in to the required length.

Lifting a load

Set the selector in the UP position and pull the right lever to press the friction plates and ratchet against the brake plate, so that these parts move together. Pump with the lever so that the transmission and load chain move smoothly and lift the load.

OPERATING INSTRUCTIONS

- 1. Do not overload the product.
- 2. Never attempt to connect the product to a motor or other drive unit. The product is only intended for manual use.
- 3. Lubricate all moving parts regularly. Always check before use that no parts are damaged and that the product moves as intended in disengaged position.
- 4. Before lifting, check that the hook is properly fastened. Never lift a load hanging from the tip of the hook. Check that the chain is not twisted or bent.
- 5. Stop using the device immediately if the lever is stiff.
 - 1. Check that the load has not been caught up something.
 - 2. Check that all the parts are working properly.

MAINTENANCE

- 1. Clean the product after use, and lubricate the moving parts. Store in a dry place.
- 2. Maintenance and inspection should be carried out by qualified personnel. The product should only be dismantled by qualified personnel.
- 3. After cleaning and/or repairing the product it should be tested with no load and with maximum load before use.
- 4. Keep the friction surfaces on the brake clean and dry. Check the brake mechanism regularly

Tobias Hammer

PRODUCT MANAGER (Signatory for Jula and authorised to compile the technical documentation

Documents / Resources



HAMRON 334113 Lever Block [pdf] Instruction Manual 334113, Lever Block

