

# HARVEST TEC 201SS Small Square Baler Precision Moisture Sensing Kit Owner's Manual

Home » HARVEST TEC » HARVEST TEC 201SS Small Square Baler Precision Moisture Sensing Kit Owner's Manual

HARVEST TEC 201SS Small Square Baler Precision Moisture Sensing Kit Owner's Manual



#### **Contents**

- 1 Introduction
- 2 Requirements
- 3 Tools Needed
- 4 Installation of Star Wheels
- **5 Control Box Installation**
- **6 Wiring Diagram**
- **7 Screen Definitions**
- 8 Operation
- 9 H2O Firmware Update through App
- 10 Pin Outs
- 11 Parts Breakdowns
- 12 Control Box & Harnesses
- 13 Fixed Chamber End of Bale Sensor Kit
- 14 H2O Dye Marker
- 15 Harvest Tec Inc. Warranty and Liability

**Agreement** 

- **16 DECLARATION OF INCORPORATION**
- 17 Documents / Resources
- **18 Related Posts**

#### Introduction

Congratulations and thank you for purchasing a Harvest Tec H2O Moisture Sensing Kit Model 201SB system. Please read this manual carefully to ensure correct steps are taken to attach the system to the baler. This system is designed to read moisture at levels of 5-33%.

#### Requirements

The app will support operation of the current operating system and one previous version for both Apple and Android devices.

It is recommended for proper communication that the original phone/tablet power cable is used. Many lower cost power cables do not meet requirements to properly charge and communicate to the Harvest Tec H2O module.

#### **Tools Needed**

SAE wrench set Hammer Drill bit set Standard screw driver Measuring tape Center punch Side cutter SAE socket set

#### Installation of Star Wheels

#### **Two-Tie Balers Only**

The pair of star wheels will need to mount on the bottom side as close to the front of the bale chute as possible and at least 3/8" (10mm) away from any metal. They will need to maintain a safe distance away from the twine.


Depending on the baler model the star wheels can mount in front of the needle arm Option A (below) if there is space available. When there is not enough room for the star wheel use Option B


The star wheels will require two holes to be drilled per block, when drilling make sure to keep the wheel square to

the bale chamber. Any angle will cause stress on the wheel and will eventually cause the wheel to work itself out of the block. Some balers may require a notch cut on the bottom of the bale chamber to mount the star wheels as close to the front of the chamber as possible.

Use the supplied bolts and place the head inside of the bale chamber. Next attach 001-6707ES to the outside of the chamber. Then attach the star wheels to the bolts followed by the flat washer, lock washer, and nut.

First, remove the cover from the star wheel block and use a 1/4" (7mm) nut driver to remove the nut from the electronic swivel. Next, run the star wheel sensor wire through the black grommet and place the eye terminal on the star wheel sensor. Tighten the eye loop with the nut on the sensor and put the star wheel cover back on the base. Next, tighten the grommet to form a tight seal around the wire. Secure the harness to the baler to avoid moving parts.





Option B

#### **Three-Tie Balers Only**

When using a three-tie baler the star wheels will need to be mounted on the top of the bale chamber as close to the knotters as possible (shown below). Use the instructions above for proper star wheel installation.





#### **Control Box Installation**

Locate a safe location in the cab of the tractor to place the control box (006-2473SB). Recommended location is as close to the tablet or phone being used to control the system.

Connect the Power Harness (006-2470P) and the Baler Power Communication Harness (006-2470SS).

The control box (006-2473SB) is equipped with a green light to indicated both power and connection.

Plug the tablet/phone cord into the communication port (closest to light) and indicated by:



Slow Blink – System has power but not connected to phone or tablet. Solid Green – Device is connected.

\*\*It is recommended for proper communication that the original phone/tablet power cable is used. Many lower cost power cables do not meet requirements to properly charge and communicate to the Harvest Tec H2O module.


#### End of Bale Sensor Installation – 200FCA (Optional)


The end of bale sensor is used to determine when the baler needle arm moves. With this information the system is able to show the average moisture of the previous bale. Part number for kit is 200FCA

Mount the 006-7400 sensor to the mounting bracket 001-4648RB as shown below. Mount the assembly on the right side of the baler chamber. The face of the sensor needs to be parallel to the arm attached to the needles. **Note:** The bracket may need to be slightly bent for the proper positioning. Mark and drill two 3/8" (10mm) holes. Install the sensor using two 5/16" x 1" allen head bolts, locks, and nuts.

The end of the sensor needs to be no greater than 1/4" (7mm) away from the needle arm. Tighten nuts on sensor after adjustment.

The harness will need to be routed toward the harness at the tongue of the baler. Secure with cable ties and take care to avoid pinch points. The harness extension (006-7400EXT) may need to be used.





#### Dye Marker Installation – 200DM (Optional)

Locate the dye marking kit tank and pump assembly (005-9015). Identify a suitable mounting location for the tank away from moving parts and hydraulic lines on the baler. Be sure to mount the tank within 10' of the connection on the Baler Pwr/Comm Harness (006-2470SS), wiring details in the wiring diagram.

**Note:** The mounting location will potentially be different for the tank on each baler model. Due to various baler designs and modifications, Harvest Tec does not offer a specific mounting location for each baler model.

Once a mounting location has been identified, mount the tank vertically as shown (right) with the tank lid on the top using the included hardware.

Next locate the dye marking spray assemblies shown (below).






Nozzle straps should be placed directly above star wheels so spray will be applied on the top of the bale in the twine grooves.

Small square and Large square balers must us the brass tip (004-TX-5)

Mount the second tip assembly on the left side of the baler in a similar position to allow the tip to spray the bale.



#### **Routing the Hose**


Using the supplied 1/4" hose (002-9006) connect to the pump and secure with the hose clamps (003-9002). Route the hose to each tip assembly by using the 1/4" Barbed Tee (003-T1414) to go to each side of the baler. Be sure to avoid moving parts.

#### Wiring Diagram

- 1. Connect the power harness (006-2470P) to the tractor convenience outlet keyed power switch using the red wire with fuse to the positive side and the black wire to the negative.
  - a. Any modifications of the power harness will void the warranty. Contact Harvest Tec before modifications are made.
- 2. The power harness (006-2470P) will mount on the tractor connected to the control box (006-2473SB) with the 12-pin male deutsch connection and the opposite end down to the draw bar.
- 3. Connect the Baler Pwr/Comm Harness (006-2470SB) to the power harness (006-2470P).
- 4. Route the Pwr/Comm Harness (006-2470SS) on the baler to each moisture sensor on both sides of bale chamber, sensors are pn 030-4642UX.

- 5. Connect the USB charging/comm cord for the phone or tablet being used to that device and the 201 control box (006-2473SB).
- 6. When using a Dye Marker, the End of Bale Sensor kit will need to be added to the system in order to see when needle arm cycles. Part number (200FCA). Connect the sensor to the End of Bale (EOB) connection on the Baler Pwr/Comm Harness (006-2470SS).
- 7. When using the optional Dye Marker (200DM) connect 4 pin round end of the H2O harness (006-2470C) to the Dye Marker (DM) connection on the (006-2470SS) harness. Then connect the two straight spade connections with only the white wire to the push switch (006-2850). The remaining two connections with 90-degree female spades will connect to the pump.

#### System wiring diagram



<sup>\*</sup>If needed an optional 8' Pwr/Comm harness extension is available (not included), part number 006-2470BL2.


#### **Downloading H2O App**

The H2O App is available on any Apple or Android device running with the current operating system software and one previous version. Download the app by searching for H2O Sensor. App icon shown right.




#### **Screen Definitions**

#### **Main Screen**




## **Settings Screen**




## Operation

After installation of the H2O app, turn the system on by turning the key in the tractor on. When the connection is made the green light on the control box will illuminate.


#### **Reading Moisture**



When hay begins to enter the bale chamber, current moisture will be displayed



If the moisture being read is Less Than 5% the reading will appear as shown above




If the moisture being read is Greater Than 33% the reading will appear as shown above

#### **Dye Marker System**



When using the dye marker turn on the setting as shown and select the desired moisture to mark a bale.
\*Bales at or above this moisture level will be marked.




Dye Marker icon will now appear on the home screen. The last bale moisture will be highlighted in red and the bale will be marked at or above the set moisture.

#### **Dye Marker Notes**

- When the Dye Marker is activated by the moisture setting it will spray 3 seconds once per End of Bale (EOB) cycle. After an EOB signal the dye marker is then reset to be able to spray again for 3 seconds once on the next bale.
- A full tank of dye is estimated to mark 50-60 bales.

#### **Dye Marker Override**



If you would like to mark a bale for any reason, press the bale icon which will cause it to turn green. When the manual override is used the last bale moisture will not highlight in red.

The manual spray function can be used on a bale as many times as preferred in 3 second intervals.

#### **H2O Firmware Update through App**


When there is an update available for the H2O system the following information will appear, and the steps listed will need to be followed.


Once an operator downloads the app update (internet connection required) the "update available" symbol will appear along with the version number of the available update once connected to the system.

At this point the system can run without updating if the operator chooses. The icon will simply remain on the screen.

Once the operator decides to perform the software update, they will press the version number or upload arrow to begin.

Internet connection is not required to perform the update to the module once the app is downloaded






Once the update is initiated, the system will enter update mode


The status light will turn red

A green loading symbol will begin to circulate on the screen



A status bar with then appear to show the update progress

This can take 3-5 minutes to load software




Once the status bar load completely, the system will boot back up


The status light will again turn green


The updated version number will be shown at the bottom of the screen


It is recommended for proper communication that the original phone/tablet power cable is used. Many lower cost power cables do not meet requirements to properly charge and communicate to the Harvest Tec H2O module.


## **Pin Outs**











H2O Wired Moisture Control 006-2473SB Pin 1 Red Module Power Pin 2 Red/Black EOB

+

Pin 3 Black EOB -

Pin 4 Grey Left Moisture Sensor

Pin 5 Brown Right Moisture Sensor

Pin 6 Purple EOB Signal

Pin 7 Yellow CAN +

Pin 8 Green CAN -

Pin 9 Red/White Dye Marker 12V + Pin 10 Black/White Dye Marker 12V - Pin 11 Blue

D

D

ye Marker Prime

Pin 12 Black Ground

#### H2O Wired Power Harness 006-2470P

Pin 1 Red Module Power Pin 2 Red/Black EOB +

Pin 3 Black EOB –

Pin 4 Grey Left Moisture Sensor

Pin 5 Brown Right Moisture Sensor

Pin 6 Purple EOB Signal

Pin 7 Yellow Not Used

Pin 8 Green Not Used

Pin 9 Red/White Dye Marker 12V + Pin 10 Black/White Dye Marker 12V - Pin 11 Blue

ye Marker Prime

Pin 12 Black Ground

#### Baler Communication Harness 006-2470SS

Pin 1 Red/Black EOB + Pin 2 Black EOB -

Pin 3 Purple Left Moisture Sensor

Pin 4 Grey Right Moisture Sensor

Pin 5 Brown EOB Signal

Pin 6 Red/White Dye Marker 12V + Pin 7 Black/White Dye Marker 12V - Pin 8 Blue

Dye Marker Prime

## End of Bale Sensor (EOB) 006-2471B

Pin 1 Brown EOB +

Pin 2 Blue EOB -

Pin 3 N/A Not Used

Pin 4 Black EOB Signal

## Dye Marker H2O Harness 006-2470C

Pin 1 Red DS +


Pin 2 Black DS -

Pin 3 White DS Prime

Pin 4 N/A Not Used

## **Parts Breakdowns**

## Star Wheel assembly 030-4642UX



Ref	Description	Part#	Qty
1	Star Wheel	006-4642US	1
	Star Wheel w insert (includes 1, 8, & hardware)	030-4642US	
2	Dust Seal (per side)	006-4642DSL	2
3	Wiring Grommet	008-0821A	1
4	Block	006-4642UB	1
5	Thrust Washer	006-4642TA	2
6	Thrust Bearing	006-4642TB	1
7	3/4" Short Nut	006-4642U	1

8	Swivel Insert	006-4642B	1
9	Rotary Swivel	006-4642A	1
10	Gasket	006-4642UG	1
11	Block Cover	006-4642UC	1
	Hardware kit (items 2, 5, 6, 7)	006-4642UK	
NP	Spacer Plate	001-6707ES	2
	Star wheel assembly	030-4642UX	2
	*Optional Twine Guard-Right	001-4644	
	*Optional Twine Guard-Left	001-4644	


<sup>\*</sup>Can be added if twine excessively makes contact with star wheels

## **Control Box & Harnesses**




Ref	<u>Description</u>	Part #	Qty
1	Baler Pwr/Comm Harness	006-2470SS	1
2	201 Series Control Box	006-2473SB	1
3	Tractor Power Harness	006-2470P	1
Optional 8'	power/comm harness extension	006-2470BL2	

## **Fixed Chamber End of Bale Sensor Kit**



Ref	<u>Description</u>	Part #	<u>Qty</u>	Ref	Description	Part #	<u>Qty</u>
1	End of Bale Sensor	006-7400	1	3	EOB Extension	006-7400EXT	1
2	End of Bale Bracket	001-4648RB	1		Complete Kit	200FCA	

## **H2O Dye Marker**



Ref	<u>Description</u>	Part #	<u>Qty</u>	Ref	Description	Part #	<u>Qty</u>
1	H2O Harness (10')	006-2470C	1	8	1/4" Street Elbow	003-SE14F	2
2	Tank & Pump	005-9015	1	9	Check Valve	007-1207VB	2
3	Nozzle Cap	004-4723	4	10	1/4" Straight Fitting	003-A1414VB	2
4	Tip – Brass	004-TX-5	2	11	Push Switch	006-2850	1
5	Tip Strainer (Green)	004-1203-100	2	12	1/4" All Barb Tee	003-T1414	1
6	Nozzle Body	004-4722	2	13	Mini Hose Clamp	003-9002	6
7	Nozzle Holder	001-4215	2	14	1/4" Hose	002-9006	40
				NP	Red Dye	009-0800	1
				NP	End of Bale Sensor Kit	200FCA	1
				Complete Assembly		030-200DM	

## Harvest Tec Inc. Warranty and Liability Agreement

Harvest Tec, Inc. will repair or replace components that are found to be defective within 12 months from the date of manufacture. Under no circumstances does this warranty cover any components which in the opinion of

Harvest Tec, Inc. have been subjected to negligent use, misuse, alteration, accident, or if repairs have been made with parts other than those manufactured and obtainable from Harvest Tec, Inc.

Our obligation under this warranty is limited to repairing or replacing free of charge to the original purchaser any part that in our judgment shows evidence of defective or improper workmanship, provided the part is returned to Harvest Tec, Inc. within 30 days of the failure. If it is determined that a non-Harvest Tec branded hay preservative has been used inside the Harvest Tec applicator system where the failure occurred, then Harvest Tec reserves the right to deny the warranty request at their discretion. Parts must be returned through the selling dealer and distributor, transportation charges prepaid.

This warranty shall not be interpreted to render Harvest Tec, Inc. liable for injury or damages of any kind, direct, consequential, or contingent, to persons or property. Furthermore, this warranty does not extend to loss of crop, losses caused by delays or any expense prospective profits or for any other reason. Harvest Tec, Inc. shall not be liable for any recovery greater in amount than the cost or repair of defects in workmanship.

There are no warranties, either expressed or implied, of merchantability or fitness for particular purpose intended or fitness for any other reason.

This warranty cannot guarantee that existing conditions beyond the control of Harvest Tec, Inc. will not affect our ability to obtain materials or manufacture necessary replacement parts.

Harvest Tec, Inc. reserves the right to make design changes, improve design, or change specifications, at any time without any contingent obligation to purchasers of machines and parts previously sold.

HARVEST TEC, INC.

P.O. BOX 63

**2821 HARVEY STREET HUDSON, WI 54016 USA** PHONE: 715-386-9100

FAX: 715-381-1792

Email: info@harvesttec.com

#### **DECLARATION OF INCORPORATION**



#### **MANUFACTURER:**

Harvest Tec Inc. 2821 Harvey St. P.O. Box 63 Hudson, WI 54016, U.S.A.

#### REPRESENTATIVE ESTABLISHED IN COMMUNITY:

Profitable Farming Company Middle Barlington, Roborough Winkleigh, Devon, EX19 8AG ENGLAND The person above certifies and declares that:

VIRTUAL MACHINE: Equipment mounted on a farm press to monitor moisture.

MODEL: H2O Sensor-Owners-201SS-19-Imp&Metric

BRAND: Harvest Tec SERIAL NUMBER:


This Harvest Tec moisture system meets the Directive 2006/42/EC of the European Parliment and the Council of 17 May 2006 and other applicable European Directives including Directive 2014/53/EU on the Radio Equipment Directive and 2014/30/EU

The Harvest Tec moisture system will be turned on after being installed on a farm press which has been declard in conformity with the Machinery Directive.

Person in the community authorized to provide information on the partly completed machinery and making this statement:

Richard Snell, President, Profitable Farming Company Signed on May 21, 2011: Middle Barlington, Roborough Winkleigh, Devon, EX19 8AG ENGLAND

#### **Documents / Resources**



Manuals+