


HARVEST HTG-TEC-GUI-001 Media Encoder User Guide

[Home](#) » [Harvest](#) » HARVEST HTG-TEC-GUI-001 Media Encoder User Guide 



MEDIA ENCODER NQE
Quick Start Guide



Contents


- [1 Overview](#)
- [2 In the Box](#)
- [3 Installation](#)
- [4 Configuration](#)
- [5 Troubleshooting](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Overview


Welcome to the Nodestream Quad Encoder (NQE)

Please read these instructions carefully before using this product and save this quick start guide for future reference. See the User Manual for full details via the QR code on the back page.

Video and two-way audio streaming solution



In the Box



Nodestream Quad Decoder



USB keyboard/mouse



4 x mini Display Port
to HDMI adaptor





Power cable
(region specific)





USB speakerphone

Rear Connections




Power
Switch

Power
Socket



IMPORTANT: 100-240VAC 47/63HZ only (UPS recommended).
Do not use the Display Port or HDMI for output to a monitor. (Use the Mini-Display port only).

Front Connections




Installation

The NQE is designed to be mounted in a standard 19" Rack and occupies 3U of space




Ensure there is adequate spacing around the NQE device for cooling. Cooling air travels in the direction shown by the arrows. No vertical loading on the NQE device.

1 Install at 4 mount points




2 Connect




Configuration

1. Switch on the power (rear of device)
2. Initial Configuration (monitor, keyboard/mouse required) On initial boot an on-screen GUI displays, if required, configure network settings (see User Manual)




3. Select Run System to start Nodestream software

4. Typical start sequence (with a monitor connected)



5. Refer to the Nodester application for device status and connection management



Once Run System is selected, the Nodestream software will start automatically when the device is

power cycled. To access the on-screen GUI, power cycle the device and select stop applications when prompted.

 User Resources	
https://qrco.de/bcfxAB	Contact and Support support@harvest-tech.com.au

Troubleshooting


Issue	Cause	Resolution
Device not powering	PSU switch is set to off position AC not connected	Confirm AC is connected and switch is in the on position
Video sources not displaying	Source(s) not connected or powered on	Confirm video source(s) connected and powered on Test source with alternate display
No display output	Video output device not connected or powered on Damaged cable	Confirm video output device is connected and powered on Change out cable
No network – “Connection error. Check the network settings message displayed	No connection to the server	Check Ethernet cable plugged in Ensure required firewall ports settings are correct (see User Manual) Check network settings, contact your network 1



Harvest Technology Pty Ltd
7 Turner Ave, Technology Park
Bentley WA 6102, Australia
www.harvest.technology

recording, or otherwise without the written consent of the Managing Director of Harvest Technology Pty Ltd.
HTG-TEC-GUI-001_2

Documents / Resources

	<p>HARVEST HTG-TEC-GUI-001 Media Encoder [pdf] User Guide HTG-TEC-GUI-001 Media Encoder, HTG-TEC-GUI-001, Media Encoder</p>
---	---

References

- [🌐 Turner Rooms for Rent](#)