

HFCL ion4l2-CPE Wi-Fi Solutions to Bridge Digital Divide User Guide

Home » HFCL » HFCL ion4l2-CPE Wi-Fi Solutions to Bridge Digital Divide User Guide 1

Contents

- 1 HFCL ion4l2-CPE Wi-Fi Solutions to Bridge Digital **Divide**
- 2 Introduction
- **3 Packaging Content**
- **4 Product Overview**
- 5 Mounting of ion412_CPE
- 6 Getting the ion412_CPE Online
- **7 Safety Precautions**
- 8 Documents / Resources
- 9 Related Posts



HFCL ion4l2-CPE Wi-Fi Solutions to Bridge Digital Divide



Introduction

Thank you for choosing the IO's Unlicensed Band Radio (UBR). Enterprise Grade point-to-point and point-to-multipoint solution is optimally designed to support low to medium capacity enterprise applications in unlicensed 5 GHz spectrum for short and long range links.

Packaging Content





Quick Start Guide (Qty:1)



Pole Holder (Qty:1)



Hose Clamp (Qty:1)



PoE Injector (24V) (Qty:1)

ion412_CPE Specifications	
Peak Throughput (aggregate)	Up to 300 Mbps Aggregate UUDL Throughput
MIMO	2X2
Modulation	Upto256 QAM
Channel Bandwidth	10/20/40 MHz
Wireless QoS	802.lle WMM

Wireless Security	WPA, WPA2, & 128-bit AES-PSK with hardware acceleration
Power Supply	IEEE 802.3af 24V Passive PoE
Power Consumption (Max)	<15W
Antenna Type	Integrated High Performance Antenna
Antenna Gain	23 dBi
Management	Standalone (via GUI) or through appliance-based EMS or cloud-based
Enclosure Dimensions	328 x 305 x 122 mm or 12.9 x 12 x 4.8 inches
Weight	1.04 kg
Operating Temperature	o·c to ss·c
Certifications	CE, FCC Class A, RoHS 3.0 , IP67

Product Overview



LAN + PoE Port(with gland)
Power up the device using PoE Injector and
a regular Ethernet Cable

Mounting of ion412_CPE

The ion4l2...CPE can be mounted on a pole. Perform the following steps for appropriate installation. **Pole Mount**

To mount ion4I2...CPE on a pole, use the pole holder & the hose clamp provided.

1. Attach the pole holder to the backside of the CPE.



2. The hose clamp is slided through the back of ion4I2_CPE as shown below.



3. Wrap the hose clamps around the pole. Tighten the strap by turning the screws clockwise.



Getting the ion412_CPE Online

Step 1 : Power up ion4I2_CPE can be powered up using PoE Injector (24V) as shown below:




Note: For powering on the CPE, use only HFCL PoE Injector supplied along with the unit. Plug and Adaptor will vary by country/ region.


Step 2: Login and Configure the CPE

Follow the steps mentioned below and connect CPE to a network :

- 1. Connect ethernet cable to the laptop/ computer.
- 2. Connect the other end of ethernet cable to the data port on PoE Injector.
- 3. Connect CPE's PoE supported ethernet port to PoE Injector power port. Device will get powered up.



- 4. Open web browser and enter "CPE IP address" in the address bar. The default static IP address for 2×2 CPE is set to "192.168.1.1".
- 5. A login screen will appear.
- 6. Enter the default login credential details: User- admin, Password- HFcl!@23#ion



7. Refer our user manual on our website io.hfcl.com for detailed information to configure CPE

Safety Precautions

Observe following safety precautions to avoid damage to the ion4I2_CPE:

- Do not power the device during installation
- Do not subject the device to high temperatures
- Keep away from high voltage cables
- Do not power off the unit in the middle of an \v upgrade process
- · The gland should be ground facing all the time

- Do not open the enclosure when the CPE is working
- · Fasten the device tightly

Contact Us:

Email: iosupport@hfcl.com
Website: www.hfcl.com
www.io.hfcl.com

8, Commercial Complex, Masjid Moth, Greater Kailash-11, New Delhi- 110048

Documents / Resources



HFCL ion4l2-CPE Wi-Fi Solutions to Bridge Digital Divide [pdf] User Guide ion4l2-CPE Wi-Fi Solutions to Bridge Digital Divide, ion4l2-CPE, Wi-Fi Solutions to Bridge Digit al Divide, Bridge Digital Divide, Divide

Manuals+,