

# **HME CU60 ZOOM Nitro Drive-Thru Timer User Guide**

Home » HME » HME CU60 ZOOM Nitro Drive-Thru Timer User Guide 1


**HME CU60 ZOOM Nitro Drive-Thru Timer** 



# Contents 1 ZOOM Nitro Drive-Thru Timer Overview 2 How to make changes to your ZOOM Nitro Timer 3 Drive-Thru Leaderboard® 4 Your System 5 Customer Support 6 Documents / Resources 6.1 References 7 Related Posts

### **ZOOM Nitro Drive-Thru Timer Overview**

Measures drive-thru lane events for comparison to your service time goals at up to eight detection points in the drive-thru lane. The Dashboard displayed below provides an example overview for a single-lane drive-thru with six lane detectors (MENU 1, CASHIER, SERVICE, and three Pull-Forward detectors) as well as two independent detectors (Mobile Pickup).




### So what's with the colors?

Color-coded cars and values provide an easy method for identifying how a metric is performing against a preset goal. Goals are used to motivate performance.

- A green car or value like this 0:29 indicates you are exceeding your goal.
- A yellow car or value like this 2:01 indicates you are meeting your goal.
- A red car or value like this indicates you are not meeting your goal.

### How to make changes to your ZOOM Nitro Timer

1. To edit your Dashboard, use a mouse connected to the USB port on the CU or use a back-office PC if configured on the same network. Click on to open screen below.



### **Drive-Thru Leaderboard®**


The Drive-Thru Leaderboard shows the top three and bottom three stores ranked against others in your network. Your store will be outlined and displayed with its closest competitors.

# **Top 3 Stores**

Top 3 performing stores in your network.

# **Your Store**

Your store will always be outlined and displayed with its closest competitors.



Also, visit the HME Training Portal at: <a href="https://www.hme.com/training">https://www.hme.com/training</a>



# **Your System**

# **Timer Signal Processor (TSP)**

Receives event data from car detections in a drive-thru lane or reserved parking location.



# **TSP Mounted location:**

Control Unit (CU) Receives and processes data from the TSP to provide information for the ZOOM Dashboard display.



## **CU Mounted location:**

Need more help?



# **Customer Support**

A copy of this guide and more information can be found by scanning this QR code above. When you land on the web page, navigate to Drive-Thru Timer Systems and click/tap on ZOOM Nitro to expand.

Or go to: <a href="https://www.hme.com/gsr/drive-thru-user-manuals">https://www.hme.com/gsr/drive-thru-user-manuals</a>

Need help? Call 1-800-848-4468, options 1,2,3 or email us at <a href="mailto:support@hme.com">support@hme.com</a> HME, INC. 2848 Whiptail Loop, Carlsbad, CA 92010 USA

Fax: 858-552-0172 | www.hme.com



### **Documents / Resources**



HME CU60 ZOOM Nitro Drive-Thru Timer [pdf] User Guide

CU60 ZOOM Nitro Drive-Thru Timer, CU60, ZOOM Nitro Drive-Thru Timer, Nitro Drive-Thru Timer, Drive-Thru Timer, Thru Timer, Timer

### References

- IME | Specialized Communications, Audio, & Software Solutions
- IME HME Training Portal
- <u>Drive-Thru Systems User Manuals | Drive-Thru Repairs | HME</u>
- Trive-Thru Systems User Manuals | Drive-Thru Repairs | HME
- HME Training Portal

Manuals+,