




Homematic IP HmIP-eTRV-C-2 Wireless Thermostatic Radiator Instruction Manual








[Home](#) » [Homematic IP](#) » Homematic IP HmIP-eTRV-C-2 Wireless Thermostatic Radiator Instruction Manual 

homematic 

**Montage- und
Bedienungsanleitung**
Mounting instruction and operating manual

Radiator Thermostat – compact p. 33







Contents

- 1 Information about this manual
- 2 Hazard information
- 3 Function and device overview
- 4 General system information
- 5 Mounting
- 6 Mounting the radiator thermostat
- 7 Support ring
- 8 Adapter for Danfoss
- 9 Danfoss RA
- 10 Danfoss RAV
- 11 Danfoss RAVL
- 12 Adaption run
- 13 Mounting the disassembly protection
- 14 Replacing batteries
- 15 Troubleshooting
- 16 Command not confirmed
- 17 Duty cycle
- 18 Error codes and flashing sequences
- 19 Restore factory settings
- 20 Maintenance and cleaning
- 21 General information about radio operation
- 22 Technical specifications
- 23 Subject to technical changes.
- 24 Information about conformity
- 25 Documents / Resources
- 26 Related Posts



Information about this manual






Please read this manual carefully before beginning operation with your Homematic IP component. Keep the manual so you can refer to it at a later date if you need to. If you hand over the device to other persons for use, please hand over this manual as well.

Symbols used:

	Attention! This indicates a hazard.
	Please note This section contains important additional information.

Hazard information

	Do not open the device. It does not contain any parts that can be maintained by the user. In t ve the device checked by an expert.
	For safety and licensing reasons (CE), unauthorized change and/or modification of the device is not permitted.

	The device may only be operated in dry and dustfree environment and must be protected from the eff olar radiation, cold and mechanical loads.
	The device is not a toy; do not allow children to play with it. Do not leave packaging material lying aro of polystyrene, etc. can be dangerous in the hands of a child.
	We do not assume any liability for damage to property or personal injury caused by improper use or tl d information. In such cases, any claim under warranty is extinguished! For consequential damages, '
	Please note that the room temperature control via the radiator thermostat is designed for a twopipe h nd return line per radiator. Use in single-pipe heating systems can lead to strong deviations in the set ns in the flow temperature.
	The device may only be operated within domestic environment, in business and trade areas as well as in small enterprises.



Using the device for any purpose other than the intended use described in the operating manual does not fall within the scope of the warranty and may invalidate any warranty or liability.

Function and device overview

With the Homematic IP Radiator Thermostat, you can conveniently regulate the room temperature in your smart home via the Homematic IP smartphone app according to your personal needs. Individual temperature profiles can easily be created via the app – with up to 3 configurable heating profiles and 13 changes per day.

The radiator thermostat fits to all common radiator valves and is easy to mount – without having to drain any water or intervene in the heating system. Thanks to the automatic weekly valve descaling run and the long battery lifetime of up to five years (typically), the radiator thermostat requires a minimum of maintenance.

With the supplied disassembly protection, the radiator thermostat is protected against theft. The disassembly protection is ideal for use in public institutions or office buildings and is easy to install on the radiator valve without additional mounting tools. The tamper contact will alert you in the Homematic IP the app about manipulation, for example, unauthorized opening of the battery compartment.

Device overview (see figure 1):




- (A) Metal nut
- (B) Battery compartment cover
- (C) System button (teach-in button and LED)
- (D) Tamper contact
- (E) Battery compartment
- (F) Lock

General system information

This device is part of the Homematic IP smart home system and works with the Homematic IP protocol. All devices of the system can be configured comfortably and individually with the user interface of the Central Control Unit CCU3 or flexibly via the Homematic IP smartphone app in connection with the Homematic IP cloud. All available functions provided by the system in combination with other components are described in the Homematic IP Wired Installation Guide. All current technical documents and updates are provided at www.homematic-ip.com.

Start-up

Teaching-in

	<p>Please read this entire section before starting the teach-in procedure.</p>
	<p>You can connect the device either to the Access Point or to the Homematic Central Control Unit of unit, please refer to the Homematic IP User Guide, available for download in the download area of www.homematic-ip.com.</p>
	<p>First set up your Homematic IP Access Point via the Homematic IP app to enable operation of o er to the operating manual of the Access Point.</p>

To integrate the radiator thermostat into your system and to enable control via the Homematic IP app, you must teach-in the device to your Homematic IP Access Point first.

To teach-in the radiator thermostat, please proceed as

follows: • Open the Homematic IP app on your smart-phone.

- Select the menu item **“Teach-in device”**.
- Open the lock (F) of the battery compartment (E) using the supplied four Allen head wrench (see figure 2).
- Remove the battery compartment cover (B) to the back and downwards to remove it from the device (see figure 3).
- Remove the insulation strip from the battery compartment of the radiator thermostat. The teach-in mode remains activated for 3 minutes.

	<p>You can manually start the teach-in mo pressing the system button (C) shortly</p>
---	--

- Your device will automatically appear in the Homematic IP app.
- To confirm, please enter the last four digits of the device number (SGTIN) in your app or scan the QR code. Therefore, please see the sticker supplied or attached to the device.
- Please wait until the teach-in is completed.
- If teaching-in was successful, the LED (C) lights up green. The device is now ready for use. If the LED lights up red, please try again.
- In the app, give the device a name and allocate it to a room.
- Do not yet close the battery compartment (see „5.3 Adaption run“ on page 48).

Mounting



Please read this entire section before

The Homematic IP Radiator Thermostat is easy to install, and can be done without draining heating water or intervening in the heating system. No special tools are required, nor does the heating have to be switched off.

The metal nut **(A)** attached to the radiator thermostat can be used universally and without accessories for all valves with a thread size of M30 x 1.5 from the most popular manufacturers such as Heimeier, MNG, Junkers, Landis&Gyr (Duodyr), Honeywell-Braukmann, Oventrop, Schlösser, Comap, Valf Sanayii, Mertik Maxitrol, Watts, Wingenroth (Wiroflex), R.B.M, Time, Jaga, Siemens and Ingmar.

By means of the adapters in the delivery, the device can also be installed on radiator valves of type Danfoss RA, Danfoss RAV and Danfoss RAVL (see „5.2.3 Adapter for Danfoss“ on page 44).

Mounting the radiator thermostat



In case of visible damage of the e please contact a specialist.

Remove the old thermostat dial from your radiator valve. To do this, please proceed as follows:

- Rotate the thermostat dial to the maximum value **(G)** anti-clockwise (see figure 5). The thermostat dial then no longer presses against the valve spigot, making it easier to remove.

There are different ways of fixing the position of the thermostat dial:

- **Union nut:** Unscrew the union nut in an anticlockwise direction **(F)**. The thermostat head can then be removed **(H)**.
- **Snap-on fastenings:** Thermostat dials that are fastened this way can be detached by turning the fastener/union nut a little bit counter-clockwise **(F)**. The thermostat head can then be removed **(H)**.
- **Compression fitting:** The thermostat dial is held in place by a mounting ring which is held together with a screw. Loosen this screw and remove the thermostat head from the valve **(H)**.
- **Threaded connection with set screw:** Loosen the set screw and remove the thermostat head (**H**).

After removing the old thermostat dial you can mount the Homematic IP Radiator Thermostat with the metal nut **(A)** to the radiator valve (see figure 6). If required, you can use one of the supplied adapters for Danfoss valves (see „5.2.3 Adapter for Danfoss“ on page 44) or the supplied support ring (see „5.2.2 Support ring“ on page 44).

Support ring

The valves from different manufacturers may have tolerance fluctuations that make the radiator thermostat

more loosely seated on the valve. In this case, the provided support ring (I) should be placed into the flange before mounting the radiator thermostat (see figure 7).

Adapter for Danfoss

One of the provided adapters is required to attach to Danfoss valves. The assignment of the suitable adapter to the relevant valve can be found in the following illustrations.


	Please ensure that you do not trap you he adapter!
---	--

The RA and RAV adapters have been manufactured with pre-tension in order to provide a better seat. Use a screwdriver during installation if necessary, and bend it open


slightly in the vicinity of the screw (see following figures).

Danfoss RA

The Danfoss valve bodies have elongated notches (1) around their circumference, which also ensure that the adapter is properly seated when it snaps on.

	During installation, please e notches (1) on the valve d on.
---	--

After clipping onto the valve body, please attach the adapter using the provided screw and nut.




Danfoss RAV

The Danfoss valve bodies have elongated notches (1) around their circumference, which also ensure that the adapter is properly seated when it snaps on.


	During installation, please ensure the notches (1) on the valve body are properly clipped on.
---	---

The lifter extension (3) must be fitted to the valve pin of RAV valves prior to installation.




Danfoss RAVL

The Danfoss valve bodies have elongated notches (1) around their circumference, which also ensure that the adapter is properly seated when it snaps on.

	During installation, please ensure the notches (1) on the valve body are properly clipped on.
---	---

The adapter RAVL does not have to be screwed.



Adaption run

	<p>Once the batteries have been in</p>
--	--

After the valve pins has been reversed completely (motor no longer moves), the radiator thermostat can be moved (see figure 6). An adaption run has to be performed in order to adapt the device to the valve. To do this, please proceed as follows:

- To start the adaption run, close the battery compartment (E) using the square key (see figure 2+3). The adaption run is alternatively started 3 minutes after reaching the valve pin end position. Now, the radiator thermostat performs the adapting run. After the adaption run, installation is completed and the device can be individually configured and controlled.

	<p>If the adaption run was initiated, the device LED (C) lights up and the audible signalling device is activated. The battery compartment lock (F) is used to return the device to the valve pin end position.</p>
---	---

Mounting the disassembly protection


If required, you can use the supplied disassembly protection to protect the radiator thermostat against theft and unauthorized disassembly. For the installation, please proceed as follows:

- Place the upper (**J**) and lower (**K**) shell above the nut or the pre-mounted radiator thermostat and allow the

parts to snap into place.



After engaging the upper and lower st
ted.



Replacing batteries




If the flashing code for empty batteries is indicated via the device LED **(C)** (see „7.4 Error codes and flashing sequences“ on page 54) or if the symbol for empty batteries appears in the app, replace the used batteries by two new LR6/mignon/AA batteries. You must observe the correct battery polarity.

To insert the batteries into the radiator thermostat, please proceed as follows:

- Open the lock **(F)** of the battery compartment **(E)** using the supplied four Allen head wrench (see figure 2).
- Remove the battery compartment cover **(B)** to the back and downwards to remove it from the device (see figure 3).
- Remove the empty batteries.
- Insert two new 1.5 V LR6/mignon/AA batteries into the battery compartment, making sure that you insert them the right way round (see figure 8)
- Re-insert the battery compartment cover and close the battery compartment using the square key.
- Please pay attention to the flashing signals of the device LED while inserting the batteries (see „7.4 Error codes and flashing sequences“ on page 54).

Replacing batteries

Once the batteries have been inserted, the radiator thermostat will perform a self-test (approx. 2 seconds). Afterward, initialization is carried out. The LED test display will indicate that initialisation is complete by lighting up orange and green.

	Caution! There is a risk of explosion if the battery is not replaced correctly. Replace only batteries. Do not throw the batteries into a fire. Do not expose batteries to excessive heat.
	Caution! Avoid skin and eye contact with leaking batteries! Wear suitable protective gloves. In case of skin contact flush with plenty of water!
	Used batteries should not be disposed of with regular domestic waste! Instead, take them to a recycling point.

Troubleshooting

Weak batteries

Provided that the voltage value permits it, the radiator thermostat will remain ready for operation also if the battery voltage is low. Depending on the particular load, may be possible to send transmissions again repeatedly once the batteries have been allowed a brief recovery period. If the voltage drops too far during transmission, the corresponding error code will be displayed on the device (see „7.4 Error codes and flashing sequences“ on page 54). In this case, replace the empty batteries by two new batteries (see „6 Replacing batteries“ on page 50).

Command not confirmed

If at least one receiver does not confirm a command, the device LED **(C)** lights up red at the end of the failed transmission process. The failed transmission may be caused

by radio interference (see „10 General information about radio operation“ on page 57). The failed transmission may also be caused by the following:

- The receiver cannot be reached.
- Receiver is unable to execute the command (load failure, mechanical blockade, etc.).
- The receiver is defective.

Duty cycle

The duty cycle is a legally regulated limit of the transmission time of devices in the 868 MHz range. The aim of this regulation is to safeguard the operation of all device working in the 868 MHz range. In the 868 MHz frequency range we use, the maximum transmission time of any device is 1% of an hour (i.e. 36 seconds in an hour). Devices must cease transmission when they reach the 1% limit until this time restriction comes to an end. Homematic IP devices are designed and produced with 100% conformity to this regulation. During normal operation, the duty cycle is not usually reached. However, repeated and radio-intensive teaching processes mean that it may be reached in isolated instances during start-up or initial installation of a system. If the duty cycle is exceeded, this is indicated by one long red flashing of the device LED **(C)** and may manifest itself in the device temporarily working incorrectly. The device starts working correctly again after a short period (max. 1 hour).

Error codes and flashing sequences

Flashing code	Meaning	Solution
Short red flashing in 10 s intervals	Valve drive sluggish or adjustment range too small	Please check whether the valve pin is stuck.
Short red flashing in 10 s intervals	Actuating range too wide	Please check the fastening if the radiator thermostat
Short orange flashing	Radio transmission/ attempting to transmit/configuration data is transmitted	Wait until the transmission is completed.
1x long green lighting	Transmission confirmed	You can continue operation.
1x long red lighting	Transmission failed or duty cycle limit is reached	Please try again (see sec. 7.2 Command not confirmed" on page 52 or 7.3 Duty cycle" on page 53).

Short orange flashing (every 10 s)	Teach-in mode active	Please enter the last four numbers of the device serial number to confirm (see 5.1 Teaching-in" on page 40).
Short orange lighting (after green or red confirmation)	Batteries empty	Replace the batteries (see „6 Replacing batteries" on page 50).
6x long red flashing	Device defective	Please see your app for error message or contact your retailer.
1x orange and 1 x green lighting (after inserting batteries)	Test display	Once the test display has stopped, you can continue.
Long and short orange flashing (alternating)	Update of device software (OTA U)	Wait until the update is completed.

Restore factory settings

	The factory settings of the device will be restored. If you do this, you will lose all your settings.
---	---

- To restore the factory settings of the radiator thermostat, please proceed as follows:
- Open the lock (F) of the battery compartment (E) using the supplied four Allen head wrench (see figure 2).
- Remove the battery compartment cover (B) to the back and downwards to remove it from the device (see figure 3).
- Remove a battery.
- Insert the battery ensuring that the polarity is correct (see figure 8) while pressing and holding down the system button (C) for 4s at the same time, until the LED will quickly start flashing orange (see figure 4).
- Release the system button again.
- Press and hold down the system button again for 4 seconds, until the LED lights up green.
- Release the system button to finish the procedure

The device will perform a restart.

Maintenance and cleaning



The device does not require you to changing the battery when necessary. It requires repairs.

Clean the device using a soft, lint-free cloth that is clean and dry. Do not use any detergents containing solvents, as they could corrode the plastic housing and label.

General information about radio operation

Radio transmission is performed on a non-exclusive transmission path, which means that there is a possibility of interference occurring. Interference can also be caused by switching operations, electrical motors or defective electrical devices.



The range of transmission within building is in the open air. Besides the transmission characteristics of the receiver, environmental conditions have an important role to play in conditions.

Hereby, eQ-3 AG, Maiburger Str. 29, 26789 Leer/Germany declares that the radio equipment type Homematic IP HmIP-eTRV-C-2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.homematic-ip.com

Technical specifications

Device short name: HmIP-eTRV-C-2

Supply voltage: 2x 1.5 V LR6/mignon/AA

Current consumption: 100 mA max.

Battery life: 5 years (typ.)

Degree of protection: IP20

Degree of pollution: 2

Ambient temperature: 0 to 50 °C

Dimensions (W x H x D): 51 x 98 x 48 mm

Weight: 172 g (including batteries)

Radiofrequency band: 868.0-868.6 MHz 869.4-869.65 MHz

Maximum radiated power: 10 dBm

Receiver category: SRD category 2

Typ. open area RF range: 250 m

Duty cycle: < 1 % per h < 10 % per h

Construction of the regulation and control unit: independently mounted electronic regulation and control unit

Method of operation: Type 1

Connection: M30 x 1.5 mm

Controlling torque: > 80 N

Valve travel: 4,3 ± 0,3 mm

Maximum travel position: 14,3 ± 0,3 mm

Minimum travel position: 10,0 ± 0,3 mm



Software class: Class A

Subject to technical changes.

Instructions for disposal

	Do not dispose of the device in the household waste. It must be disposed of at local collection points in compliance with the Waste Electrical and Electronic Equipment (WEEE) Directive.
---	---

Information about conformity


	The CE sign is a free trading sign addressed exclusively to the authorities.
	For technical support, please contact your retailer.

Kostenloser Download der Homematic IP App! Free download of the Homematic IP app!



<https://itunes.apple.com/de/app/homematic-ip/id1012842369?mt=8>
<https://play.google.com/store/apps/details?id=de.eq3.pscc.android&hl=de>

Documents / Resources

	<p>Homematic IP HmIP-eTRV-C-2 Wireless Thermostatic Radiator [pdf] Instruction Manual HmIP-eTRV-C-2, IP Wireless Thermostatic Radiator, HmIP-eTRV-C-2 IP Wireless Thermostatic Radiator, Wireless Thermostatic Radiator, Thermostatic Radiator</p>
---	--