

homematic IP HmIP-HAP Smart Home Access Point Instruction Manual

Home » Homematic IP » homematic IP HmIP-HAP Smart Home Access Point Instruction Manual





Installation and operating manual

Contents

- 1 HmIP-HAP Smart Home Access Point
- 2 Package contents
- 3 Information about this manual
- 4 Hazard information
- 5 Homematic IP Smart living, simply comfortable
- 6 Function and device overview
- 7 Start-up
- 8 Troubleshooting
- 9 Restore factory settings
- 10 Maintenance and cleaning
- 11 General information about radio operation
- 12 Disposal
- 13 Technical specifications
- 14 Documents / Resources
 - 14.1 References

HmIP-HAP Smart Home Access Point

Documentation © 2015 eQ-3 AG, Germany

All rights reserved. Translation from the original version in German. This manual may not be reproduced in any format, either in whole or in part, nor may it be duplicated or edited by electronic, mechanical or chemical means, without the written consent of the publisher.

Typographical and printing errors cannot be excluded. However, the information contained in this manual is reviewed on a regular basis and any necessary corrections will be implemented in the next edition. We accept no liability for technical or typographical errors or the consequences thereof.

All trademarks and industrial property rights are acknowledged.

Changes may be made without prior notice as a result of technical advances.

140889 (web) | Version 3.6 (05/2024)

Package contents

- 1x Homematic IP Access Point
- 1x Plug-in mains adapter
- 1x Network cable
- 2x Screws
- 2x Plugs
- 1x User manual

Information about this manual

Read this manual carefully before beginning operation with your Homema tic IP components. Keep the manual so you can refer to it at a later date if you need to. If you hand over the device to other persons for use, hand over this manual as well.

Symbols used:




Attention!

This indicates a hazard.



Please note: This section contains important additional information.

Hazard information



Do not use the device if there are signs of damage to the housing, control elements or connecting sockets, for example, or if it de-monstrates a malfunction. If you have any doubts, please have the device checked by an expert.

Do not open the device. It does not contain any parts that can be maintained by the user. In the event of an error, have the device checked by an expert.


For safety and licensing reasons (CE), unauthorized change and/or modification of the device is not permitted.

The device may only be operated indoors and must be protected from the effects of moisture, vib- rations, solar or other methods of heat radiation, cold and mechani- cal loads.

The device is not a toy; do not allow children to play with it. Do not leave packaging material lying around. Plastic films/bags, pieces of polystyrene, etc. can be dange- rous in the hands of a child.



The device may only be connected to an easily accessible power socket outlet. The mains plug must be pulled out if a hazard occurs.



 $^{
m J}$ The device may only be operated within residential buildings.

Using the device for any purpose other than that described in this operating manual does not fall within the scope of intended use and shall invalidate any warranty or liability.

Homematic IP - Smart living, simply comfortable

With Homematic IP, you can install your smart home solution in just a few little steps.

The Homematic IP Access Point is the central element of the Homematic IP smart home system and communicates with the Homematic IP radio protocol. You can pair up to 120 Homematic IP devices using the Access Point.

All devices of the Homematic IP system can be configured comfortably and individually with a smartphone via the Homema tic IP app. The available functions provided by the Homematic IP system in combination with other components are described in the Homema tic IP User Guide.

All current technical documents and updates are provided at www.homematic-ip.com.

Function and device overview

The Homematic IP Access Point is the central unit of the Homematic IP system.

It connects smartphones via the Homema tic IP cloud with all Homema tic IP devices and transmits configuration data and control commands from the app to all Homema tic IP devices. You can simply adjust your smart home control to your personal needs at any time and place.

Device overview:


(A) System button and LED

(B) QR code and device number (SGTIN)

(C) Screw holes

(D) Interface: Network cable

(E) Interface: Plug-in mains adapter



Start-up

This chapter describes how to set up your Homematic IP system step by step.

First install the Homematic IP app on your smartphone and set up your Access Point as described in the following section. Once your Access Point has been set up successfully, you can add and integrate new Homematic IP devices to your system.


6.1 Set-up and mounting of the Access Point

The Homematic IP app is available for iOS and Android and can be downloaded for free in the corresponding app stores.

- Download the Homematic IP app in the app store and install it on your smartphone.
- Start the app.
- Place the Access Point close to your router and a socket.

Always keep a minimum distance of 50 cm between the Homema tic IP Access Point and your WLAN router.

• Connect the Access Point with the router using the supplied network cable (F). Provide power supply for the device using the supplied plugin mains adapter (G).



- Scan the QR code (B) on the back side of your Access Point. You can also enter the device number (SGTIN) (B) of your Access Point manually.
- Please confirm in the app if the LED of your Access Point lights up permanently blue.

If the LED lights up differently, please follow the instructions in the app or (see "7.3 Error codes and flashing sequences" on page 17).

- The Access Point is registered to the server. This may take a few minutes. Please wait.
- After successful registration, please press the system button of your Access Point for confirmation.
- · Pairing will be carried out.
- The Access Point is now set up and immediately ready for use.

6.2 First steps: Pairing devices and adding rooms

As soon as your Homematic IP Access Point and the Homematic IP app are ready for use, you can pair additional Homematic IP devices and place them in different rooms within the app.

- Tap on the main menu symbol at the bottom right of the app homescreen and select the menu item "Pair device".
- Establish the power supply of the device you want to pair to be able to activate the pairing mode. For further information, please refer to the operating manual of the corresponding device.
- Follow the instructions of the app step by step.
- Select the desired solution for your device.
- In the app, give the device a name and create a new room or place the device in an existing room.

Please define the device names very carefully in order to avoid assignment errors when using various devices of the same type. You can change the device and room names at any time.

6.3 Operation and configuration

After having connected your Homematic IP devices and allocated them to rooms, they will be you can comfortably control and configure your Homematic IP system.

For further information about operati-on via the app and configuration of the Homematic IP system, please refer to the Homematic IP User Guide (available in the download area at www.homematic-ip.com).

Troubleshooting

7.1 Command not confirmed

If at least one receiver does not confirm a command, this may be caused by radio interference (see "10 General information about radio operation" on page 19). The error will be displayed in the app and may be cause by the follow:

- · Receiver cannot be reached
- Receiver is unable to execute the command (load failure, mechanical blockade, etc.)
- · Receiver is defective

7.2 Duty Cycle

The duty cycle is a legally regulated limit of the transmission time of de-vices in the 868 MHz range. The aim of this regulation is to safeguard the operation of all devices working in the 868 MHz range. In the 868 MHz frequency range we use, the maximum transmission time of any device is 1% of an hour (i.e. 36 seconds in an hour). Devices must cease transmissi- on when they reach the 1% limit until this time restriction comes to an end. Homema tic IP devices are designed and produced with 100% conformity to this regulation.

During normal operation, the duty cycle is not usually reached. However, repeated and radio-intensive pair processes mean that it may be reached in isolated instances during start-up or initial installation of a system. If the duty cycle limit is exceeded, the device

may stop working for a brief period. The device starts working correctly again after a short period (max. 1 hour).

7.3 Error codes and flashing sequences

Flashing code	Meaning	Solution
Permanent orange ligh- ting	Access Point is starting	Please wait shortly and observe the subsequent flashing behaviour.
Fast blue flashing	Connection to the server is being e stablished	Wait until the connection is establis hed and the LED lights permanently blue.
Permanent blue lighting	Normal operation, con nection to se rver is established	You can continue operation.
Fast yellow flashing	No connection to network or router	Connect the Access Point to the net work/ router.
Permanent yellow ligh- ting	No Internet connection	Please check the Internet connection and firewall settings.
Permanent turquoise lighting	Router function active (for operation with several Access Point s/Central Control Units)	Please continue the operation.
Fast turquoise flashing	No connection to Central Control U nit (only when operating with CCU3)	Check the network con-nection of y our CCU
Alternately long and short orange fl ashing	Update in progress	Please wait until the up-date has been completed
Fast red flashing	Error during update	Please check the server and Intern et connection. Re-start the Access Point.
Fast orange flashing	Stage before restoring the factory s ettings	Press and hold down the system bu tton again for 4 seconds, until the L ED lights up green.
1x long green lighting	Reset confirmed	You can continue operation.
1x long red lighting	Reset failed	Please try again.

Restore factory settings

The factory settings of your Access Point as well as of your entire installation can be restored. The operations distinguish as follows:

- Resetting the Access Point: Here, only the factory settings of the Access Point will be restored. The entire installation will not be deleted.
- Resetting and deleting the entire installation: Here, the entire installation is reset. Afterwards, the app has to be uninstalled and reinstalled. The factory settings of your single Homematic IP devices have to be restored as to enable them to be connected again.

8.1 Resetting the Access Point

To restore the factory settings of the Access Point, please proceed as follows:

- Disconnect the Access Point from the power supply. Therefore, unplug the mains adapter.
- Plug-in the mains adapter again and press and hold down the system button for 4s at the same time, until the

LED will quickly start flashing orange.

- · Release the system button again.
- Press and hold down the system button again for 4 seconds, until the LED lights up green. If the LED lights up red, please try again.
- Release the system button to finish the procedure.

The device will perform a restart and Access Point is being reset.

8.2 Resetting and deleting the entire installation

During the reset, the Access Point must be connected to the cloud so that all data can be deleted. Therefore, the network cable must be plugged in during the process and the LED must light up blue continuously afterwards.

To reset the factory settings of the en- tire installation, the procedure described above must be performed twice in succession, within 5 minutes:

- · Reset the Access Point as descri-bed above.
- Wait at least 10 seconds until the LED permanently lights up blue.
- Immediately afterwards, perform the reset for the second time by disconnecting the Access Point from the power supply again and repeating the previously described steps.

After the second restart, your system will be reset.

Maintenance and cleaning

The device does not require you to carry out any maintenance. Enlist the help of an expert to carry out any maintenance or repairs.

Clean the device using a soft, lint-free cloth that is clean and dry. You may dampen the cloth a little with lukewarm water in order to remove more stubborn marks. Do not use any detergents containing solvents, as they could corrode the plastic housing and label.

General information about radio operation

Radio transmission is performed on a non-exclusive transmission path, which means that there is a possibility of interference occurring. Interference can also be caused by switching ope- rations, electrical motors or defective electrical devices.

The range of transmission within buildings can differ greatly from that available in the open air. Besides the transmitting power and the reception characteristics of the receiver, environmental factors such as humidity in the vicinity have an important role to play, as do on-site structural/screening conditions.

Hereby, eQ-3 AG, Maiburger Str. 29, 26789 Leer/Germany declares that the radio equipment type Homematic IP HmIP-HAP, HmIP-HAP-A is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.homematic-ip.com

Disposal

Instructions for disposal

This symbol means that the device must not be disposed of as household waste, general waste, or in a yellow bin or a yellow sack. For the protection of health and the environment, you must take the product and all electronic parts included in the scope of delivery to a municipal collection point for old electrical and electronic equipment to ensure their correct disposal. Distributors of electrical and electronic equipment must also take back obsolete equipment free of charge.

By disposing of it separately, you are making a valuable contribution to the reuse, recycling and other methods of recovery of old devices.

Please also remember that you, the end user, are responsible for deleting personal data on any old electrical and electronic equipment before disposing of it.

Information about conformity

The CE mark is a free trademark that is intended exclusively for the authorities and does not imply any assurance of properties.



For technical support, please contact your retailer.

Technical specifications

Device short name:	HmIP-HAP, HmIP-HAP-A
Supply voltage Plug-in mains adapter (input):	100 V-240 V/50 Hz
Power consumption plug-in mains adapter:	2.5 W max.
Supply voltage:	5 VDC
Current consumption:	500 mA max.
Standby power consumption:	1.1 W
Degree of protection:	IP20
Ambient temperature:	5 to 35 °C
Dimensions (W x H x D):	118 x 104 x 26 mm
Weight:	153 g
Radio frequency band:	868.0-868.6 MHz 869.4-869.65 MHz
Maxium radiated power:	10 dBm max.
Receiver category:	SRD category 2
Typ. open area RF range:	400 m
Duty cycle:	< 1 % per h/< 10 % per h
Network:	10/100 MBit/s, Auto-MDIX

Subject to technical changes.

Free download of the Homematic IP app!



https://itunes.apple.com/de/app/homematic-ip/id1012842369?mt=8



https://play.google.com/store/apps/details?id=de.eq3.pscc.android&hl=de

Manufacturer's authorised representative:

eQ-3 eQ-3 AG

Maiburger Straße 29 26789 Leer / GERMANY www.eQ-3.de

Documents / Resources



homematic IP HmIP-HAP Smart Home Access Point [pdf] Instruction Manual HmIP-HAP, HmIP-HAP-A, HmIP-HAP Smart Home Access Point, HmIP-HAP, Smart Home Access Point, Home Access Point, Access Point

References

- P Home page | Homematic IP
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.