



Home » Honeywell Home » Honeywell Home N100 Series Non Programmable Thermostat User Guide ™

Contents [hide]

- 1 Honeywell Home N100 Series Non-Programmable Thermostat
- 2 UWP Wall Plate Installation
- 3 Power options
- 4 Wiring Diagrams
- 5 Thermostat Mounting
- 6 Configuration and Settings
- 7 Auto Changeover
- 8 Troubleshooting
- 9 Specifications
- 10 Frequently Asked Questions
- 11 Documents / Resources
 - 11.1 References

Honeywell Home

Honeywell Home N100 Series Non-Programmable Thermostat



Package Includes

- FocusPRO N100 Series Thermostat
- UWP™ Wall Plate
- Decorative Cover Plate with J-Box Adapter
- Screws and Anchors
- 2 AA Batteries
- Thermostat Literature

Compatibility

TH1110U4000 models are compatible with 24 VAC, single-stage heating and cooling systems including:

- Heat pumps without auxiliary heat
- · Gas/oil/electric forced air
- Single-stage cooling
- Radiant Hydronic heat
- Hot water coil
- 750 MV

TH1320U4002 models are compatible with most 24 VAC heating and cooling systems including:


- Heat pumps with 1 or 2 compressor stages and auxiliary heat
- Dual fuel

- 1 or 2 stage Gas/oil/electric forced air
- 1 or 2 stage cooling
- Radiant Hydronic Heat
- Hot water coil
- 750 MV
- S terminals for C7089U1006 wired outdoor sensor (used for Aux Heat lockout or balance point on heat pump systems.

UWP Wall Plate Installation

If the cover plate is used, the UWP snaps on the cover plate as shown here.

- 1. Before starting, turn the power off at the breaker box or switch. Open the package to find the UWP. See Figure 1. 2
- 2. Position the UWP on wall. Level and mark hole positions. See Figure 2.
- 3. Using a 3/16" bit, drill holes at marked positions and then lightly tap the supplied wall anchors into the wall using a hammer.
- 4. Pull the door open and insert the wires through wiring hole of the UWP. See Figure 3.
- 5. Place the UWP over the wall anchors. Insert and tighten mounting screws supplied with the UWP. Do not overtighten. Tighten until the UWP no longer moves. Close the door. See Figure 4.




Use 3x supplied #6 1-1/2" screws


Optional Cover Plate Installation

If the Optional Cover Plate is not required, see UWP Wall Plate Installation. Use the Optional Cover Plate when you need to cover a paint gap from the old thermostat.

- 1. Separate the Cover Plate from Mounting Plate (Figure 1).
- Mount the Mounting Plate on to the wall or J-box using any of the 8 screw holes.
 Insert and tighten mounting screws supplied with Cover Plate Kit. Do not overtighten.
 See Figure 2. Make sure the Mounting Plate is level.
- 3. Attach the UWP by hanging it on the top hook of the Mounting Plate and then snapping the bottom of the UWP in place. See Figure 3.
- 4. Snap the Cover Plate onto the Mounting Plate. See Figure 4.




Power options



Insert **R** and **C** wires into designated terminals for primary AC power. (C terminal is **optional** if batteries are installed but is **recommended**). Remove wires by pressing down on the terminal tabs.

Thermostats using Y and G wires

If there is no C wire from the previous thermostat or no extra wire in the bundle to the thermostat, you may use the THP9045A C-wire adapter (sold separately).



Insert AA batteries for primary or backup power

For more information on the THP9045A C-wire adapter, go to:

https://customer.resideo.com/resources/Techlit/TechLitDocuments/33-00000s/33-00618.pdf

Setting Slider Tabs

Set R Slider Tab


Use built-in jumper (R Slider Tab) to differentiate between one or two transformer systems.

- If there is only one R wire, and it is connected to the R, Rc, or RH terminal, set the slider to the up position (1 wire).
- If there is one wire connected to the R terminal and one wire connected to the Rc

terminal, set the slider to the down position (2 wires).

Slider Tabs for U terminals should be left in place for FocusPRO N100 models.

UWP Wall Plate



R/Rc slider tab


Wiring terminal designations

Y2	Compressor contact or (stage 2) (TH1320U4002 only)	E	Emergency Heat (T H1320U4002 only)	○ S L/A ○ A ○ S O/B ○ ○ Y AUX ○ W2 ○ Y2 E ○ ○ G ○ W ○ C ○ K ○ U ○ R ○ U ○ R
G	Fan	W	Heat (stage 1)	MCR39537 The most commonly used
С	24VAC common. For 2-transformer sy stems, use Common wire from cooling transformer.	K	To THP9045A C-Wir e adapter if needed	terminals are shaded in the illustration above.
U	Not used on these m	R	24VAC power from h eating transformer*	
U	odels	Rc	24VAC power from c ooling transformer*	
* Terminal can be jumped using Slider Tab. See Setting Slider Tabs.				

Wiring Diagrams

• Heat Only: Gas or Oil Furnace


• Compatible models: All N100



- 1. COMMON OPTIONAL
- 2. G USED FOR INDEPENDENT FAN CONTROL ONLY. (MOST HEAT ONLY, GAS OR OIL FORCED AIR SYSTEMS DO NOT USE A FAN [G] WIRE)

Cool Only


Compatible models: All N100



1. COMMON OPTIONAL

Hot Water Boiler, Heat Only


Compatible models: All N100



1. COMMON OPTIONAL

1H/1C: Gas Furnace


Compatible models: All N100



1. COMMON OPTIONAL.

Transformer System, 1H/1C: Oil Furnace with Air Conditioning


Compatible models: All N100



1. COMMON OPTIONAL

2H/1C: Gas Furnace


Compatible model: TH1320U4002 models only



1. COMMON OPTIONAL

Transformer System, Hot Water Heat with Air Conditioning (or Hot Water Coil)


Compatible models: All N100



1. COMMON OPTIONAL

2H/2C: Gas Furnace

Compatible model: TH1320U4002 models only




MCR39497

1. COMMON OPTIONAL

Hot Water Heat with Power Open Zone Valve


Compatible models: All N100



1. COMMON OPTIONAL TO THERMOSTAT

1H/1C: Heat Pump without Aux Heat


Compatible models: All N100



- 1. COMMON OPTIONAL
- 2. L ONLY CONNECTED IF HEAT PUMP HAS A FAULT TERMINAL
- 3. SOME HEAT PUMPS USE B RATHER THAN O FOR REVERSING VALVE
- 4. IMPORTANT: DO NOT CONNECT ANY WIRE TO W FOR HEAT PUMP APPLICATIONS! THIS CAN CAUSE HEAT TO RUN CONTINUOUSLY.

Hot Water Heat with Power Open/Power Closed Series 20 Zone Valve


Compatible models: All N100



- 1. COMMON OPTIONAL TO THERMOSTAT
- 2. THERMOSTAT MUST BE CONFIGURED FOR RADIANT HEAT WITH 0 (ZERO) COOL STAGES

2H/1C: Heat Pump with Electric Aux Heat


• Compatible model: TH1320U4002 models only 6



- 1. COMMON OPTIONAL
- 2. L IS ONLY CONNECTED IF THE HEAT PUMP HAS A FAULT TERMINAL
- 3. SOME HEAT PUMPS USE B RATHER THAN O FOR REVERSING VALVE
- 4. DIFFERENT HEAT PUMP MODELS MAY LABEL THE AUXILIARY HEAT TERMINAL DIFFERENTLY THAN SHOWN. CONSULT HEAT PUMP WIRING GUIDE
- 5. IF LOCKOUT OF AUX HEAT ON HIGH OUTDOOR TEMPERATURE IS REQUIRED, WIRE C7089U1006 TO THE TWO S TERMINALS
- 6. MOST HEAT PUMPS SHARE THE SAME SET OF HEAT STRIPS FOR AUX AND EM HEAT. IN THESE CASES, E IS NOT USED. MODEL TH1320U4002 CAN BE CONFIGURED FOR SEPARATE AUX AND E. IN THIS SITUATION, WIRE ONE SET OF STRIPS TO E TO BE ENERGIZED IN EM HEAT AND A DIFFERENT SET OF STRIPS TO AUX TO BE ENERGIZED IN AUX HEAT.
- 7. IMPORTANT: DO NOT CONNECT ANY WIRE TO W FOR HEAT PUMP APPLICATIONS! THIS CAN CAUSE HEAT TO RUN CONTINUOUSLY.

3H/2C: Heat Pump with Electric Aux Heat


Compatible model: TH1320U4002 only



- 1. COMMON OPTIONAL.
- 2. L ONLY CONNECTED IF HEAT PUMP HAS A FAULT TERMINAL.
- 3. SOME HEAT PUMPS USE B RATHER THAN O FOR REVERSING VALVE.
- 4. DIFFERENT HEAT PUMP MODELS LABEL THE AUXILIARY HEAT TERMINAL DIFFERENTLY THAN SHOWN. CONSULT HEAT PUMP WIRING GUIDE.
- 5. IF LOCKOUT OF AUX HEAT ON HIGH OUTDOOR TEMPERATURE IS REQUIRED, WIRE C7089U1006 TO THE TWO S TERMINALS.
- 6. MOST HEAT PUMPS SHARE THE SAME SET OF HEAT STRIPS FOR AUX AND EM HEAT. IN THESE CASES, E IS NOT USED. MODEL TH1320U4002 CAN BE CONFIGURED FOR SEPARATE AUX AND E. IN THIS SITUATION, WIRE ONE SET OF STRIPS TO E TO BE ENERGIZED IN EM HEAT AND A DIFFERENT SET OF STRIPS TO AUX TO BE ENERGIZED IN AUX HEAT.
- 7. IMPORTANT: DO NOT CONNECT ANY WIRE TO W FOR HEAT PUMP APPLICATIONS! THIS CAN CAUSE HEAT TO RUN CONTINUOUSLY.

Dual Fuel, 2H/1C: Heat Pump


Compatible model: TH1320U4002 only



- 1. COMMON OPTIONAL.
- 2. L ONLY CONNECTED IF HEAT PUMP HAS A FAULT TERMINAL.
- 3. SOME HEAT PUMPS USE B RATHER THAN O FOR REVERSING VALVE.
- 4. THE HEAT PUMP AND FURNACE HAVE SEPARATE BOARDS. THEY ARE SHOWN TOGETHER HERE TO SIMPLIFY THIS DIAGRAM. W IS FROM THE FURNACE BOARD.
- 5. WIRE C7089U1006 TO THE TWO S TERMINALS.
- 6. IMPORTANT: DO NOT CONNECT ANY WIRE TO W FOR HEAT PUMP APPLICATIONS! THIS CAN CAUSE HEAT TO RUN CONTINUOUSLY.

Dual Fuel 3H/2C: Heat Pump


Compatible model: TH1320U4002



- 1. COMMON OPTIONAL.
- 2. L ONLY CONNECTED IF HEAT PUMP HAS A FAULT TERMINAL.
- 3. SOME HEAT PUMPS USE B RATHER THAN O FOR REVERSING VALVE.
- 4. THE HEAT PUMP AND FURNACE HAVE SEPARATE BOARDS. THEY ARE SHOWN TOGETHER HERE TO SIMPLIFY THIS DIAGRAM. W IS FROM THE FURNACE BOARD.
- 5. WIRE C7089U1006 TO THE TWO S TERMINALS.
- 6. IMPORTANT: DO NOT CONNECT ANY WIRE TO W FOR HEAT PUMP APPLICATIONS! THIS CAN CAUSE HEAT TO RUN CONTINUOUSLY.

Thermostat Mounting

- 1. Push the excess wire back into the wall opening.
- 2. Close the UWP door. It should remain closed without bulging.
- 3. Align the UWP with the thermostat and push gently until the thermostat snaps into place.
- 4. Turn the power on at the breaker box or switch.




Configuration and Settings

Installer Options

On initial setup, the thermostat will enter the ISU menu. If entering the ISU menu after initial setup, follow the steps below:

- 1. Press and hold the bottom left button and the Up arrow button for 5 seconds to access the INSTALLER SETUP (ISU).
- 2. The ISU number is on the left. The ISU setting is on the right. When an ISU number is displayed, press up or down to change the setting.
- 3. After choosing the correct setting for an ISU, press NEXT to advance to the next ISU setting.
- 4. To finish the setup, press the SAVE button.



Depen	Depending on system settings, not all options may be available			
#ISU	ISU Name ISU Options (factory defaults are in bold)			
1050	Temperature Indication Scale	F = Fahrenheit C = Celsius		
1060	Outdoor Sensor (TH1320U4002 only. For lock outs only. Does not display)	0 = None 1 = Wired Outdoor Sensor		
2000	Heating System Type	1 = Conventional Forced Air Heat 2 = Heat Pump 3 = Radiant Heat 5 = None (Cool Only)		

		Conventional Forced Air Heat:
	Heating Equipment Type	1 = Standard Efficiency Gas Forced Air
		2 = High Efficiency Gas Forced Air
		3 = Oil Forced Air
2010		4 = Electric Forced Air 5 = Hot Water Fan Coil Heat Pump:
		7 = Air to Air Heat Pump
		8 = Geothermal Heat Pump
		Radiant Heat:
		9 = Hot Water Radiant Heat
		12 = Steam
		0= O (O/B in Cool)
2060	Reversing Valve O/B	1=B (O/B in Heat)
		0, 1, 2
2070	Compressor Stages	Only 1 compressor stage available on TH111 0U4000
		Heat Stages: 1, 2
2071	Heat Stages/Backup Heat St ages	Backup Heat Stages: 0, 1 (TH1320U4002 only)
2110	Fan Control in Heat	1 = Equipment Controls Fan 2 = Thermostat Controls Fan (Only shown if 2010 = 4 or 5)

	Aux/E terminal control	0 = Drive both Aux & E together
2175	(TH1320U4002 only)	1 = Aux and E independent
2180	Backup Heat Source (Heat P ump Only) (TH1320U4002 on ly)	31 = Electric Forced Air 32 = Standard Efficiency Gas Forced Air 33 =
2185	Emergency Heat Source (TH 1320U4002 only)	High Efficiency Gas Forced Air 34 = Oil Forced Air, Hot Water Fan Coil 35 = Hot Water Radiant Heat 36 = Other
3000	System Changeover	0 = Manual 1 = Automatic
3015	Auto Changeover Differential	O°F to 5°F O.O°C to 2.5°C The Differential setting is the minimum number of degrees from the set-point needed to switten characteristic moderunning (HeatorCool) to the opposite mode when The thermostatic auto-changeover.
3020	Finish With High Heat Stage	0 = No 1 = Yes (TH1320U4002 only)

		0 = No
3021	Finish With High Cool Stage	1 = Yes
		(TH1320U4002 only)

#ISU	ISU Name	ISU Options (factory	defaults are in bold)
3090	Backup Heat Droop	0 = Comfort 2 °F to 15 °F (in 1 °F in 1 °F in 1.0 °C to 7.5 °C (in 0.5) 0 (comfort) setting of Backup Heat (ISU 21) set to Electric. TH13	5 °C increment). nly available if 80) is
3110	Upstage Timer for Backup He at	0 = Off 1 = 30 minutes 2 = 45 minutes 3 = 60 minutes 4 = 75 minutes 5 = 90 minutes 6 = 2 hours 7 = 3 hours	8 = 4 hours 9 = 5 hours 10 = 6 hours 11 = 8 hours 12 = 10 hours 13 = 12 hours 14 = 14 hours 15 = 16 hours

		(TH1320U4002 only) If 3090 = 0 and 2180 and 0.3.	= 31, 3110 only has setti
3120	Compressor Lockout / Balanc e Point (TH1320U4002 only)	0 = Off 1 = -15°F (-26°C) 2 = -10°F (-23.5°C) 3 = -5°F (-20.5°C) 4 = 0°F (-18°C) 5 = 5°F (-15°C) 10 = 10°F (-12°C) 15 = 15°F (-9.5°C) 20 = 20°F (-6.5°C)	25 = 25°F (-4°C) 30 = 30°F (-1°C) 35 = 35°F (1.5°C) 40 = 40°F (4.5°C) 45 = 45°F (7°C) 50 = 50°F (10°C) 55 = 55°F (13°C) 60 = 60°F (15.5°C)
3121	Outdoor Lockout Backup Hea t (TH1320U4002 only)	0 = Off 5 = 5°F (-15°C) 10 = 10°F (-12°C) 15 = 15°F (-9.5°C) 20 = 20°F (-6.5°C) 25 = 25°F (-4°C) 30 = 30°F (-1°C)	35 = 35°F (1.5°C) 40 = 40°F (4.5°C) 45 = 45°F (7°C) 50 = 50°F (10°C) 55 = 55°F (13°C) 60 = 60°F (15.5°C) 65 = 65°F (18.5°C)

			13 = 65 min
3125	Lockout Fan after a Cool call	[0] = Off 1 = 5 min 2 = 10 min 3 = 15 min 4 = 20 min 5 = 25 mi n 6 = 30 min 7 = 35 min 8 = 40 min 9 = 4 5 min 10 = 50 min 11 = 55 min 12 = 60 min	14 = 70 min 15 = 75 min 16 = 80 min 17 = 85 min
			18 = 90 min 19 = 95 20 = 100 min 21 = 105 min 22 = 110 min 23 = 115 min 24 = 120 min
3140	Compressor Cycle Rate (Sta ge 1)	1 – 6	
3141	Compressor Cycle Rate (Sta ge 2)	1 – 6 (TH1320U4002	only)
3150	Heating Cycle Rate (Stage 1)	1 – 12	
3151	Heating Cycle Rate (Stage 2)	1 – 12 (TH1320U4002	2 only)
3160	Heating Cycle Rate Auxiliary Heat	1 – 12 (TH1320U4002	2 only)
3165	Heating Cycle Rate Emergen cy Heat	1 – 12 (TH1320U4002	2 only)

3240	Compressor Protection	0 = Off 1 - 5 minutes
4100	Maximum Cool Setpoint	50°F to 99°F 10°C to 37°C
4101	Minimum Cool Setpoint	50°F to 99 °F 10.0°C to 37.0 °C
4102	Maximum Heat Setpoint	40°F to 90°F 4.5°C to 32.0°C
4103	Minimum Heat Setpoint	32 °F to 50 °F (Default is 40 ° F) 0 °C to 10.0 °C (Default is 4.5 ° C)

7110	Air Filter Replacement Reminder	 0 = Off 1 = 10 Run Time Da ys 2 = 20 Run Time Da ys 3 = 30 Run Time Da ys 4 = 45 Run Time Da ys 5 = 60 Run Time Da ys 6 = 90 Run Time Da ys 7 = 120 Run Time Da ays 8 = 150 Run Time Da ays 9 = 30 Calendar Day s 	10 =45 Calendar Days 11 =60 Calendar Days 12 =75 Calendar Days 13 =3 Calendar Month s 14 =4 Calendar Month s 15 =5 Calendar Month s 16 =6 Calendar Month s 17 =9 Calendar Month s 18 =12 Calendar Month hs 19 =15 Calendar Mont hs
------	---------------------------------	---	--

		0 = On Demand
1400	Backlighting	1 = Continuous
3		Common wire is needed for Continuous.


Т

Т

1400	Backlight brightness	1 – 5 (Only displayed if Continuous Backlight i s selected.)
1400	Idle screen selection	0 – Minimum Information shown 2 – Maximum display information shown
1402	Temperature Display Offset	-3 to 3 F (0) -1.5 to 1.5 C (0)

Installer Test

- 1. After finishing the INSTALLER SETUP, the N100 enters INSTALLER TEST mode.
- 2. The display will show the current test mode. To test the mode displayed, press **up.** If testing Heat or Cooling on multi-stage equipment, a second press of the **up** button will indicate a call for Stage 2.
- 3. Press NEXT to advance to the next mode in the test menu. Possible settings in the test menu are Heat, Cool, Em Heat and Fan.



System Test	System Status	
Shaded areas below apply only to TH1320U4002		
Heat	0	All Off
	1	Heat Stage 1 On
	2	Heat Stage 2 also On
	3	Heat Stage 3 also On
Cool	0	All Off
	1	Cool Stage 1 On
	2	Cool Stage 2 also On
Em Heat	0	All Off
	1	Em Heat On
Fan	0	Fan Off
	1	Fan On

Note: If ISU 1060 is set for a wired outdoor sensor, that sensor reading is shown in the display after cycling through the Installer test menu but is not shown on the home screen.

System Operation Settings

- 1. Press the MODE button to cycle to the next available System mode
- 2. Cycle through the modes until the desired System mode is displayed. Available System modes vary by model and system settings

System modes

- AUTO
- HEAT
- COOL
- EM HEAT
- OFF

Fan Operation Settings

1. Press the FAN button to cycle to the next available Fan mode.

2. Cycle through the modes until the desired Fan mode is displayed


Available Fan modes vary with system settings.


Fan modes

• AUTO: Fan runs only when the heating or cooling system is on

• ON: Fan is always on

• CIRC: Fan runs about 33% of the time to circulate air





Auto Changeover

When a thermostat is set to Auto Changeover, the thermostat has a Heat setpoint and a Cool setpoint and can run either Heat or Cool as needed.

- 1. Verify the thermostat is set to Auto Changeover mode. Press the MODE button in the upper left until AUTO is selected. Press the SAVE button (Center left).
- 2. Press the **up or down** button. Upper right shows HEAT TO or COOL TO in flashing text, and the setpoint. Use the **up or down** button to adjust the setpoint. If the display shows HEAT TO flashing when you want to adjust the Cool setpoint, or vice versa,


press the System button. While HEAT TO or COOL TO is flashing, the mode indication at upper left shows either HEAT or COOL flashing. Pressing the MODE button at this time changes the setpoint being adjusted from HEAT to COOL or vice-versa.

Heat and cool set to the same temperature

Most customers are comfortable in a 2–3 degree temperature range. Therefore, the heat is usually set a few degrees below the Cool setpoint. When the indoor temperature is between the Heat and Cool setpoints, the system is off. The Heat and Cool setpoints can be the same. To ensure that the system doesn't cycle back and forth between Heating and Cooling, the thermostat observes a differential setting (set by the installer). If the thermostat last ran in Heat mode, it cycles heat on and off to maintain the setpoint. The indoor temperature must rise to the differential setting before it switches to Cool. Then cooling will run down to the Cool setpoint and cycle cooling on and off to maintain as needed. The thermostat would then need to drop to the differential setting before switching back to Heat. Typically, a thermostat using Auto Changeover would only need to switch over twice per day as outdoor temperature rises during the day and drops in the evening.

Alerts


When an alert is active, this icon will appear in the lower part of the display. Pressing any button will activate the display and show the alert number above the indoor temperature reading. If more than one alert is active, the thermostat will display the number of the next alert after 10 seconds. Some alerts can be resolved by the homeowner, for example, Replace Batteries. Other alerts may require a service call to the professional installer.



Alert Num ber	Alert Meaning
405	Low batteries
407	Critically low batteries
164	Heat Pump has detected a fault
170	Thermostat Memory Failure
173	Internal Sensor Error
178	Wired Outdoor Sensor Error. Check wires and connections to the outdo or sensor.

Replace Filter Reminder

When a Replace Filter reminder occurs, this icon will appear in the lower part of the display along with the message Replace Filter. After replacing the furnace filter, you can reset this reminder by pressing and holding the upper left and lower right buttons for 5 seconds.



Built-in compressor protection

Damage can occur if your system's compressor is restarted too soon after shutdown. This feature forces the compressor to wait for a few minutes before restarting. During the wait time, the display will show the message Waiting For Equipment under the room temperature reading. When the safe wait time has elapsed, the message disappears,

and the thermostat will show "Heat on" or "Cool on".




Accent Piece Installation/Replacement


Private label accent piece for FocusPRO N100 models

Private label replacement accent pieces for N100 thermostats can be ordered. Information about the private label program can be found at:


www.resideo.com/us/en/pro/private-label-program



Example of the private label accent pieces that can be ordered for the thermostats listed above.



To replace an accent piece, pull it away from the thermostat...



...then snap the new one on.


See the video at:



Battery Replacement

The thermostat's display will let you know when the batteries are low and need to be replaced.

- 1. Remove the thermostat by pulling it away from its mount, as seen below.
- 2. Be sure to use fresh AA batteries and insert them as shown.
- 3. After inserting the new batteries, align the thermostat with the mounting plate and push gently until the thermostat snaps back into place.



Troubleshooting

	Check circuit breaker and reset if necessary
	Make sure power switch for heating & cooling system is on
Dioplay is blank	Make sure furnace door is closed securely
Display is blank	Make sure fresh AA alkaline batteries are correctly instal led See Battery
	Replacement

- When running heat, the display will show **HEAT ON** in lower right of display
- · When running cool, display will show **COOL ON** in lo wer right of display
- If display shows **WAITING FOR EQUIPMENT** under t emperature reading, it is **in compressor delay mode** to protect the system. Wait 5 minutes to determine if the th ermostat makes a Heat or Cool call
- If the display doesn't indicate a call for Heat or Cool or WAITING FOR EQUIPMENT, verify the mode setting, to emperature setpoint and room temperature

If you press the Up or Down arrow

- Upper left of the display shows mode setting
- Upper right shows setpoint
- · The center of the display shows the room temperature

If the issue persists

- · Check the circuit breaker and reset if necessary
- Make sure the power switch at the heating & cooling system is on
- Make sure the furnace door is closed securely

Heating or cooling does not run

Heat or Aux Heat runs wi	 Verify there is not a wire attached to W for heat pump systems. See Wiring Diagrams. For heat pump applications, the reversing valve is en ergized in Heat on some heat pumps and Cool for other heat pumps. Verify ISU 2060 is set correctly
an occurry	Verify that no wires are shorted. Look for exposed se ctions of wire at the UWP
	 Verify display does not indicate HEAT ON, COOL O N or AUX HEAT ON
Heat or Aux heat runs wit	 Verify there is not wire attached to W for heat pump s ystems. See Wiring Diagram.
ng	Verify that no wires are shorted. Look for exposed se ctions of wire at the UWP
	Verify the mode setting (Heat, Cool, Auto, or Em Heat in upper left of display)
	The setting ranges for these modes are
	o Heat or Em Heat: 32 °F to 90 °F (0 °C to 32. 0 °C)
Cannot change the setpoint to the desired se	o Cool: 50 °F to 99 °F (10.0 °C to 37.0 °C)
tting	If the setpoint can be adjusted, but not to the full range s hown above, the thermostat may be configured for a ma ximum heat or minimum cool
	setpoint to restrict settings that are energy inefficient.

WAITING FOR EQUIPME

NT

shown in the display under the room

temperature

The compressor protection feature is engaged. Wait a fe w minutes for the system to safely restart to avoid dama ging the compressor. See Built-in

compressor protection.

Specifications

Temperature Ranges

• **Heat**: 32 °F to 90 °F (0 °C to 32.0 °C)

Cool: 50 °F to 99 °F (10.0 °C to 37.0 °C)

- Working Ambient Temperature 32 °F to 120 °F (0 C° to 48.9 °C)
- Operating Ambient Temperature 32 °F to 102 °F (0 °C to 38.9 °C)
- Shipping Temperature -20 °F to 120 °F (-28.9 °C to 48.9 °C)
- Operating Relative Humidity 5% to 90% (non-condensing)
- Physical Dimensions in inches (mm) (H x W x D) Thermostat
 - ∘ 5-1/8" W x 3-7/16" H x 1-3/16" D

Cover Plate

- 6-1/16" W x 4-3/5" H
- 154 mm W x 117 mm H

Electrical Ratings

- Device Input Power AC: 1.1 VA, 24 VAC nominal (20-30 VAC), 60 Hz
- Load Ratings see below
- Batteries Two 1.5V AA alkaline batteries

Terminal	Voltage (60Hz)	Running Current
W Heating	24 Vac	0.02-1.0 A
W Heating	750 mV DC	100 mA DC
W2 (Aux) Heating	24 Vac	0.02-1.0 A
E Emergency Heat	24 Vac	0.02-0.5 A
Y Compressor Stage 1	24 Vac	0.02-1.0 A
Y2 Compressor Stage 2	24 Vac	0.02-1.0 A
G Fan	24 Vac	0.02-0.5 A
O/B Changeover	24 Vac	0.02-0.5 A
L/A Input	24 Vac	0.02-0.5 A

CAUTION: ELECTRICAL HAZARD

Can cause electrical shock or equipment damage. Disconnect power before beginning installation.

CAUTION: EQUIPMENT DAMAGE HAZARD

Compressor protection is bypassed during testing. To prevent equipment damage, avoid cycling the compressor quickly.

CAUTION: MERCURY NOTICE

If this product is replacing a control that contains mercury in a sealed tube, do not place the old control in the trash. Contact your local waste management authority for instructions regarding recycling and proper disposal.

CAUTION: ELECTRONIC WASTE NOTICE

The product and batteries should not be disposed of with other household waste. Check for the nearest authorized collection centers or authorized recyclers. The correct disposal of end-of-life equipment will help prevent negative consequences for the environment and human health.

FCC statement available at: https://customer.resideo.com/en-us/support/residential/codes-and-standards/FCC15105/Pages/default.aspx

Customer Assistance

For assistance with this product, please visit <u>customer.resideo.com</u> or call Resideo Customer Care toll-free at 1-800-633-3991

5-year limited warranty

For Warranty information, go to honeywellhome.com/support

Resideo Technologies Inc. Scottsdale, AZ 85254 33-00692EFS-01 L.Y. Rev. 12-24 The Honeywell Home trademark is used under license from Honeywell International, Inc. This product is manufactured by Resideo Technologies, Inc. and its affiliates. 2024 Resideo Technologies, Inc. Resideo Technologies Inc. Scottsdale, AZ 85254 33-00692EFS-01 L.Y. Rev. 12-24 La marca comercial Honeywell Home se utiliza bajo licencia de Honeywell International, Inc. Este producto está fabricado por Resideo Technologies, Inc. y sus filiales. 2024 Resideo Technologies, Inc.

www.resideo.com

Frequently Asked Questions

Q: Can I customize the label with my own brand?

A: Yes, the FocusPRO Series allows for a customizable snap-on label. Contact Honeywell for more information on branding options.

Q: How do I troubleshoot common issues with the FocusPRO?

A: Refer to the user manual for a list of common issues and troubleshooting steps. If problems persist, contact customer support for assistance.

Q: Is professional installation required for setting up the FocusPRO?

A: While professional installation is recommended for best results, the provided installation guide can help users with DIY setup. If unsure, consult a professional installer.

Documents / Resources



<u>Honeywell Home N100 Series Non Programmable Thermostat [pdf]</u> User Guide

N100, S200, P200, N100 Series Non Programmable Thermostat, N100 S eries, Non Programmable Thermostat, Programmable Thermostat, Thermostat

References

- User Manual
- Honeywell Home
- ► Honeywell Home, N100, N100 Series, N100 Series Non Programmable Thermostat, Non-Programmable Thermostat, P200, PROGRAMMABLE THERMOSTAT, S200, Thermostat

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
ivame		
Email		
Website		
☐ Save my name, email, and website in this browser for the next time I com	nment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.