




ICON Procon TVF-450 Flow Batching Controller User Guide

[Home](#) » [ICON Procon](#) » [ICON Procon TVF-450 Flow Batching Controller User Guide](#) 

Contents

- [1 ICON Procon TVF-450 Flow Batching Controller](#)
- [2 Symbol Explanation](#)
- [3 Basic Requirements | User Safety](#)
- [4 Specifications](#)
- [5 Front Panel Description](#)
- [6 Function of Push Buttons](#)
- [7 Dimensions](#)
- [8 Wire Connection](#)
- [9 Power Supply & Relay Connection](#)
- [10 Programming K Factor](#)
- [11 Programming Batching](#)
- [12 Resetting Totalizer](#)
- [13 Warranty, Returns and Limitations](#)
- [14 FAQ](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)



ICON Procon TVF-450 Flow Batching Controller



Quick Start Manual



Read the user's manual carefully before starting to use the unit. Producer reserves the right to implement changes without prior notice.

Symbol Explanation



This symbol denotes especially important guidelines concerning the installation and operation of the device. Not complying with the guidelines denoted by this symbol may cause an accident, damage or equipment destruction.


Basic Requirements | User Safety

- Do not use the unit in areas threatened with excessive shocks, vibrations, dust, humidity, corrosive gasses and oils.
- Do not use the unit in areas where there is risk of explosions.
- Do not use the unit in areas with significant temperature variations, exposure to condensation or ice.
- The manufacturer is not responsible for any damages caused by inappropriate installation, not maintaining the proper environmental conditions and using the unit contrary to its assignment.
- If in the case of a unit malfunction there is a risk of a serious threat to the safety of people or property additional, independent systems and solutions to prevent such a threat must be used.
- The unit uses dangerous voltage that can cause a lethal accident. The unit must be switched off and disconnected from the power supply prior to starting installation or troubleshooting (in the case of malfunction).
- Do not attempt to disassemble, repair or modify the unit yourself. The unit has no user serviceable parts.
- Defective units must be disconnected and submitted for repairs at an authorized service center.

Specifications

General	
Display	LED 6 Digit 13mm High Red
Displayed Values	0 ~ 999999
RS485 Transmission	1200...115200 bit/s, 8N1 / 8N2 RS485
Housing Material	NORYL
Protection Class	NEMA 4X IP65
Input Signal Supply	
Standard	Current: 4-20mA 0-20mA 0-5V* 0-10V*
Voltage	85 – 260V AC/DC 16 – 35V AC, 19 – 50V DC*
Output Signal Supply	
Standard	2 x Relays (1A) 4-20mA + 1 x Relay (1A)
Communication	RS485
Voltage	24VDC
Passive current output *	4-20mA (Operating Range Max. 2.8 – 24mA)
Performance	
Accuracy	±0.1% @ 25°C One Digit
Temperatures	
Operating Temperature	-4 – 122°F -20 – 50°C

Front Panel Description



Function of Push Buttons



Symbol used in the manual : [ESC/MENU]

Functions:

- Enter to main menu (press and hold for at least 3 sec.)
- Exit the current Screen and Enter to previous menu (or measure mode)
- Cancel the changes made in parameter being edited



Symbol used in the manual : [ENTER/PAUSE]

Functions:

- Start to edit the parameter
- Enter into the sub-menu
- Confirmation of changes made in parameter being edited
- In batcher mode : Pause / Start Batching



Symbol used in the manual : [Σ/RESET]

Functions:

- Switching of the display between total and instantaneous measurements or batcher counter (In batcher mode only)
- Zeroing the currently displayed counter (Press & Hold for at least 2 Sec), the zeroing must be confirmed by pressing [ENTER] button




Symbol used in the manual : [^] [v]

Functions:


- Change of the present menu
- Modification of the parameter value
- Switching of the display between relay thresholds and number of batches counter.

Dimensions




Wiring Diagram

* Depending on Version 85/230/260V AC/DC ; 50 – 60 Hz 19/24 – 50V DC ; 16/24/35V AC




Wire Connection

- Loosen Set Screw
- Insert Wire
- Tighten Set Screw



- Due to possible significant interference in industrial installations, appropriate measures assuring correct operation of the unit must be applied.
- The unit is not equipped with an internal fuse or power supply circuit breaker.
- For this reason, an external time-delay cut-out fuse with a small nominal current value must be used (recommended bipolar, max. 2A) and a power supply circuit breaker located near the unit.

Power Supply & Relay Connection



Note:

Contacts of relay outputs are not equipped with spark suppressors. When using the relay outputs for switching of inductive loads (coils, contactors, power relays, electromagnets, motors etc.) it is required to use additional suppression circuit (typically capacitor 47nF/ min. 250VAC in series with 100R/5W resistor), connected in parallel to relay terminals or (better) directly on the load.

Suppression Circuit Connection




Figure: Examples of Suppression Circuit Connection
 a) To Stepper Relay Terminals b) To the Inductive Load (Motor)

OC-Type Output Connection*






Figure: Examples of OC-type output connection

Flow Meter Connections

TKM Series : 4-20mA Output		
450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
33	Yellow	mA+
34	Grey	mA-



TKS Series : Pulse Output		
GPM/Pulse = K factor		
450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	Black	NPN Pulse
Note : Jump 5 & 35		




TKW Series : Pulse Output

GPM/Pulse = K factor


450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	Black	Pulse

Note : Jump 5 & 35



TKW Series : 4-20mA Output

450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
33	Black	mA+
34	White	mA-




TKM | TKP Series : Pulse Output

GPM/Pulse = K factor

450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	Black	Pulse

Note : Jump 5 & 35




TIW Series : Pulse Output

GPM/Pulse = K factor

450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	White	Pulse

Note : Jump 5 & 35




TIM | TIP Series : Pulse Output

GPM/Pulse = K factor


450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	White	Pulse

Note : Jump 5 & 35



TIM Series : 4-20mA Output

450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
33	Yellow	mA+
34	Grey	mA-




UF 1000 | 4000 | 5000 – Pulse Output

GPM/Pulse = K factor

450 Terminal	Pin	Description
5	1	+VDC
31	2	Pulse
6	3	-VDC


Note : Jump 5 & 35



UF 1000 | 4000 | 5000 – 4-20mA Output

450 Terminal	Pin	Description
5	1	+VDC
33	2	+mA
6	3	-VDC

Note : Jump 6 & 35




ProPulse (Flying Lead) – Pulse Output

GPM/Pulse = K factor

450 Terminal	Wire Color	Description
5	Red	+VDC
6	Shield	-VDC
31	Blue	Pulse


Note : Jump 5 & 35



ProPulse@2 – Pulse Output

450 Terminal	Wire Color	Description
5	Brown	+VDC
6	Blue	-VDC
31	Black	Pulse






































Note : Jump 5 & 35










Programming K Factor

STEPS	DISPLAY	OPERATION
1 Main Display ESC MENU 3 SEC		MAIN DISPLAY
2 Relay 1 ↓ X 5		RELAY 1 Settings
3 Input ENTER PAUSE		INPUT Menu
4 K Factor ENTER PAUSE		Press ↓ or ↑ → Select PULSEL (K Factor)
5 K Factor Value ENTER PAUSE 2 SEC		Enter K FACTOR Value Press ↓ or ↑ to change digit Press ENTER PAUSE to advance to next digit Note: Enter the K Factor value according to the Flow Unit. Eg: To display flow in GPM, Enter K Factor corresponding to GPM.
6 Save Value ENTER PAUSE		Save Selection
7 K Factor ESC MENU		PULSEL
8 Input ESC MENU		Input Menu
9 Main Display		Main Display


























Programming Relays


STEPS	DISPLAY	OPERATION
1 Main Display    3 SEC		MAIN DISPLAY
2 Relay 1  		RELAY 1 Settings
3 Source  		SOURCE Menu
4 FLo bAt tot  		Press  or  → Select FLo (Flow)
5 Save  		Save Selection
6 Source  		Source
7 Set Point 1  		SET POINT 1
8 Set Point 1 Value    2 SEC		Enter SET POINT 1 Value Press  or  to change digit Press  to advance to next digit
9 Save  		Save Value
10 Set Point 1  		SET POINT 1

STEPS	DISPLAY	OPERATION
11 Set Point 2 		SET POINT 2* * Option available only when the MODE is set to In/Out
12 Set Point 2 Value 2 SEC		Enter SET POINT 2 Value Press or to change digit Press to advance to next digit
13 Save 		Save Value
14 Set Point 2 		Set Point 2
15 Hysteresis 		HYSTERISIS Menu
16 Hysteresis Value 2 SEC		Enter HYSTERISIS Value Press or to change digit Press to advance to next digit
17 Save 		Save Value
18 Hysteresis 		Hysteresis Menu
19 Mode 		MODE Menu
20 On Off In Out 		Press or → Select On OFF In Out

STEPS	DISPLAY	OPERATION
21 Save 		Save Selection
22 Mode 		Mode Menu
23 Relay 1 		Relay 1 Menu
24 Main Display		Main Display

Programming Batching

STEPS	DISPLAY	OPERATION
1 Main Display  3 SEC		MAIN DISPLAY
2 Relay 1 		RELAY 1 Settings
3 Source 		SOURCE Menu
4 FLo bAt tot 		Press  or  → Select bAt (Batch)
5 Save 		Save Selection
6 Source 		Source
7 Set Point 1 		SET POINT 1
8 Set Point 1 Value  2 SEC		Enter SET POINT 1 Value Press  or  to change digit Press  to advance to next digit
9 Save 		Save Value
10 Set Point 1 		SET POINT 1

























Programming Output (For 4-20mA Output Models)






STEPS	DISPLAY	OPERATION
11 Set Point 2 		SET POINT 2* * Option available only when the MODE is set to In/Out
12 Set Point 2 Value  2 SEC 		Enter SET POINT 2 Value Press  or  to change digit Press  to advance to next digit
13 Save 		Save Value
14 Set Point 2 		Set Point 2
15 Hysterisis 		HYSTERISIS Menu
16 20mA 		Setting 20mA (HIGH VALUE)
17 20mA Value  2 SEC 		Enter 20mA Value Press  or  to change digit Press  to advance to next digit
18 Save 		Save Value
19 20mA 		20mA (High value)
20 Output 		Output Menu
21 Main Display		Main Display

Resetting Batch















8	Set Point Value	 ENTER PAUSE 2 SEC		Enter SET POINT Value	Press  or  to change digit Press  to advance to next digit
9	Save	 ENTER PAUSE		Save Value	
10	Set Point	 ESC MENU		Set Point	
11	Relay 1	 ESC MENU		Relay 1 Menu	
12	Main Display	 RESET		Main Display	
13	Batching Mode	 ENTER PAUSE to start batching		BATCHING MODE Note: Switching between Flow rate, Totalizer and Batching can be done by pressing  /RESET button. Kind of displayed value is signalised by "Σ" LED.  LED ON : Totalizer  LED OFF: Flow Rate  LED Pulsing: Batching	 R1  R2  Σ


Resetting Totalizer

STEPS	DISPLAY	OPERATION
1 Main Display  ESC MENU 3 SEC		MAIN DISPLAY
2 Relay 1  X 7		Relay 1 Settings
3 Batch Settings  ENTER PAUSE		BATCH Menu
4 Batch Resolution  X 5		BATCH RESOLUTION
5 Mode Clear  ENTER PAUSE		MODE CLEAR

6	oFF on			Press  or  → Select on
7	Save			Save Selection
8	Mode Clear			Mode Clear
9	Batch Settings			Batch Menu
10	Main Display			Main Display

Setting Decimal Point

STEPS	DISPLAY	OPERATION
1 Main Display  		MAIN DISPLAY
2 Relay 1  X 6		Relay 1 Settings
3 Flow Menu 		FLOW Menu *
4 Flow Precision 		FLOW PRECISION
5 Decimal Point 		DECIMAL POINT
		Press  or  to change Decimcal Point



* To change decimal points for Batch | Totalizer, select Batch | Totalizer Menu

Warranty, Returns and Limitations

Warranty

Icon Process Controls Ltd warrants to the original purchaser of its products that such products will be free from defects in material and workmanship under normal use and service in accordance with instructions furnished by Icon Process Controls Ltd for a period of one year from the date of sale of such products. Icon Process Controls Ltd obligation under this warranty is solely and exclusively limited to the repair or replacement, at Icon Process Controls Ltd option, of the products or components, which Icon Process Controls Ltd examination determines to its satisfaction to be defective in material or workmanship within the warranty period. Icon Process Controls Ltd must be notified pursuant to the instructions below of any claim under this warranty within thirty (30) days of any claimed lack of conformity of the product. Any product repaired under this warranty will be warranted only for the remainder of the original warranty period. Any product provided as a replacement under this warranty will be warranted for the one year from the date of replacement.

Returns

Products cannot be returned to Icon Process Controls Ltd without prior authorization. To return a product that is thought to be defective, go to www.iconprocon.com, and submit a customer return (MRA) request form and follow the instructions therein. All warranty and non-warranty product returns to Icon Process Controls Ltd must be shipped prepaid and insured. Icon Process Controls Ltd will not be responsible for any products lost or damaged in shipment.

Limitations

This warranty does not apply to products which: 1) are beyond the warranty period or are products for which the original purchaser does not follow the warranty procedures outlined above; 2) have been subjected to electrical, mechanical or chemical damage due to improper, accidental or negligent use; 3) have been modified or altered; 4) anyone other than service personnel authorized by Icon Process Controls Ltd have attempted to repair; 5) have been involved in accidents or natural disasters; or 6) are damaged during return shipment to Icon Process Controls Ltd reserves the right to unilaterally waive this warranty and dispose of any product returned to Icon Process Controls Ltd where: 1) there is evidence of a potentially hazardous material present with the product; or 2) the product has remained unclaimed at Icon Process Controls Ltd for more than 30 days after Icon Process Controls Ltd has dutifully requested disposition. This warranty contains the sole express warranty made by Icon Process Controls Ltd in connection with its products.

ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. The remedies of repair or replacement as stated above are the exclusive remedies for the breach of this warranty. IN NO EVENT SHALL Icon Process Controls Ltd BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING PERSONAL OR REAL PROPERTY OR FOR INJURY TO ANY PERSON. THIS WARRANTY CONSTITUTES THE FINAL, COMPLETE AND EXCLUSIVE STATEMENT OF WARRANTY TERMS AND NO

PERSON IS AUTHORIZED TO MAKE ANY OTHER WARRANTIES OR REPRESENTATIONS ON BEHALF OF Icon Process Controls Ltd. This warranty will be interpreted pursuant to the laws of the province of Ontario, Canada.

If any portion of this warranty is held to be invalid or unenforceable for any reason, such finding will not invalidate any other provision of this warranty.

For additional product documentation and technical support visit: www.iconprocon.com

- e-mail: sales@iconprocon.com or support@iconprocon.com
- Ph: 905.469.9283

Corrosion-Free Instrumentation Equipment

FAQ

- **What should I do if the unit malfunctions?**

If the unit malfunctions, disconnect it from the power supply and contact an authorized service center for repairs.

- **Can I use the unit in areas with explosive risks?**

Avoid using the unit in areas with a risk of explosions to ensure safety and prevent damage to the equipment.

- **How do I ensure correct operation in industrial installations?**

Appropriate measures should be applied to minimize interference and ensure the correct operation of the unit in industrial settings.

Documents / Resources



[ICON Procon TVF-450 Flow Batching Controller](#) [pdf] User Guide

TVF-450 Flow Batching Controller, TVF-450, Flow Batching Controller, Batching Controller, Controller

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.