



# IDEC FC6A Series MicroSmart CPU Module Instructions

[Home](#) » [IDEC](#) » IDEC FC6A Series MicroSmart CPU Module Instructions 

IDEC FC6A Series MicroSmart CPU Module



This sheet provides brief operating instructions of the MICROSmart programmable controller. For details, see the FC6A Series MICROSmart User's Manual.

## Contents

- 1 Safety Precautions
- 2 TYPE
- 3 Specification
- 4 Name & Function
- 5 Assembling Modules
- 6 Default Setting of the Function Switch
- 7 Mounting Modules
- 8 Installation in Control Panel & Mounting Direction
- 9 Dimensions
- 10 Wiring
- 11 CAN Port (SAE J1939)
- 12 Precaution for Disposal
- 13 Documents / Resources
- 14 Related Posts

## Safety Precautions

Special expertise is required to use the MICROSmart.

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MICROSmart.  
Keep this instruction sheet where it can be accessed by the end user.
- All MICROSmart modules are manufactured under I DEC's rigorous quality control system, but users must add backup or failsafe provisions to control systems use the MICROSmart in applications where heavy damage or personal injury may be caused if the MICROSmart should fail.
- Install the MICROSmart according to the instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MICROSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact I DEC before using the MICROSmart.
- In this instruction sheet, safety precautions are categorized in order of importance from Warning and Caution:



Warning notices are used to emphasize that improper operation may cause severe personal injury or death.



Warning notices are used to emphasize that improper operation may cause severe personal injury or death.



- Turnoff the power to the MICROSmart before starting installation, removal, wiring, maintenance, or inspection on the MICROSmart. Failure to turn off the power may cause damage, electrical shocks or fire hazard.

- Emergency stop and interlocking circuits must be configured outside the MICROSmart. If such a circuit is configured inside the MICROSmart, failure of the MICROSmart may cause disorder of the control system, damage, or accidents.
- SUITABLE FOR USE IN CLASS 1, DIVISION 2, GROUPS A,B,C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.
- WARNING – EXPLOSION HAZARD – DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.
- THIS EQUIPMENT IS AN OPEN -TYPE DEVICE MEANT TO BE INSTALLED IN AN ENCLOSURE SUITABLE FOR THE ENVIRONMENT THAT IS ONLY ACCESSIBLE WITH THE USE OF A TOOL OR KEY
- WARNING – EXPLOSION HAZARD – THE USB PORT IS NOT FOR USE IN HAZARDOUS LOCATIONS



- The MICROSmart is designed for installation in equipment. Do not install the MICROSmart outside of equipment.
- Install the MICROSmart in environments as described in the user's manual. If the MICROSmart is used in places where it is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, or excessive shocks it will result in electrical shocks, fire hazard, or malfunction.
- The environment rating for using the MICROSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MICROSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to the proper tightening torque.  
(Power supply Terminals: 0.51 N-m, Input Terminals and Output Terminals: 0.28 N-m)
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T)
- This is required when exporting equipment containing MICROSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MICROSmart to Europe.
- If relays or transistors in the MICROSmart output modules should fail, outputs may remain on or off.
- For output signals which may cause heavy accidents, provide a monitor circuit outside of the MICROSmart.
- Do not disassemble, repair, or modify MICROSmart modules

This symbol mark means that batteries and accumulators, at their end-of life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows:

Hg : Mercury (0.0005%) Cd : Cadmium (0.002%) Pb : Lead (0.004%)

In the European Union there are separate collection systems for used batteries and accumulators.

Please dispose of batteries and accumulators correctly in accordance with each country or local regulation.



## TYPE

Power Supply Type	Output Type	Type No.
100-240VAC	Relav	FC6A-C40R1AEJ
24VDC	Relav	FC6A-C40R1CEJ
	Transistor Sink	FC6A-C40K1CEJ
	Transistor Protect Source	FC6A-C40P1CEJ
12VDC	Relav	FC6A-C40R1 DEJ
	Transistor Sink	FC6A-C40K1DEJ
	Transistor Protect Source	FC6A-C40P1DEJ

Packing(Pcs/pack): FC6A Unit (1), Connector with analog input cable (1 ), Battery holder with battery (1) ~ Instruction Sheet (this manual) (1 ).

## Specification

Operating Temperature: -10 to +55°C(no freezing)

Expanded Operating Temperature: -25 to -10°C, +55 to 65°C (no freezing)

- See the use~s manual for details on use in Expanded Operating Temperatures.

Storage Temperature: -25 to +70°C(no freezing)

Relative/ Storage Humidity: 10 to 95%RH (no condensation)

Altitude or Air Pressure: 1,013 to 795hPa (0 to 2,000 m) during operation 1,013 to 701 hPa (0 to 3,000 m) during transport,

Vibration Resistance: 5 to 8.4 Hz half amplitude 3.5 mm, 8.4 to 150 Hz, acceleration 9.8 mis' (1 G), X, Y, Z directions, 2 hours,



Shock Resistance: 147 mis' (15 G), 11 ms, X, Y, Z, 3 axes, 6 directions, 3 times each Installation Location : Inside cabinet (indoor use)

Maximum Surrounding Air Temperature: 55°C / 65°C


Temperature Code: T4A

- See the user's manual for more details on the product specifications.

## Name & Function



## Assembling Modules



1. Grasp the battery holder and remove it from the module." (a)
2. Remove the old back up battery from the battery holder (c) by pulling the outside hook. (b)
3. Install a new back up battery in the battery holder.  
Push the battery in until the outside hook (b) clicks.
4. Insert the battery holder into the module. (a)
  - The length of the battery holder is 36 mm.





- Warning: Replace Only The Battery With Panasonic BR2032, Or The Alternative Batteries Compatible On The List As Below. Use of Another Battery May Present A Risk of Fire Or Explosion.

Alternative Batteries Compatible with BR2032	
CR2032X or CR2032W	Murata
CR2032A or CR2032B	Panasonic




- Change the battery before the old battery expires.
- Do not change the battery when the MICROSmart is power ON. Doing so may damage the product.
- Change the battery within 1 minute of turning off the power supply, or the device value will be reset to its initial values.
- Battery May Explode If Mistreated. Do Not Recharge,Disassemble Or Dispose Of In Fire.

### Default Setting of the Function Switch

- 1**  • The default setting of the function switch is 0.
- 0**  • The PLC will not run if the function switch is 0 when Run/Stop PLC by Function Switch is enabled in WindLDR and a program is downloaded with Automatic start after download enabled.
- To run the PLC, the function switch must be set to 1.
- Enabled is the default setting for Run/Stop PLC by Function Switch in WindLDR.
  - For details on the function switch, see the user's manual.

### Mounting Modules

For details about mounting and removing modules, see the user's manual.




[ Mounting on DIN Rail]

Use a 35-mm-wide DIN Rail and BNL6 mounting clips to secure the modules.




1. Pull out the DIN Rail Hook.
2. Put the groove of the module on the DIN Rail.
3. Press the modules towards the DIN Rail.
4. Push in the DIN Rail Hook.



**[Direct Mounting on Panel Surface]**

Pull out the DIN Rail Hook on the back of the module and insert the direct mounting Hook (FC6A-PSP1 PN05) into the slot. Attach the module to the mounting plate using the screw holes.

Attach the module to the mounting plate using M4 tapping screws, as shown below, or make 5 to 6mm mounting holes and secure the module using M4 pan head screws. Always give sufficient consideration to operability, ease-of-maintenance, and environmental resistance when deciding on the mounting position.





## ⚠ CAUTION

When an expansion module is not connected next, don't peel off the protection sticker.

### Installation in Control Panel & Mounting Direction


Mount the FC6A MicroSmart as follows. To provide ample ventilation, ensure that there is sufficient space between the FC6A MicroSmart and other devices, heat sources, and panel surfaces.






For UL/cUL, Horizontal mounting only.

## Dimensions



\*See the user's manual for more details on the dimensions.


## Wiring



100 to 240V AC power supply type: Support of sensor power which is in the circle area of above figure is able to be used instead of 24V DC external power.

24V DC power supply type: No support of sensor power. Therefore 24V DC external power is required.

12V DC power supply type: No support of sensor power. Therefore 12V DC external power is required.



\* See the use~s manual for more details on the wiring.

## CAUTION

- Use a Class 2 power supply source when power supply voltage less than 30V DC is required to power the terminal.
- Use copper conductor only.
- When the MICROSmart is used in a Surrounding Air Temperature of 65°C, reduce the I/O voltage and I/O utilization. See the users manual for details.

### CAN Port (SAE J1939)

No.	Signal wire	J1939-11		J1939-15	
		Cable Type		Shielded	Unshielded
1	SG	Twisted pair Cable		0.3mm <sup>2</sup> - 0.82mm <sup>2</sup> (AWG22-18)	
2	CAN_L				
3	CAN_SHLD* <sup>1</sup>				
4	CAN_H	Standards		ISO 11898/1993	
5	(V+)* <sup>2</sup>	Characteristic impedance		120Ω	

- 1 This port is connected to SG inside via resistor and capacitor connected in series (R=1Ω, C=0.68μF)

- 2 This port is N.C. Not connect to inside.
- 3 Use Termination resistors (1200, 0.5W or higher) at the both ends of the network.

The recommended ferrule is made by Phoenix Contact or Weidmiüller. To crimp the ferrules shown below, use a special crimping tool. (CRIMPFOX6 (1212034) or PZ 6 Rote L (1444050000)) To the terminal block, use the recommended screwdriver made by Phoenix Contact or Weidmiüller and lighten terminal screws tightening torque. Power supply Terminals, Input Terminals and Output Terminals :

Applied cable		Recommended ferrule
UL1007 / UL 2464	AWG24	Al 0,25-6 (3203040). Al 0.25-8 (3203037). H0.25/10 HBL(9025740000). H0.25/12T GE (9021020000)
	AWG22	Al 0,34-6 (3203053), Al 0,34-8 (3203066), H0,34/10 TK(9025750000), H0,34/12 TK (9025770000)
	AWG20	Al 0,5-6 (3200687), Al 0,5-8 (3200014), Al-TWIN 2×0,5-8 (3200933), H0.5/12D W(9019000000). H0.5/16D W (9019020000). H0,5/14D ZH W (9037380000)
	AWG18	Al 0,75-6 (3200690). Al 0,75-8 (3200519), Al-TWIN 2×0.75-8 (3200807), H0.75/12D GR (9019030000). H0.75/14D GR (9019040000). H0,75/14D ZH GR (9037410000)
	AWG16	Al 1,5-6 (3200755). Al 1.5-8 (3200043). H1.5/14D SW (9019120000)
UL1015	AWG20	Al 0,5-8 GB (1208966)
	AWG18	Al 1-8 (3200030), H1,0/14D R (9019080000)
	AWG16	Al 1,5-6 (3200755), Al 1,5-8 (3200043), H1,5/14D SW (9019120000)

Screwdriver	Tighten torque
SZS 0,6×3,5 (1205053). SDS 0.6×3.5×100 (9008330000)	0.51 N-m

## CAN Port

Applied cable		Recommended ferrule
UL1007 / UL 2464	AWG24	Al 0.25-10 (3241128)
		Al 0,34-10 (3241129)
	AWG20	Al 0,5-10 (3201275), Al-TWIN2x0,5-10 (3203309), H 0,5/16D W (9019020000). H 0,5/16D ZH W (9037390000)
		Al 0.75-10 (3201288). Al-TWIN 2x0,75-10 (3200975). H 0,75/16D GR (9019050000), H 0,75/16D ZH GR(9037420000)
	AWG16	Al 1,5-10 (3200195), H 1,5/16D SW (9019130000)
UL1015		Al 0.5-10 GB (3203150). H 0.5/16 DS W (9202910000)
		Al 1-10 (3200182), H 1,0/16D R (9019100000)
	AWG16	Al 1.5-10(3200195). H 1.5/16D SW (9019130000)

Screwdriver	Tighten torque
SZS 0,6×3,5 (1205053), SDS 0,6×3,5×100 (9008330000)	0.49 N-m

( ) indicates the Type No. of PHOENIX CONTACT GmbH & Co. KG and Weidmiüller Interface GmbH & Co. KG.

## Precaution for Disposal


- Dispose of the FC6A Series MICROSmart as an industrial waste.

MicroSmart User's manual can be downloaded from <http://www.idec.com/FC6Amanuals>

[www.idec.com](http://www.idec.com)



## Documents / Resources

	<b><a href="#">IDEC FC6A Series MicroSmart CPU Module</a></b> [pdf] Instructions FC6A Series, MicroSmart CPU Module, FC6A Series MicroSmart CPU Module
---	---

