



## **IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions Instruction Manual**

[Home](#) » [Ikea](#) » **IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions Instruction Manual** 


## Contents

- 1 [IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions Instruction Manual](#)
- 2 [IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions](#)
- 3 [Safety Information](#)
- 4 [SAFETY WARNINGS](#)
- 5 [Permitted use](#)
- 6 [Pyrolytic cleaning:](#)
- 7 [Installation](#)
- 8 [Electrical warnings](#)
- 9 [Environmental concerns](#)
- 10 [SAFETY WARNINGS](#)
- 11 [DISPOSAL OF PACKAGING MATERIALS](#)
- 12 [SCRAPPING OF HOUSEHOLD APPLIANCES](#)
- 13 [ENERGY SAVING TIPSs](#)
- 14 [Notes on cleaning](#)
- 15 [How to clean: Cavity embossment](#)
- 16 [How to remove: Shelf supports](#)
- 17 [How to use: Pyrolytic Cleaning](#)
- 18 [How to remove and install: Door](#)
- 19 [Cleaning reminder](#)
- 20 [The cleaning reminder goes out:](#)
- 21 [How to replace: Lamp](#)
- 22 [IKEA guarantee](#)
- 23 [How long is the IKEA guarantee valid?](#)
- 24 [Who will execute the service?](#)
- 25 [What does this guarantee cover?](#)
- 26 [What will IKEA do to correct the problem?](#)
- 27 [What is not covered under this guarantee?](#)
- 28 [How country law applies](#)
- 29 [Area of validity](#)
- 30 [The dedicated After Sales Service for IKEA](#)
- 31 [How to reach us if you need our service](#)
- 32 [SAVE THE SALES RECEIPT! It is](#)
- 33 [Do you need extra help?](#)
- 34 [Read More About This Manual & Download PDF:](#)
- 35 [Documents / Resources](#)
  - 35.1 [References](#)
- 36 [Related Posts](#)

## IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions Instruction Manual



### IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions



## Safety Information

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

## SAFETY WARNINGS

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children of less than 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised. Children must not play with the appliance. Keep all packaging away from children and dispose of it appropriately. Children shall not carry out cleaning and user maintenance of the appliance without supervision. If the appliance has a child safety device, it should be activated.

**WARNING:** The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.

**WARNING:** Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock. If the supply cord is damaged, it must be replaced with an identical one by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard – risk of electrical shock.

This appliance is for household use only. Do not change the specification of this appliance. Always cook with the oven door closed. Use oven gloves to remove pans and accessories.



Do not use a steam cleaner to clean the appliance. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door since they can scratch the surface, which may result in shattering of the glass. The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules. Excessive spillage must be removed before the pyrolytic cleaning. Remove all parts from the oven.

## Permitted use

Risk of injury, burns, electric shock, fire, explosion or damage to the appliance.

This appliance is for cooking purposes only. It must not be used for other purposes, for example room heating. Do not let the appliance stay unattended during operation. Deactivate the appliance after each use. Make sure that the ventilation openings are not blocked.

Keep clothes or other flammable materials away from the appliance, until all the components have cooled down completely – risk of fire.

If the appliance is installed behind a furniture panel (e.g. a door) make sure the door is never closed when the appliance operates. Heat and moisture can build up behind a closed furniture panel and cause subsequent damage to the appliance, the furniture or the floor. Do not close the furniture panel until the appliance has cooled down after use.

Do not operate the appliance with wet hands or when it has contact with water. Do not apply pressure on the open door. Be careful when you remove the door from the appliance. The door is heavy. Do not use the appliance as a work surface or as a storage surface.

Be careful when you open the appliance door while the appliance is in operation. Hot air can release. Do not put flammable products or items that are wet with flammable products in, near or on the appliance. When you place food into hot oil, it may splash. Do not let sparks or open flames to come in contact with the appliance when you open the door. Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.

To prevent damage or discoloration to the enamel:

- Do not put ovenware or other objects in the appliance directly on the
- Do not put aluminium foil directly on the bottom of cavity of the
- Do not put water directly into the hot
- do not keep moist dishes and food in the appliance after you finish the
- be careful when you remove or install the

Use a deep pan for moist cakes. Fruit juices cause stains that can be permanent. Discoloration of the enamel or stainless steel has no effect on the performance of the appliance.

Clean regularly the appliance to prevent the deterioration of the surface material.

Before maintenance, deactivate the

appliance and disconnect from the mains. Ensure the appliance is cooled down before any cleaning or maintenance – risk of burn. Be careful when you remove the door from the appliance. The door is heavy. There is also the risk that the glass panels can break. Replace immediately the door glass panels when they are damaged. Contact the Authorised Service Centre.

Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects. Do not clean the catalytic enamel with detergents (if applicable). Fat and food remaining in the appliance can cause fire. Do not remove the knobs from the appliance (if applicable). If you use an oven spray, follow the safety instructions on its packaging.

### **Pyrolytic cleaning:**

Risk of Injury / Fires / Chemical Emissions (Fumes) during the pyrolytic mode. Read carefully all the instructions for pyrolytic cleaning.

During pyrolytic cleaning, fumes are released that are not harmful to humans, including infants or persons with medical conditions.

Unlike all humans, some birds and reptiles can be extremely sensitive to potential fumes emitted during the cleaning process of all pyrolytic ovens. Small pets can also be highly sensitive to the localized temperature changes in the vicinity of all pyrolytic ovens when the pyrolytic self- cleaning program is in operation.

Before carrying out a pyrolytic self- cleaning function or the First Use please remove from the oven cavity:

- Any excess food residues, oil or grease spills /
- Any removable objects (including shelves, side rails / telescopic runners, etc. provided with the product) particularly any non-stick pots, pans, trays, utensils

Non-stick surfaces on pots, pans, trays, utensils etc., can be damaged by the high temperature pyrolytic cleaning operation of all pyrolytic ovens and can be also a source for low level harmful fumes.

Keep children away from the appliance while the pyrolytic cleaning is in operation. The appliance becomes very hot and hot air is released from the front cooling vents.

Pyrolytic cleaning and first maximum temperature use are high temperature operations that can release fumes from cooking residues and construction materials, as such consumers are strongly advised to:

- Provide good ventilation during and after each pyrolytic
- Provide good ventilation during and after the first use at maximum temperature

Ensure that any pets (especially birds) are taken as far as possible from the vicinity of the appliance location during and after the pyrolytic cleaning and first use maximum temperature operation. Keeping them in a different room would be the preferred option during the pyrolytic cycle and until appliance has cooled down again to room temperature. Good ventilation has to be provided during and after (till appliance cool down) operations of the pyrolytic cycle and first maximum temperature use cycle.

## Installation



The appliance must be handled and installed by two or more persons – risk of injury. Always use safety gloves and enclosed footwear – risk of cuts.

Installation, including water supply (if any) and electrical connections, service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy (if any) and repairs must be carried out by the authorised installer. Follow the assembly instructions supplied with the appliance.

Remove all the packaging. Make sure that the appliance has not been damaged during transport. In the event of problems, contact the dealer or your nearest Authorised Service Centre. Do not install or use a damaged appliance.

Install the appliance in a safe and suitable place that meets installation requirements. Do not use the appliance before installing it in the built-in structure.

Do not pull the appliance by the handle. Keep the minimum distance from other appliances and units. Before mounting the appliance, check if the oven door opens without restraint.

Ensure that the appliance is switched off and disconnected from the power supply before performing any maintenance operation – risk of electric shock. During installation, make sure the appliance does not damage the power cable – risk of fire or electric shock. Only activate the appliance when the installation has been completed. Do not obstruct the minimum gap between the worktop and the upper edge of the oven – risk of burns.

## Electrical warnings

Risk of fire and electric shock.

Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.

Do not use extension leads, multi-plug sockets or adapters. Do not operate the appliance if it has a damaged power cable or plug, if it is not working properly, or if it has been damaged or dropped. The appliance must be earthed. Always use a correctly installed shockproof socket. The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools. The electrical components must not be accessible to the user after installation.

The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm. Use only correct isolation devices: line protecting cutouts, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.

Connect the mains plug to the mains socket only at the end of the installation. Fully close the appliance door before you connect the mains plug to the mains socket. Make sure that there is access to the mains plug after the installation. If the mains socket is loose, do not connect the mains plug. Do not pull the mains cable to disconnect the appliance. Always pull the mains plug. Do not let mains cables touch or come near the appliance door or the niche below the appliance, especially when it operates or the door is hot.

To replace the power cable, contact the Authorized Service Centre.

This product contains a light source of energy efficiency class G.

Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational status of the appliance. They are not intended to be

used in other applications and are not suitable for household room illumination.

## Environmental concerns

## **SAFETY WARNINGS**

Before disposal, disconnect the appliance from the mains supply. Cut off the mains electrical cable close to the appliance and dispose of it. Remove the door catch to prevent children or pets from becoming trapped in the appliance – risk of injury or suffocation.

## **DISPOSAL OF PACKAGING MATERIALS**

Recycle materials with the symbol . Put the packaging in relevant containers to recycle it.

## **SCRAPPING OF HOUSEHOLD APPLIANCES**

Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of

appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

## **ENERGY SAVING TIPSS**

**NOTE:** This appliance has features which help you save energy during everyday cooking.

Make sure that the oven door is closed properly when the oven operates. Do not open the door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position. Use metal dishes to improve energy saving. When possible, do not preheat the oven before you put the food inside.

When the cooking duration is longer than 30 minutes, reduce the oven temperature to minimum 3 – 10 minutes before the end of the cooking time, depending on the duration of the cooking. The residual heat inside the oven will continue to cook.

Use the residual heat to warm up other dishes. Keep breaks between baking as short as possible when you prepare few dishes at one time. Choose the lowest possible temperature setting to use residual heat and keep a meal warm.




When possible, use the cooking functions with fan to save energy.

If a programme with the Duration or End Time selection is activated and the cooking time is longer than 30 minutes, the heating elements automatically deactivate earlier in some oven functions (if applicable).

When possible, turn off the lamp during cooking. Turn it on only when you need it.

Moist Fan Baking (if applicable): Function designed to save energy during cooking. When you use this function the lamp automatically turns off.

## **Notes on cleaning**

 <b>Cleaning Agents</b>	Clean the front of the appliance with a microfibre cloth with warm water and a mild detergent.
	Use a cleaning solution to clean metal surfaces.
	Clean stains with a mild detergent.
 <b>Everyday Use</b>	Clean the cavity after each use. Fat accumulation or other residue may cause fire.
	Moisture can condense in the appliance or on the door glass panels. To decrease the condensation, let the appliance work for 10 minutes before cooking. Do not store the food in the appliance for longer than 20 minutes. Dry the cavity with a microfibre cloth after each use.
 <b>Accessories</b>	Clean all accessories after each use and let them dry. Use a microfibre cloth with warm water and a mild detergent. Do not clean the accessories in a dishwasher.
	Do not clean the non-stick accessories using abrasive cleaner or sharp-edged objects.



### How to clean: Cavity embossment

Clean the cavity embossment to remove limestone residue after cooking with steam

Step 1	Step 2	Step 3	
Pour: 250 ml of white vinegar	Let the vinegar dissolve the	Clean the cavity with warm	
into the cavity embossment.	limestone residue at the ambient	water and a soft cloth.	
Use maximum 6% vinegar	temperature for 30 minutes.		
without any additives.			
For the function: Direct Steam clean the oven for every 5 – 10 cooking cycles.			

## How to remove: Shelf supports

Remove the shelf supports to clean the oven.

<b>Step 1</b>	Turn off the oven and wait until it is cold.	
<b>Step 2</b>	Pull the front of the shelf support away from the side wall.	
<b>Step 3</b>	Pull the rear end of the shelf support away from the side wall and remove it.	
<b>Step 4</b>	Install the shelf supports in the opposite sequence.	

## How to use: Pyrolytic Cleaning

**Warning!** The oven becomes very hot. There is a risk of burns.

**Warning!** Ensure that any pets (especially birds) are taken as far as possible from the vicinity of the appliance location during and after the Pyrolytic cleaning and first use maximum temperature operation. Keeping them in a different room would be the preferred option during the pyrolytic cycle and until appliance has cooled down again to room temperature. Good ventilation has to be provided during and after (till appliance cool down) operations of the pyrolytic cycle and first maximum temperature use cycle.

**Warning!** Before carrying out a Pyrolytic self-cleaning function or the First Use, please remove from the oven cavity:

- Any excess food residues, oil or grease spills /
- Any removable objects (including shelves, side rails / telescopic runners, etc. provided with the product) particularly any non-stick pots, pans, trays, utensils

**Caution!** Do not use the hob at the same time as the Pyrolysis function. It can cause damage to the oven.

Before you turn on the Pyrolysis:

- remove all the accessories and removable shelf
- clean the oven floor with warm water and mild
- clean the inner door glass with warm water and soft
- close the oven door.

1. Set the Pyrolysis Refer to “Daily Use” chapter, Oven functions.

1. When the display shows P1, press to start the

You can use the End function to delay the start of the cleaning.

During the Pyrolysis the oven lamp is off. Time of the procedure: 1 h 30 min.

2. When the oven is at the set temperature,

the door locks. The display shows . Do not open the door before the procedure completes. This will

abort the procedure. When the oven cools down, the door automatically unlocks.

3. When Pyrolysis is completed, the display shows the time of day. The oven door stays locked. When the oven is cool again, the signal sounds and the door

## **How to remove and install: Door**

To stop Pyrolysis before it is completed, turn the knob for the oven functions to the off position.

## **Cleaning reminder**



To remind you that the pyrolysis is necessary, PYR flashes in the display for 10 seconds after each activation and deactivation of the oven.


## **The cleaning reminder goes out:**


- after the end of the
- if you press and at the same time while PYR flashes in the

The oven door has three glass panels. You can remove the oven door and the internal glass panels to clean them. Read the whole “Removing and installing door” instruction before you remove the glass panels.

**Caution!** Do not use the oven without the glass panels.

<b>Step 1</b>	Open the door fully and hold both hinges.	
<b>Step 2</b>	Lift and pull the latches until they click.	


<b>Step 3</b>	Close the oven door halfway to the first opening position. Then lift and pull to remove the door from its seat.	
<b>Step 4</b>	Put the door on a soft cloth on a stable surface.	
<b>Step 5</b>	Hold the door trim (B) on the top edge of the door at the two sides and push inwards to release the clip seal.	

<b>Step 6</b>	Pull the door trim to the front to re- move it.	
<b>Step 7</b>	Hold the door glass panels by their top edge and carefully pull them out one by one. Start from the top pan- el. Make sure the glass sli des out of the supports completely.	
<b>Step 8</b>	Clean the glass panels with water and soap. Dry the glass panels carefully. Do not clean the glass panels in the dishwasher.	
<b>Step 9</b>	After cleaning, install the glass panels, the door trim and the oven door, close the latches on the b oth hinges.	
If the door is installed correctly, you will hear a click when closing the latches.		

Make sure that you put the glass panels (A and B) back in the correct sequence. Check for the symbol / printing on the side of the glass panel, each of the glass panels looks different to make the disassembly and as- sembly easier.

The screen-printing zone must face the in- ner side of the door. Make sure that after the installation the surface of the glass pan- el frame on the screen-printing zones is not rough when you touch it.

When installed correctly the door trim clicks.  
Make sure that you install the middle panel of glass in the seats correctly.



**How to replace: Lamp**

**Warning!** Risk of electric shock.

The lamp can be hot.  
Always hold the halogen lamp with a cloth to prevent grease residue from burning on the lamp

<b>Before you replace the lamp:</b>		
<b>Step 1</b>	<b>Step 2</b>	<b>Step 3</b>
Turn off the oven. Wait until the oven is cold.	Disconnect the oven from the mains.	Put a cloth on the bottom of the cavity.

Back lamp

<b>Step 1</b>	Turn the glass cover to remove it.
<b>Step 2</b>	Clean the glass cover.
<b>Step 3</b>	Replace the lamp with a suitable 300 °C heat-resistant lamp.
<b>Step 4</b>	Install the glass cover.

## **IKEA guarantee**

### **How long is the IKEA guarantee valid?**

This guarantee is valid for **5 years** from the original date of purchase of your appliance at IKEA. The original sales receipt is required as proof of purchase. If service work is carried out under guarantee, this will not extend the guarantee period for the appliance.

### **Who will execute the service?**

IKEA service provider will provide the service through its own service operations or authorized service partner network.

### **What does this guarantee cover?**

The guarantee covers faults of the appliance, which have been caused by faulty construction or material faults from the date of purchase from IKEA. This guarantee applies to domestic use only. The exceptions are specified under the headline "What is not covered under this guarantee?" Within the guarantee period, the costs to remedy the fault e.g. repairs, parts, labour and travel will be covered, provided that the appliance is accessible for repair without special expenditure. On these conditions the EU guidelines (Nº 99/44/EG) and the respective local regulations are applicable. Replaced parts become the property of IKEA.

### **What will IKEA do to correct the problem?**

IKEA appointed service provider will examine the product and decide, at its sole discretion, if it is covered under this guarantee. If considered covered, IKEA service provider or its authorized service partner through its own service operations, will then, at its sole discretion, either repair the defective product or replace it with the same or a comparable product.

### **What is not covered under this guarantee?**

- Normal wear and
- Deliberate or negligent damage, damage caused by failure to observe operating

instructions, incorrect installation or by connection to the wrong voltage, damage caused by chemical or electro-chemical reaction, rust, corrosion or water damage including but not limited to damage caused by excessive lime in the water supply, damage caused by abnormal environmental conditions.

- Consumable parts including batteries and
- Non-functional and decorative parts which do not affect normal use of the appliance, including any scratches and possible color
- Accidental damage caused by foreign objects or substances and cleaning or unblocking of filters, drainage systems or soap
- Damage to the following parts: ceramic glass, accessories, crockery and cutlery baskets, feed and drainage pipes, seals, lamps and lamp covers, screens, knobs, casings and parts of Unless such damages can be proved to have been caused by production faults.
- Cases where no fault could be found during a technician's
- Repairs not carried out by our appointed service providers and/or an authorized service contractual partner or where non- original parts have been
- Repairs caused by installation which is faulty or not according to specification.
- The use of the appliance in a non- domestic environment e. professional use.
- Transportation damages. If a customer transports the product to their home or other address, IKEA is not liable for any damage that may occur during However, if IKEA delivers the product to the customer's delivery address, then damage to the product that occurs during this delivery will be covered by this guarantee.
- Cost for carrying out the initial installation of the IKEA appliance. However, if an IKEA

service provider or its authorized service partner repairs or replaces the appliance under the terms of this guarantee, the service provider or its authorized service partner will re-install the repaired appliance or install the replacement, if necessary.

This restriction do not apply to fault-free work carried out by a qualified specialist using our original parts in order to adapt the appliance to the technical safety specifications of another EU country.

## **How country law applies**

The IKEA guarantee gives you specific legal rights, which covers or exceed local demands. However these conditions do not limit in any way consumer rights described in the local legislation.

## **Area of validity**

For appliances which are purchased in one EU country and taken to another EU country, the services will be provided in the framework of the guarantee conditions normal in the new country. An obligation to carry out services in the framework of the guarantee exists only if the appliance complies and is installed in accordance with:

- the technical specifications of the country in which the guarantee claim is made;
- the Assembly Instructions and User Manual Safety Information;

## **The dedicated After Sales Service for IKEA**

**appliances:**

Please do not hesitate to contact IKEA After Sales Service to:

1. make a service request under this guarantee;
2. ask for clarification on installation of the IKEA appliance in the dedicated IKEA kitchen furniture. The service won't provide clarifications related to:
  - the overall IKEA kitchen installation;
  - connections to electricity (if machine comes without plug and cable), to water and to gas since they have to be executed by an authorized service
3. ask for clarification on user manual contents and specifications of the IKEA

To ensure that we provide you with the best assistance, please read carefully the Assembly Instructions and/or the User Manual section of this booklet before contacting us.

### How to reach us if you need our service

Please refer to the last page of this manual for the full list of IKEA appointed contacts and relative national phone numbers.

In order to provide you with a quicker service, we recommend that you use the specific phone numbers listed at the end of this manual. Always refer to the numbers listed in the booklet of the specific appliance you need an assistance for. Before calling us, assure that you have to hand the IKEA article number (8 digit code) and the Serial Number (8 digit code that can be found on the rating plate) for the appliance of which you need our assistance.

### SAVE THE SALES RECEIPT! It is

your proof of purchase and required for the guarantee to apply. Note that the receipt reports also the IKEA article name and number (8 digit code) for each of the appliances you have purchased.

### Do you need extra help?

For any additional questions not related to After Sales of your appliances, please contact our nearest IKEA store call centre. We recommend you read the appliance documentation carefully before contacting us.

Country	Phone number	Call Fee	Opening time
België	070 246016	Binnenlandse gesprekskosten	8 tot 20 Weekdagen

<b>Belgique</b>		Tarif des appels nationaux	8 à 20. En semaine
<b>България</b>	+359 2 492 9397	Според тарифата на оператора за обаждания към стационарен номер	От 8:30 до 17:30 ч в работни дни
<b>Česká Republika</b>	246 019721	Cena za místní hovor	8 až 20 v pracovních dnech
<b>Danmark</b>	70 15 09 09	Landstakst	man. – fre. 09.00 – 20.00 lør. – søn. 09.00 – 18.00
<b>Deutschland</b>	+49 1806 33 45 32*	* 0,20 €/Verbindung aus dem Fest- netz max. 0,60 €/Verbindung aus dem Mobilfunknetz	Werktags von 8.00 bis 20.00
<b>Ελλάδα</b>	211 176 8276	Υπεραστική κλήση	8 έως 20 κατά τις εργάσιμες ημέρες

<b>España</b>	91 1875537	Tarifa de llamadas nacionales	De 8 a 20 en días laborables
<b>France</b>	0170 36 02 05	Tarif des appels nationaux	9 à 21. En semaine
<b>Hrvatska</b>	00385 1 6323 339	Cijena ovisi o pružatelju telefonske usluge korisnika	radnim danom od ponedjeljka do petka od 08:00 do 16:00
<b>Ireland</b>	0 14845915	National call rate	8 till 20 Weekdays
<b>Ísland</b>	+354 5852409	Innanlandsgjald fyrir síma	9 til 18. Virka daga
<b>Italia</b>	02 00620818	a applicata alle chiamate nazionali	dalle 8 alle 20 nei giorni feriali
<b>Κυπρος</b>	22 030 529	Υπεραστική κλήση	8.30 έως 16.30 κατά τις εργάσιμες ημέρες

<b>Lietuva</b>	5 230 06 99	Nacionalinių pokalbių tarifai	Pr. – Ketv.: 8:00 – 12:00, 12:45 – 17:00 Pnkt.: 8:00 – 12:00, 12:45 – 15:45
<b>Magyarország</b>	06-1-252-1773	Belföldi díjszabás	Hétköznapi 8.00 és 17.00 óra között
<b>Nederland Luxembourg</b>	050-7111267 (0900-BEL IKEA) +31 507111267 (internationaal)	Geen extra kosten. Alleen lokaal tarief.	ma-vr: 8.00 – 21.00 zat: 9.00 – 21.00 zon / pub. vakantie: 10.00 – 18.00
<b>Norge</b>	22 72 35 00	Takst innland	8 til 18 ukedager
<b>Österreich</b>	+43-1-2056356	max. 10 Cent/min.	Mo – Fr 8.00 – 20.00 Uhr
<b>Polska</b>	801 400 711 and +48 22 749 60 99	Koszt zgodny z taryfą operatora	Od 8 do 20 w dni robocze


<b>Portugal</b>	211557985	Chamada Nacional	9 às 21. Dias de Semana *excepto feriados
<b>România</b>	021 211 08 88	Tarif apel național	8 – 20 în zilele lucrătoare
<b>Россия</b>	8 495 6662929	Действующие телефонные тарифы	с 8 до 20 по рабочим дням Время московское
<b>Schweiz</b>	031 5500 324	Tarif für Anrufe im Bundesgebiet	8 bis 20 Werktage
<b>Suisse</b>		Tarif des appels nationaux	8 à 20. En semaine
<b>Svizzera</b>		a applicata alle chiamate nazionali	dalle 8 alle 20 nei giorni feriali

<b>Slovenija</b>	+38618108621	lokalni strošek je običajna tržna vrednost, odvisna od ponudnika telefonije	8.00 – 16.00 ob delavnikih
<b>Slovensko</b>	(02) 3300 2554	Cena vnútroštátneho hovoru	8 až 20 v pracovných dňoch
<b>Suomi</b>	030 6005203	pvm/mpm	Ma – To 8:00 -18:00 Pe 9:00 -16:00
<b>Sverige</b>	0775 700 500	lokalsamtal (lokal taxa)	mån-fre 8.30 – 20.00 lör-sön 9.30 – 18.00
<b>United Kingdom</b>	020 3347 0044	National call rate	9 till 21. Weekdays
<b>Србија</b>	+381 11 7 555 444 (ако позивате изван Србије) 011 7 555 444 (ако позивате из Србије)	Цена позива у националном саобраћају	Понедељак – субота: 09 – 20 Недеља: 09 – 18



Eesti, Latvija, Україна	<a href="http://www.ikea.com">www.ikea.com</a>
-------------------------	--

***Read More About This Manual & Download PDF:***

**Documents / Resources**

<div>SMAKSAK</div> <div></div>	<div><a href="#">IKEA SMAKSAK Forced Air Oven with Pyrolytic Functions</a> [pdf] Instruction Manual</div> <div>004.210.91, SMAKSAK, Forced Air Oven with Pyrolytic Functions, SMAKSAK Forced Air Oven with Pyrolytic Functions</div>
---	--

**References**

-  [Hej! Welcome to IKEA Global](#)
-  [Hej! Welcome to IKEA Global](#)