

IMOU IPC-AX2E-C Consumer Camera User Guide


[Home](#) » [imou](#) » IMOU IPC-AX2E-C Consumer Camera User Guide 

Contents

- [1 IMOU IPC-AX2E-C Consumer Camera](#)
- [2 Welcome](#)
- [3 Package Content](#)
- [4 Camera Introduction](#)
- [5 LED Indicators](#)
- [6 HOW TO CONNECT](#)
- [7 Troubleshooting](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



IMOU IPC-AX2E-C Consumer Camera



Welcome

Thank you for choosing Imou.

We are devoted to providing you easy smart home products. If you have problems using the product, please contact our service team before returning your product.

Our service mail: service.global@imoulife.com.


Detailed installation instructions & videos, frequently asked questions can be found at:

imoulife.com/support/help


or scan this QR code to help page.




Package Content



Camera ×1




Power Cable ×1




Power Adapter ×1




Positioning Map ×1



Quick Start Guide ×1




Screw Package ×1



Mounting Plate ×1

- Camera x1
- Power Cable x1
- Power Adapter x1
- Positioning Map x1
- Quick Start Guide x1
- Screw Package x1
- Mounting Plate x1

Camera Introduction



LED Indicator



Lens




Built-in Mic



Micro SD Card Slot



Reset Button




Built-in Speaker



Ethernet Port



Power Port



Note: Press and hold the reset button for 10 s to reset the camera.

LED Indicators

The description of the LED Indicator Is Included In the following table.

LED Status

Off
Rebooting after reset
Red light on
Device malfunction
Green light flashing
Green light on
Red light flashing
Green and red light flashing alternately


Device Status

Powered off/LED turned off


Booting

Waiting for network
Operating properly
Network connection failed
Firmware updating



HOW TO CONNECT



Tips



To ensure the best possible wireless performance please make sure that there are no obstacles and electromagnetic between the camera and router



Troubleshooting

Problem	Solution
Cannot configure the	<ul style="list-style-type: none"> • Make sure that your smart phone and the camera are within range of your Wi-Fi router. • Make sure that the LED indicator on the camera is flashing green
How to find the camera Wi-Fi password	It is the safety code on the device label.
No picture or device is offline	<ul style="list-style-type: none"> • Make sure that the LED indicator on the camera is flashing green. See “LED Status” section for details if otherwise. • Make sure that the camera is properly connected to power using the included USB power adapter. • Reposition the camera, router, or both to improve signal strength.
Picture is not clear	<ul style="list-style-type: none"> • Check the camera lens for dirt, dust, and spider webs. Clean the lens with a soft, clean cloth • Remove the vinyl cover on the camera lens.
No audio	<ul style="list-style-type: none"> • Make sure that audio function on camera is turned on. • Make sure that audio is turned up on viewing device.
Human detection does not work	Make sure that you have enabled Human Detection in the Device Settings interface of Imou Life App.
Camera stuck downwards	Check Privacy Mode setting on Imou Life App.
Fail to scan QR code	<ul style="list-style-type: none"> • Clean the camera lens of your smart phone. • Make sure that there is enough light on the QR code. • Do not hold the QR code too close to the camera.

Documents / Resources



[IMOU IPC-AX2E-C Consumer Camera](#) [pdf] User Guide

IPC-AX2E-C, IPCAX2EC, 2AVYF-IPC-AX2E-C, 2AVYFIPCAX2EC, IPC-AX2E-B, IPCAX2EB, 2AVYF-IPC-AX2E-B, 2AVYFIPCAX2EB, IPC-A4X-B, IPCA4XB, 2AVYF-IPC-A4X-B, 2AVYFIPCA4XB, IPC-AX2E-C Consumer Camera, Consumer Camera, Camera