



Instant Pot Duo Plus V2 3, 6 and 8 Quart Multi-Use Pressure Cookers User Manual

[Home](#) » [Support](#) » Instant Pot Duo Plus V2 3, 6 and 8 Quart Multi-Use Pressure Cookers User Manual 

Contents

- [1 Instant Pot Duo Plus V2 3, 6 and 8 Quart Multi-Use Pressure Cookers User Manual](#)
- [2 Welcome to the world of Instant cooking.](#)
- [3 IMPORTANT SAFEGUARDS](#)
- [4 References](#)
- [5 Related Posts](#)

Instant Pot Duo Plus V2 3, 6 and 8 Quart Multi-Use Pressure Cookers User Manual



DUO PLUS
3, 6 and 8 Quart
Multi-Use Pressure Cookers

Welcome to the world of Instant cooking.

Thank you for welcoming us into your kitchen.

Having families ourselves, we developed the Instant Pot® Duo™ Plus pressure cookers to allow busy families and professionals alike to cook healthy, delicious meals more easily and in less time.

We have partnered with chefs, authors and bloggers to compile a collection of recipes that we hope you enjoy!

Happy cooking,

A handwritten signature in black ink that reads 'Robert J. Wang'.

Robert J. Wang
Founder and Chief Innovation Officer



Download the Instant Pot App

- Original Recipes
- New User Tips
- Getting Started Videos



IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed:

1. READ THE GETTING STARTED GUIDE AND ALL INSTRUCTIONS, SAFEGUARDS, AND WARNINGS BEFORE OPERATING THE APPLIANCE. FAILURE TO FOLLOW THESE SAFEGUARDS AND INSTRUCTIONS MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.
2. Use only the Instant Pot Duo Plus lid with the Instant Pot Duo Plus pressure cooker base. Using any other pressure cooker lids may cause injury and/or damage.
3. To reduce the risk of pressure leakage, cook only in an authorized stainless steel Instant Pot inner pot. DO NOT use the appliance without the removable inner pot installed.
4. Always operate the appliance on a stable, non-combustible, level surface.
5. Do not use the appliance for anything other than its intended use. Failure to follow these instructions may result in injury or property damage.
6. For household use only. Do not use outdoors. Not for commercial use.
7. **CAUTION** Do not place the appliance on or in close proximity to a hot gas or electric burner, or a heated oven. Heat from an external source will damage the appliance. Failure to follow these instructions may result in injury or property damage.
8. **CAUTION** Do not use the appliance near water or flame. Keep out of direct sunlight. Failure to follow these instructions may result in injury or property damage.
9. **CAUTION** Do not touch hot surfaces. Only use side handles for carrying or moving. Extreme caution must be used when moving the appliance containing hot liquids. Do not move the appliance when it is under pressure.
10. The cooker base contains electrical components. To avoid electrical shock, do not put liquid of any kind into cooker base, and do not immerse power cord, plug, or the appliance in water or other liquid. Do not rinse the appliance under tap.
11. **CAUTION** Do not fill over PC MAX — 2/3 as indicated on the inner pot. When cooking foods that expand during cooking such as rice or dried vegetables, do not fill the inner pot over —1/2 line. Overfilling may cause a risk of clogging the steam release pipe and developing excess pressure.
12. **WARNING** This appliance cooks under pressure. Inappropriate use may result in burns, injury and/or property damage. Make certain the appliance is properly closed before operating. Refer to Pressure Control Features—Pressure Cooking Lid.
13. When cooking meat with skin (e.g. sausage with casing), the skin can swell when heated. Do not pierce the skin while it is swollen; this could result in scalding injury.
14. **CAUTION** When pressure cooking food with a doughy or thick texture, or a high fat/oil content, contents may splatter when opening the lid. Please follow recipe instructions for pressure release method. Refer to Depressurizing the Cooker (Venting Methods).
15. **CAUTION** Before each use, check the steam release valve/handle, steam release pipe, anti-block shield and float valve for clogging. Failure to do so may result in injury or property damage.
16. **DANGER** Do not open the appliance until it has depressurized and all internal pressure has been released. If the float valve is still up and/or the lid is difficult to open, this indicates that the appliance is still pressurized—do

not force it open. Any pressure in the appliance can be hazardous. Refer to Depressurizing the Cooker (Venting Methods) for information on releasing pressure. Opening appliance while it is still pressurized may lead to sudden release of hot contents and may cause burns or other injuries.

17. Do not use this appliance for deep frying or pressure frying with oil.

18. Do not lean over or place your hands or face over the steam release valve/ handle or float valve when the appliance is in operation or has residual pressure. Do not touch the metal portion of the lid when the appliance is in operation; this could result in injury.

19. Do not cover or obstruct the steam release valve/handle and/or float valve with cloth or other objects.

Obstructing the steam release valve/handle and/or float valve can create a safety issue and may cause injury.

20. Turn the appliance off if steam escapes from the steam release valve/handle and/or float valve in a steady stream for longer than 3 minutes. There may be residual pressure in the appliance. Allow the appliance to depressurize naturally or release all excess pressure before opening. For more information on how to release pressure, refer to Depressurizing the Cooker (Venting Methods).

21. Turn the appliance off if steam escapes from the sides of the lid and ensure sealing ring is properly installed. Overview of Pressure Control Features—Sealing Ring for more information.

22. To disconnect, select Cancel, then remove plug from power source.

23. Unplug from the outlet when not in use, as well as before adding or removing parts or accessories, and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.

24. Regularly inspect the appliance and power cord. Do not operate the appliance if the power cord or plug is damaged, or after the appliance malfunctions or is dropped or damaged in any manner. For assistance, contact Customer Care at support@instantpot.com or 1-800-828-7280.

25. **CAUTION** Do not let the power cord hang over edges of tables or counters, or touch hot surfaces or open flame, including the stovetop.

26. **CAUTION** Spilled food can cause serious burns. A short power-supply cord is provided to reduce the hazards resulting from grabbing, entanglement and tripping.

- Keep the appliance and cord away from children.
- Never drape the power cord over edges of tables or counters.
- Never use below-counter power outlets, and never use with an extension cord.

27. Intended for countertop use only. Keep the appliance on a stable, heatresistant platform. Do not place on anything that may block the vents on the bottom of the appliance. Do not place on a hot stove.

28. **CAUTION** Do not use any accessories or attachments not authorized by Instant Brands Inc. The use of attachments not recommended by the manufacturer, may cause a risk of injury, fire or electric shock.

29. **CAUTION** Before inserting the inner pot into the appliance, clean the outer surface of the inner pot and the heating element located on the inner surface of the outer pot with a clean, dry cloth. Ensure they are dry and free of food debris.

30. Do not attempt to repair, replace, or modify components of the appliance, as this may cause electric shock, fire or injury, and will void the warranty.

31. Do not tamper with any of the safety mechanisms, as this may result in injury or property damage.

32. Do not use the appliance in electrical systems other than 120 V/60 Hz for North America. Do not use with power converters or adapters.

33. This appliance is NOT to be used by children or by persons with reduced physical, sensory, or mental capabilities. Close supervision is necessary when any appliance is used near children and these individuals. Children should not play with this appliance.

34. To prevent personal injury and damage to the appliance, only replace the sealing ring with an authorized Instant Pot sealing ring.

35. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

36. Proper maintenance is recommended after each use. Refer to Care and Cleaning. Let the appliance cool to room temperature before cleaning or storage.

37. Never connect this appliance to an external timer switch or separate remotecontrol system.

38. **CAUTION DO NOT** touch accessories during or immediately after cooking. To avoid personal injury,

- Always use oven mitts when removing accessories, and to handle the inner pot.
- Always place hot accessories on a heat resistant surface or cooking plate.
- Use extreme caution when disposing of hot grease.

Failure to follow these instructions may result in serious injury or property damage.

39. Do not leave the appliance unattended while in use.

40. CAUTION Extreme caution must be used when the inner pot contains hot oil, hot food, or hot liquids. Improper use, including moving the cooker base, may result in personal injury. Do not move the appliance while it is in use.

41. Oversized foods and/or metal utensils must not be inserted into the inner pot as they may cause risk of fire and/or personal injury.

42. Do not store any materials in the cooker base or inner pot when not in use.

43. Do not place any combustible materials in the cooker base or inner pot, such as paper, cardboard, plastic, Styrofoam or wood.

44. Do not use the included accessories in a microwave, toaster oven, convection or conventional oven, or on a ceramic cooktop, electric coil, gas range, or outdoor grill.

45. The removable inner pot can be extremely heavy when full of ingredients.

Care should be taken when lifting the inner pot from the cooker base to avoid burn injury.

46. Use caution when removing the lid. Heat and steam escape as soon as the lid is removed. Never place your face, hands or exposed skin over the appliance opening where heat and steam escape when removing the lid.

SAVE THESE INSTRUCTIONS

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)