



INTERPHONE UCOM6R U-COM 6R Bluetooth Intercom System User Manual

[Home](#) » [Interphone](#) » INTERPHONE UCOM6R U-COM 6R Bluetooth Intercom System User Manual 

Contents

- 1 INTERPHONE UCOM6R U-COM 6R Bluetooth Intercom System
- 2 Product Information
- 3 Product Usage Instructions
- 4 Product details
- 5 Package contents
- 6 HOW TO INSTALL
- 7 GETTING STARTED
- 8 PAIRING WITH OTHER BLUETOOTH® DEVICES
- 9 MOBILE PHONE USAGE
- 10 MUSIC
- 11 BLUETOOTH INTERCOM
- 12 FUNCTION PRIORITY AND FIRMWARE UPGRADES
- 13 CONFIGURATION SETTING
- 14 TROUBLESHOOTING
- 15 Documents / Resources
 - 15.1 References



INTERPHONE UCOM6R U-COM 6R Bluetooth Intercom System



Product Information

The product is a 6R user manual that provides detailed information on the usage and installation of a specific product. The manual covers various topics such as product details, package contents, installation instructions, getting started, mobile phone usage, music features, intercom pairing, function priority, firmware upgrades, configuration settings, and troubleshooting.

About

The product details include a boom microphone for flip-up & jet helmets, a status LED, a music/power button, a wired microphone for full-face helmets, an intercom feature, a DC power charging & firmware upgrade port.

Package Contents:

- Main unit
- Data/charge cable USB type C
- Adhesive bracket
- Clip-on bracket
- Boom microphone
- Wired microphone
- Boom microphone Velcro
- Wired microphone Velcro
- Boom microphone foam cover
- Speakers
- Spacers for speakers
- Speakers Velcro
- Boom microphone holder

Product Usage Instructions

How to Install:

1. For installation, use the double-sided adhesive in the bracket or the clamp for the main unit.
2. To install the speakers and the microphone, follow the provided instructions and diagrams.

Getting Started:

- To power on the device, press the power button once.
- To power off the device, press and hold the power button for 5 seconds.
- To increase the volume, press the volume button once.

Mobile Phone Usage:

- To pair with a mobile phone or TFT systems, follow the pairing instructions provided.
- To pair a second mobile phone, follow the additional pairing instructions.
- To pair with GPS, follow the GPS pairing instructions.
- To make and answer calls, use the designated buttons or features as described in the manual.
- To use Siri or Google Assistant, follow the instructions provided.
- To use speed dialing, either use preset speed dial numbers or follow the specific instructions provided.

Music:

- To pair with an intercom, follow the intercom pairing instructions.
- To engage in a two-way intercom conversation, follow the instructions provided.
- To use older Interphone series devices, refer to the specific section in the manual.
- To use Anycom feature, follow the instructions provided.

Function Priority and Firmware Upgrades:

The manual provides information on function priority and firmware upgrades. Follow the instructions provided for detailed guidance.


Configuration Setting:

To configure headset settings, follow the instructions provided. This includes deleting all pairings if necessary.


Troubleshooting:

If facing any issues, refer to the troubleshooting section for fault reset and factory reset instructions.

Product details



Package contents





- **A)** Main unit
- **B)** Data/charge cable usb type C
- **C)** Adhesive bracket
- **D)** Clip-on bracket
- **E)** Boom microphone
- **F)** Wired microphone
- **G)** Boom microphone Velcro
- **H)** Wired microphone Velcro
- **I)** Boom microphone foam cover
- **L)** Speakers
- **M)** Spacers for speakers
- **N)** Speakers Velcro
- **O)** Boom microphone holder



HOW TO INSTALL

Install main unit




Use/application with double-sided adhesive in the bracket




Use/application with the clamp for main unit



Installing the speakers and the microphone



GETTING STARTED



Note:

- Any USB charger with FCC, CE, IC or any local approval can be used.
- U-COM 6R is compatible only with USB device with 5V DC input.

PAIRING WITH OTHER BLUETOOTH® DEVICES


- When using the headset with other Bluetooth® devices for the first time, they will need to be “paired.” This enables them to recognize and communicate with one another whenever they are within range.
- U-COM 6R can be paired to Bluetooth® devices such as mobile phones, GPS Satnav and TFT motorcycle multimedia systems.

Pairing with Mobile phone/TFT systems


1. Switch on Bluetooth® service on your phone (check device manual for more details).
2. With U-COM 6R on, press and hold INTERCOM button for 5 seconds, to enter settings menu. Don't release the button until the led light is blue.
3. Press once VOLUME + button to start phone pairing mode.
4. On your phone search for new Bluetooth® devices.

5. In few moments the phone will list “U-COM 6R vx.x” among available devices to pair. Select this item.
6. If prompted for a PIN or code, enter 0000 (four times zero).
7. U-COM Voice guide will confirm the successful pairing.
8. If your smartphone asks for additional authorization please confirm.

Main phone pairing (to be done with unit on)



Multimedia TFT system of motorcycle must be paired with “PHONE PAIRING”:



The primary phone will have priority over the second phone, in case of simultaneous call reception on both phones.

Second mobile phone pairing


1. Switch on Bluetooth® service on your phone (check device manual for more details).
2. With U-COM 6R on, press and hold INTERCOM button for 5 seconds, to enter settings menu. Don't release the button until the led light is blue.
3. Press the VOLUME + button twice to activate Second mobile phone pairing mode.
4. Start the search for new Bluetooth® devices on the mobile phone.
5. In few moments the phone will list “U-COM 6R vx.x” among available devices to pair. Select this item.
6. If prompted for a PIN or code, enter 0000 (four times zero).
7. UCOM Voice guide will confirm the successful pairing.
8. If your smartphone asks for additional authorization please confirm.

GPS Pairing

1. Switch on Bluetooth® service on your phone (check device manual for more details).
2. With U-COM 6R on, press and hold INTERCOM button for 5 seconds, to enter settings menu. Don't release the button until the led light is blue.
3. Press the VOLUME + button twice to activate Second mobile phone pairing mode.


4. Start the search for new Bluetooth® devices on the mobile phone.
5. In few moments the phone will list “U-COM 6R vx.x” among available devices to pair. Select this item.
6. If prompted for a PIN or code, enter 0000 (four times zero).
7. UCOM Voice guide will confirm the successful pairing.
8. If your smartphone asks for additional authorization please confirm.

Gps SATNAV & TFT pairing (to be done with unit on)



MOBILE PHONE USAGE

Making and Answering Calls



Note:

If you have a GPS device connected, you will not hear its voice navigations during a phone call.

Siri and Google Assistant

U-COM 6R supports the Siri and Google Assistant access directly or press the PHONE button once. You can activate the Siri or Google Assistant using the voice through the headset's microphone, a wake word will be used. This is a word or groups of words such as “Hey Siri” or “Hey Google”.

Speed Dialing

It is possible to store up to 3 telephone numbers (if “advanced mode” is active) to be used as speed dials. You can set the speed dial numbers via UNITE APP or INTERPHONE Device Manager.

Using preset speed dial numbers

How to activate speed dial (with ADVANCED FEATURES off)

Speed dial



How to activate speed dial (with ADVANCED FEATURES on)


1. Enter into the Speed Dial menu.

Speed dial



2. Navigate between the Speed Dial Preset with VOLUME + or VOLUME – buttons, as indicated in picture here below. Select the wanted feature with INTERCOM button.


Select one function/Confirm selected function



MUSIC

Playing Music with Bluetooth® Devices

Interphone U-COM 6R can play music from Bluetooth® devices (smartphones, MP3 players, Motorcycle TFTs etc ...) equipped with the A2DP profile. To play music you need to pair these devices to INTERPHONE U-COM 6R.




Music sharing

- You can start sharing the music received from your phone with another U-COM control unit, during a two-way intercom conversation.
- Both control units can control the playback of music, eg example go to the next track or the previous track.

Note:

music sharing cannot be activated at the same time as an intercom conversation.


To start / stop sharing music, activate first the intercom conversation, then press the MUSIC button for 2 seconds (until the second “beep”).



BLUETOOTH INTERCOM


Intercom pairing

U-COM 6R can be paired with up to 3 other UCOM units (or Sena units), as shown in the following picture.




The pairing is only necessary the first time, then the control units will automatically recognize each other.

- Press and hold the INTERCOM button on both units A and B for 3 seconds, until you hear the voice prompt “intercom pairing”. The light flashing red indicates the device is now visible.




After few seconds the units will be paired and they will start the intercom communication. The light on both units will flash blue twice.

2. Repeat the previous step again, pressing the INTERCOM button on the two units A and C for 3 seconds until you hear the voice prompt “Intercom pairing”.




3. Repeat the procedure again, pressing the INTERCOM button of the two units A and D for 3 seconds until you hear the voice prompt “Intercom pairing”.




Two-way Intercom Conversation

After pairing the control units, communication can be started, by pressing the INTERCOM button, according to the diagram below.

1. Press once to connect the control unit D.




Start/stop intercom connection with unit “D”




2. Press twice to connect the control unit C.

Start/stop intercom connection with unit “C”




3. Press three times to connect the control unit B.

Start/stop intercom connection with unit “B”




Old Interphone Series

It is possible to pair previous Interphone series devices by pressing, with the unit on, the INTERCOM and TELEPHONE buttons for 3 seconds. Then start pairing mode on the second unit, usually pressing the power button (with the control unit off) until the led flashes red/blue.



Anycom

Anycom feature allows intercom conversations with other intercom brands. It is possible to pair the intercom with only one non-Interphone device at a time. The intercom distance depends on the performance of the connected Bluetooth® intercom. When a not-Interphone device is paired with the Interphone device, if another Bluetooth® device is paired via the second mobile phone pairing, it will be disconnected.



1. With U-COM 6R on, enter the configuration menu by pressing the INTERCOM button for 5 seconds. Do not to release the button before the led turns blue.
2. Press the VOLUME – button 3 times to activate the ANYCOM pairing mode.
3. Set the not-Interphone intercom to mode Phone pairing.

FUNCTION PRIORITY AND FIRMWARE UPGRADES

Function Priority

The headset prioritizes connected devices in the following order:

1. (Highest) Mobile phone
2. Bluetooth® Intercom
3. (Lower) Bluetooth® stereo music

- Priority between intercom and music can be changed via the APP
- Interphone unite or the Device Manager for Win/MAC.

A lower-priority function gets interrupted by a higher-priority function. For example, stereo music will be interrupted by an Bluetooth® Intercom Conversation; an Bluetooth® Intercom Conversation will be interrupted by an incoming mobile phone call.


Firmware Upgrades

- The headset supports firmware upgrades. Using the Device Manager utility (available for PC and MAC on www.interphone.com) you can upgrade firmware.
- The USB Power & Data Cable (USB-C) must be connected to your computer, then start Device Manager on computer and follow instructions step by step.
- Interphone Unite APP can check the firmware version present on the headset and inform you in case of a newer available firmware, but APP can't flash the new firmware to headset.

CONFIGURATION SETTING

Headset Configuration Setting

With U-COM 6R on, press and hold INTERCOM button for 5 seconds, to enter settings menu. Don't release the button until the led light is blue.



To navigate through the settings, press once the VOLUME + button or the VOLUME – button.

1. Phone pairing
2. Second Mobile Phone Pairing
3. GPS pairing

To confirm the following configuration menu options, press INTERCOM button once.

4. Delete all pairings
5. Anycom pairing
6. Factory reset
7. Exit

Delete all pairings

Delete all Bluetooth® pairings stored in the device.

Device settings

You can change the device settings from the Device Manager utility (available for PC and MAC on www.interphone.com) or from the Interphone UNITE app.

Attention:

The setting “Advanced Features” will enable the following headset features:

1. Phone multiple speed dial

Speed dial

Assign phone numbers for speed dialing to make a phone call quickly.

VOX Phone (Default: Enable)

If this feature is enabled, you can answer incoming calls by voice. When you hear a ringtone for an incoming call, you can answer the phone by saying a word such as “Hello” loudly or by blowing air into the microphone. VOX phone is temporarily disabled if you are connected to intercom. If this feature is disabled, you have to tap the PHONE button to answer an incoming call.

VOX Intercom (Default: Disable)

If VOX Intercom is enabled, you can initiate an intercom conversation with the last connected intercom by voice. When you want to start intercom, say a word such as “Hello” loudly or blow air into the microphone. If you start an intercom conversation by voice, the intercom terminates automatically when you and your intercom friend remain silent for 20 seconds. However, if you manually start an intercom conversation by tapping the INTERCOM button, you have to terminate the intercom conversation manually. However, if you start the intercom by voice and end it manually by tapping the INTERCOM button, you will not be able to start intercom by voice temporarily. In this case, you have to tap the INTERCOM button to restart the intercom. This is to prevent repeated unintentional intercom connections by strong wind noise. After rebooting the headset, you can start the intercom by voice again.

Audio Multitasking (Default: Disabled)

Audio Multitasking (Bluetooth® Intercom Audio Multitasking) allows you to have an intercom conversation while simultaneously listening to music or GPS instructions. The overlaid audio is played in the background with reduced volume whenever there is an intercom conversation and will return to normal volume once the conversation is finished.

Note:

- For Bluetooth® Intercom Audio Multitasking to work properly, you need to power the headset off and on. Please restart the headset.
- Bluetooth® Intercom Audio Multitasking will be activated during two-way intercom conversations with a headset that also supports this feature.
- Some GPS devices may not support this feature.
- The Audio Multitasking feature can be configured through the Intercom-Audio Overlay Sensitivity and the Audio Overlay Volume Management settings.
- Attention, activating Audio Multitasking will lead to a deterioration of the quality of the Intercom audio.

HD Voice (Default: Enable)

- HD Voice allows you to communicate in high-definition during phone calls. This feature increases the quality so that the audio will be crisp and clear during phone call conversations.
- Three-Way Conference Phone Call with Intercom Participant will not be available if HD Voice is enabled.

Note:

- Refer to the manufacturer of your Bluetooth® device that will be connected to the headset to see if it supports HD Voice.
- HD Voice is active only when Bluetooth® Intercom Audio Multitasking is disabled.

HD Intercom (Default: Enable)

HD Intercom enhances the two-way intercom audio from normal quality to HD quality. HD Intercom will become temporarily disabled when you enter into a multi-way intercom. If this feature is disabled, the two-way intercom audio will change to normal quality.

Note:

- The intercom distance of HD Intercom is relatively shorter than normal intercom.
- HD Intercom will become disabled temporarily when Bluetooth® Intercom Audio Multitasking is enabled.

Unit Language

You can select the device language. The selected language is maintained even when the headset is rebooted

Voice Prompt (Default: Enable)

You can disable voice prompts by software configuration settings, but the following voice prompts are always on.

- Headset configuration settings menu, battery level indicator, speed dial.

TROUBLESHOOTING

Please visit www.interphone.com for video tutorials and answers to frequently asked questions.

Fault reset


When the intercom does not work properly, it is possible to reset the unit easily, by inserting a paper clip inside the reset hole, on the back of the main unit and pressing gently.

Note:

Reset after error will not restore the intercom to factory settings.

Factory reset

To erase all of your settings and start fresh, the headset can be restored to factory default settings using the Factory Reset feature.



With U-COM 6R on, enter the configuration menu by pressing INTERCOM button for 5 seconds. Be careful not to release the button before the LED turns blue, you will hear the message confirming activation of the configuration menu.

Press the VOLUME

Button twice until you hear the message “Factory reset”, press once the INTERCOM button to confirm. A voice announcement will be issued to confirm: “Reset headphones, goodbye”.

Documents / Resources



[INTERPHONE UCOM6R U-COM 6R Bluetooth Intercom System](#) [pdf] User Manual
UCOM6R U-COM 6R Bluetooth Intercom System, UCOM6R, U-COM 6R Bluetooth Intercom System, Bluetooth Intercom System, Intercom System

References

- [@ Interphone Site IT | Motorcycle intercoms and motorcycle accessories](#)