



Intesis INBACRTR0320000 BACnet MS/TP to BACnet IP router Installation Guide

[Home](#) » [Intesis](#) » Intesis INBACRTR0320000 BACnet MS/TP to BACnet IP router Installation Guide 



INBACRTR0320000
Intesis BACnet MS/TP to BACnet IP router
Order Code: INBACRTR0320000

** stands for the Intesis gateway capacity and varies depending on the specific gateway acquired.

Installation Sheet rev.1.5

HMS Industrial Networks S.L.U ©

Owner's Record

The serial number is located at the rear of the gateway.

Record this information in the space provided below.

Refer to it whenever you contact upon your gateway dealer or support team regarding this product.

Serial No.....

Contents

- [1 SAFETY INSTRUCTIONS](#)
- [2 CONFIGURATION](#)
- [3 INSTALLATION](#)
- [4 CONNECTIONS](#)
- [5 ELECTRICAL & MECHANICAL FEATURES](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

SAFETY INSTRUCTIONS



WARNING

Follow carefully this safety and installation instructions.

Improper work may lead to serious harm to your health and may also damage seriously the gateway and/or any other equipment connected to it.

The gateway must be installed by an accredited electrician or similar technical personnel, following all the safety instructions given here and in accordance always with the country legislation for installation of electric equipment. The gateway cannot be installed outdoors or exposed to direct solar radiation, water, high relative humidity, or dust.

The gateway must only be installed in a restricted access location.

In case of wall mount, fix firmly the gateway on a not vibrating surface following the instructions next.

In the case of the DIN rail, mount fix the gateway properly to the DIN rail following the instructions below.

Mounting on DIN rail inside a metallic cabinet properly connected to the earth is recommended.

Disconnect always a power of any wires before manipulating and connecting them to the gateway.

A power supply with an NEC Class 2 or Limited Power Source (LPS) and SELV rated is to be used.

Respect always the expected polarity of power and communication cables when connecting them to the gateway.

Supply always a correct voltage to power gateway, see details of voltage range admitted by the device in the technical characteristics below.

CAUTION: The device is to be connected only to networks without routing to the outside plant, all communication ports are considered indoor only.

This device was designed for installation in an enclosure. To avoid electrostatic discharge to the unit in environments with static levels above 4 kV, precautions should be taken when the device is mounted outside an enclosure. When working in an enclosure (ex. making adjustments, setting switches, etc.) typical anti-static precautions should be observed before touching the unit.

Safety instructions in other languages can be found at: <https://intesis.com/docs/manuals/v6-safety>

CONFIGURATION

Use the Configuration Tool to configure the gateway.

See instructions to download and install the latest version at: <https://intesis.com/docs/software/intesis-maps-installer>

Use the Ethernet connection for communication between the gateway and the configuration tool. See CONNECTIONS below and follow instructions of the user's manual for more details.

INSTALLATION

Follow instructions next to properly install the gateway.

Disconnect from mains the power supply before connecting it to the gateway.

Disconnect the power of any bus or communication cable before connecting it to the gateway.

Mount the gateway in a vertical position on the wall or DIN rail following the instruction given below, respecting the safety instructions given above.

IMPORTANT: Connect an NEC Class 2 or Limited Power Source (LPS) and SELV rated power supply to the gateway, respect the polarity if DC power or Line and Neutral if AC power. This power supply must not be shared with other devices. Apply always a voltage within the range admitted by the gateway and of enough power (see technical characteristics).


Circuit-breakers must be used before the power supply. Rating 250V6A.

Connect the communication cables to the gateway, see details on the user's manual.

Power the gateway and the rest of the devices connected to it.


Wall Mount

1. Separate the fixing clips in the bottom of the box, pushing them to the outside until hearing the "click" which indicates that now the clips are in position for wall mount, see in the figure below.
2. Use the holes of the clips to fix the box in the wall using screws. Use the template below for the wall wholes.



DIN Rail Mount

With the clips of the box in their original position, insert first the box in the upper edge of the DIN rail and later insert the box in the down part of the rail, using a small screwdriver and following the steps in the figure below.



CONNECTIONS

Power Supply

Must use NEC Class 2 or Limited Power Source (LPS) and SELV-rated power supply. Respect polarity applied of terminals (+) and (-). Be sure the voltage applied is within the range admitted (check table below). The power supply can be connected to earth but only through the negative terminal, never through the positive terminal.


Ethernet / BACnet IP

Connect the cable coming from the IP network to the connector ETH of the gateway. Use an Ethernet CAT5 cable. If communicating through the LAN of the building, contact the network administrator and make sure traffic on the port used is allowed through all the LAN path (check the gateway user manual for more information). With factory settings, after powering up the gateway, DHCP will be enabled for 30 seconds. After that time, if no IP is provided by a DHCP server, the default IP 192.168.100.246 will be set.


Port BACnet MS/TP

Connect the EIA485 bus to connectors A3 (B+), A2 (A-), and A1 (SNGD) of the gateway's Port. Respect the polarity.

Note for MS/TP port; Remember the characteristics of the standard EIA485 bus: maximum distance of 1200 meters, maximum 32 devices connected to the bus, and in each end of the bus it must be a termination resistor of 120 Ω .



ELECTRICAL & MECHANICAL FEATURES



Enclosure	Plastic, type PC (UL 94 V-0) Net dimensions (dxwxh): 93x53x58 mm Recommended space for installation (dxwxh) Color: Light Grey. RAL 7035
Mounting	Wall. DIN rail EN60715 TH35.
Terminal Wiring(for power supply and low-voltage signals)	Per terminal: solid wires or stranded wires (tv 1 core: 0.5mm 2... 2.5mm2 2 cores: 0.5mm2 ... 1.5mm2 3 cores: not permitted
Power	1 x Plug-in screw terminal block (3 poles) Positive, Negative, Earth 9-36 VDC / 24 VAC / 50-60 Hz / 0.140 A / 1.7
Ethernet	1 x Ethernet 10/100 Mbps RJ45 2 x Ethernet LED: port link and activity
Port	1 x Serial EIA485 (Plug-in screw terminal blo A, B, SGND (Reference ground or shield) 1500VDC isolation from other ports
Operation Temperature	0°C to +60°C
Operational Humidity	5 to 95%, no condensation
Protection	IP20 (IEC60529)



This marking on the product, accessories, packaging or literature (manual) indicates that the product contains electronic parts and they must be properly disposed of by following the instructions at


<https://intesis.com/weee-regulation>
<https://www.intesis.com>

Rev.1.5





© HMS Industrial Networks S.L.U – All rights reserved.

This information is subject to change without notice.

Documents / Resources

	Intesis INBACRTR0320000 BACnet MS/TP to BACnet IP router [pdf] Installation Guide INBACRTR0320000, BACnet MS TP to BACnet IP router
---	--

References

-  [Waste Electrical and Electronic Equipment | Intesis](#)
-  [intesis.com/docs/manuals/v6-safety](https://www.intesis.com/docs/manuals/v6-safety)
-  [Waste Electrical and Electronic Equipment | Intesis](#)
-  [Intesis | Gateway solutions for Building Automation](#)

Manuals+.