



Intesis Modbus Server for Hisense Air Conditioning Gateway integration of VRF Systems User Manual

[Home](#) » [Intesis](#) » Intesis Modbus Server for Hisense Air Conditioning Gateway integration of VRF Systems User Manual 



Hisense Air Conditioning Gateway for the integration of Hisense VRF systems into Modbus (RTU and TCP) systems

USER MANUAL

Issue date: 11/2018 r1.0 ENGLISH

Important User Information Disclaimer

The information in this document is for informational purposes only. Please inform HMS Industrial Networks of any inaccuracies or omissions found in this document. HMS Industrial Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Industrial Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Industrial Networks and is subject to change without notice. HMS Industrial Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Industrial Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

Gateway for the integration of Hisense VRF systems into Modbus (RTU and TCP) systems.

ORDER CODE	LEGACY ORDER CODE
INMBSHIS0160000	HS-AC-MBS-16
INMBSHIS0640000	HS-AC-MBS-64

Contents

1	1.1Introduction
2	Integration of Hisense's compatible systems into Modbus systems
3	1.1 Functionality
4	1.2 Capacity of Intesis
5	2. Modbus interface
6	1.3 Functions supported
7	1.4 Modbus RTU
8	1.5 Modbus TCP
9	1.6 Modbus Address Map
10	Intesis™ Modbus Server – HISENSE VRF
11	Intesis™ Modbus Server – HISENSE VRF
12	Intesis™ Modbus Server – HISENSE VRF
13	3. Connections
14	Intesis™ Modbus Server – HISENSE VRF
15	1.7 Power device
16	1.8 Connect to Hisense VRF installation
17	4. Set-up process and troubleshooting
18	1.11 Pre-requisites
19	Intesis™ Modbus Server – HISENSE VRF
20	Intesis™ Modbus Server – HISENSE VRF
21	Figure 4.4 Intesis MAPS Hisense configuration tab
22	Intesis™ Modbus Server – HISENSE VRF
23	Figure 4.8 Intesis MAPS Signals tab
24	Intesis™ Modbus Server – HISENSE VRF
25	Intesis™ Modbus Server – HISENSE VRF
25.1	Port A
26	Intesis™ Modbus Server – HISENSE VRF
27	Intesis™ Modbus Server – HISENSE VRF
28	Read More About This Manual & Download PDF:
29	Related Posts


1.1Introduction

This document describes the integration of Hisense VRF air conditioning systems into Modbus compatible devices and systems using using gateway the Intesis Modbus Server to Hisense VRF communication gateway. The aim of this integration is to monitor and control Hisense air conditioning systems, remotely, from a Control Center using any commercial SCADA or monitoring software that includes a Modbus Master driver (RTU and/or TCP). To do it so, Intesis performs as a Modbus Server, allowing poll and write requests from any Modbus master device.

Intesis makes available the Hisense air conditioning system indoor units' datapoints through independent Modbus registers.

Up to 64 indoor units supported, depending on product version.

This document assumes that the user is familiar with Modbus and Hisense technologies and their technical terms. Integration of



Integration of Hisense's compatible systems into Modbus systems

1.1 Functionality

Intesis™ continuously monitors Hisense VRF network for all configured signals and keeps the updated status of all of them in its memory, ready to be served when requested from the Modbus master.

Commands toward the indoor units are permitted.

Each indoor unit is offered as a set of MBS objects.

Element	Object supported
Outdoor Unit	<ul style="list-style-type: none"> Status
Indoor Unit	<ul style="list-style-type: none"> Status Command Communication status
General signals (all units)	<ul style="list-style-type: none"> Command

1.2 Capacity of Intesis

Element	Max.	Notes
Number of indoor units	64 *	Number of indoor units that can be controlled through Intesis

* There are different models of Intesis MBS – Hisense VRF each one with different capacity. The table above shows the capacity for the top model (with maximum capacity).

Their order codes are:

- INMBSHIS016O000: Model supporting up to 16 indoor units
- INMBSHIS064O000: Model supporting up to 64 indoor units

2. Modbus interface

In this section, a common description for all Intesis Modbus series gateways is given, from the point of view of Modbus system which is called from now on internal system. Connection with the Hisense VRF system is also called from now on external system.

1.3 Functions supported

This part is common for Modbus RTU and TCP.

Modbus functions 03 and 04 (Read Holding Registers and Read Input Registers) can be used to read Modbus registers.

Modbus functions 06 and 16 (Single Multiple Holding Registers and Write Multiple Holding Registers) can be used to write Modbus registers.

Configuration of poll records is possible between Modbus addresses 0 and 20000. Addresses that are not defined in section 2.2 (Modbus map of the device) are read-only and will always report 0.

Modbus error codes are supported, they will be sent whenever a non-valid Modbus address is queried.

All registers are 16-bit signed integer, in standard Modbus Big Endian (MSB/LSB) format.

Intesis supports Modbus RTU and Modbus TCP and both interfaces can be used simultaneously.

1.4 Modbus RTU

Both EIA485 and EIA232 physical layers are supported. Only the lines RX, TX and GND of the EIA232 connector are used (TX and RX for EIA485).

Baud rate can be selected between 1200, 2400, 4800, 9600, 19200, 38400, 56700 and 115200. Parity (none, even or odd) and stop bits (1 or 2) can be selected as well. Modbus slave number must be configured and the physical connection (RS232 or RS485) can also be selected

1.5 Modbus TCP

TCP port to use (default is 502) and keep alive period must be configured.

IP settings of Intesis (DHCP status, own IP, net mask and default gateway) must be configured as well.

1.6 Modbus Address Map

Modbus address from the formula is expressed in link layer format. This is, first register address is 0.

Modbus Address (Field Address+2)	Read/Write	Register/Signal name	Possible values
0	W	On (all the units)	1-Set all the units-On
1	W	Off (all the units)	1-Set all the units-Off
2	W	Operation Mode Auto (all the units)	1-Set Auto-Mode
3	W	Operation Mode Heat (all the units)	1-Set Heat Mode
4	W	Operation Mode Dry (all the units)	1-Set Dry Mode
5	W	Operation Mode Fan (all the units)	1-Set Fan Mode
6	W	Operation Mode Cool (all the units)	1-Set Cool Mode
7	W	Fan Speed Auto (all the units)	1-Set Fan-Speed Auto
8	W	Fan Speed Low (all the units)	1-Set Fan-Speed Low
9	W	Fan Speed Mid (all the units)	1-Set Fan-Speed Mid
10	W	Fan Speed High (all the units)	1-Set Fan-Speed High
11	W	Fan Speed High+ (all the units)	1-Set Fan-Speed High+
12	W	Vane Position Auto (all the units)	1-Set Vane-Position Auto
13	W	Vane Position 1 (all the units)	1-Set Vane-Position 1
14	W	Vane Position 2 (all the units)	1-Set Vane-Position 2
15	W	Vane Position 3 (all the units)	1-Set Vane-Position 3
16	W	Vane Position 4 (all the units)	1-Set Vane-Position 4
17	W	Vane Position 5 (all the units)	1-Set Vane-Position 5
18	W	Vane Position 6 (all the units)	1-Set Vane-Position 6
19	W	Vane Position 7 (all the units)	1-Set Vane-Position 7

DB	W	Temperature (Setpoint) (°C) (all units)	Unit: 15.0°C; Max: 15.0°C
(CPU20)=10000+0 Reserved for future use Address: 0.00	R	Communication Error (0)	0=No error, 1=Error
(CPU20)=10000+1	R	Indoor Air Temp.	0.0 to 9.0
(CPU20)=10000+2	R	Room Temp. Temp.	0.000 °C
(CPU20)=10000+3	R	Total Room Temp. Pres.	0.000 Pa
(CPU20)=10000+4	R	Total Temp. Current	0.000 A
(CPU20)=10000+5	R	Out Box Valve 1 Open	0.000 %
(CPU20)=10000+6	R	Discharge Pressure (°C)	-0.0 to 0.0 MPa
(CPU20)=10000+7	R	Suction Pressure (°C)	-0.0 to 0.0 MPa
(LJ100)=0 0=No fault/Alarm code or temperature zone temperature setpoint 0.000 °C	R/W	Device	0=Off, 1=On
(LJ100)=1	R/W	Operation Mode	0=Auto, 1=Heat, 2=Dry, 3=Fan, 4=Cool
(LJ100)=2	R/W	Fan Speed	0=Auto, 1=Low, 2=Med, 3=High, 4=High+
(LJ100)=3	R/W	Valve Position	0=Auto, 1=Open, 2=Close
(LJ100)=4	R/W	Temperature Setpoint (°C)	0.00 to 15.00°C; Max: 15.00°C
(LJ100)=5	R	Room Sensor Temp. (°C)	-0.0 KPC
(LJ100)=6	R	Ind Temp. (°C)	-0.0 KPC
(LJ100)=7	R	Outdoor Temp. (°C)	-0.0 KPC
(LJ100)=8	R	Discharge Temp. (°C)	-0.0 KPC
(LJ100)=9	R	Liquid Pipe Temp. (°C)	-0.0 KPC
(LJ100)=10	R	Unit Error Code	Error code
(LJ100)=11	R	Fiber Alarm	0=Normal, 1=Alarm
(LJ100)=12	W	Fiber Alarm Reset	1=Reset
(LJ100)=13	R	Communication Status	0=Not Err, 1=Err

Intesis™ Modbus Server – HISENSE VRF

(UI*100)+14	R/W	Allow On/Off from RC	0-Allow, 1-Not allow
(UI*100)+15	R/W	Allow Mode from RC	0-Allow, 1-Not allow
(UI*100)+16	R/W	Allow Setpoint from RC	0-Allow, 1-Not allow
(UI*100)+17	R/W	Allow Fan from RC	0-Allow, 1-Not allow
(UI*100)+18	R	Unit Type	0-Not Defined, 1-CS, 2-FC, 3-VRF, 4-RJ, 5-ES
(UI*100)+19	R	Unit Address	1..64
(UI*100)+20	R	System Address	1..64
(UI*100)+21	R	Dehumidification	0-Disabled, 1-Enabled
(UI*100)+22	R/W	Dehumidification Correction	0-0, 1+1), 2+3)
(UI*100)+23	R	Compressor Stop Cause	255-Operation OK, Other-See manual
(UI*100)+24	R	Expansion Valve Open	0..100%
(UI*100)+25	R	Operation Condition	0-OK, 1-Thermo OK, 2-Thermo On, 3-Alarm
(UI*100)+26	R	RC SW Temperature (x10°C)	-63..63°C
(UI*100)+27	R	RC SW Config	0-Without RCS, 1-With RCS

Intesis™ Modbus Server – HISENSE VRF

3. Connections

Find below information regarding the Intesis connections available.

Power Supply

Must use NEC Class 2 or Limited Power Source (LPS) and SELV rated power supply.

If using DC power supply:

Respect polarity applied of terminals (+) and (-). Be sure the voltage applied is within the range admitted (check table below). The power supply can be connected to earth but only through the negative terminal, never through the positive terminal.


If using AC power supply:

Make sure the voltage applied is of the value admitted (24 Vac). Do not connect any of the terminals of the AC power supply to earth, and make sure the same power supply is not supplying any other device.

Ethernet / Modbus TCP (TCP) / Console (UDP & TCP)

Connect the cable coming from the IP network to the connector ETH of the gateway. Use an Ethernet CAT5 cable.

If communicating through the LAN of the building, contact the network administrator and make sure traffic on the port used is allowed through all the LAN path (check the gateway user manual for more information). Default IP is 192.168.100.246. DHCP is enabled by default.



PortA / H-Link Hisense

Connect the H-Link terminals (TB2) of Hisense Outdoor Unit to the connectors A3 and A4 of gateway's PortA. There is no polarity to be respected.

PortB / Modbus-RTU RS485

Connect the EIA485 bus to connectors B1 (B+), B2 (A-) and B3 (SNGD) of gateway's PortB. Respect the polarity. Remember the characteristics of the standard EIA485 bus: maximum distance of 1200 meters, maximum 32 devices connected to the bus, and in each end of the bus it must be a termination resistor of 120 Ω . Bus biasing and termination resistor for EIA485 can be enabled for PortB by means of a dedicated DIP:

SW1:

ON: 120 Ω termination active

OFF: 120 Ω termination inactive (Default setting).

SW2+3:

ON: Polarization active

OFF: Polarization inactive (Default setting).

If the gateway is installed in one bus end, make sure that termination is active.

Intesis™ Modbus Server – HISENSE VRF

1.7 Power device

The first step to perform is to power up the device. To do so, a power supply working with any of the voltage range allowed is needed (check section 5). Once connected the ON led will turn on.

WARNING! In order to avoid earth loops that can damage the gateway, and/or any other equipment connected to it, we strongly recommend:

- The use of DC power supplies, floating or with the negative terminal connected to earth. Never use a DC

power supply with the positive terminal connected to earth.

- The use of AC power supplies only if they are floating and not powering any other device.

1.8 Connect to Hisense VRF installation

Use the PortA connector in the top corner of the Intesis device in order to connect H-Link bus to the Intesis.

Remember to follow all safety precautions indicated by Hisense.

Connect the Hisense H-Link/TB2 bus to connectors A3 and A4 of gateway's PortA. Bus is not sensitive to polarity.

1.9 Connection to Modbus

1.9.1 Modbus TCP

The gateway's Ethernet port connection is used for Modbus TCP communication. Connect the communication cable coming from the network hub or switch to the Ethernet port of Intesis. The cable to be used shall be a straight Ethernet UTP/FTP CAT5 cable.

TCP port to use (default 502) and keep alive period must be configured.

IP settings of the gateway (DHCP status, own IP, netmask and default gateway) must be configured as well.

1.9.2 Modbus RTU

Connect the communication cable coming from the modbus network to the port marked as Port B of the Intesis.

Connect the EIA485 bus to connectors B1 (-), B2 (+) and B3 (SNGD) of gateway's PortB. Respect the polarity.

Remember the characteristics of the standard EIA485 bus: maximum distance of 1200 meters, maximum 32 devices (without repeaters) connected to the bus, and in each end of the bus it must be a termination resistor of 120 Ω . The gateway has an internal bus biasing circuit that incorporates the termination resistor. Bus biasing and termination resistor for EIA485 can be enabled for PortB by means of a dedicated DIP switch.

1.10 Connection to PC (Configuration tool)

This action allows the user to have access to configuration and monitoring of the device (more information can be found in the configuration tool User Manual). Two methods to connect to the PC can be used:

- Ethernet: Using the Ethernet port of Intesis.
- USB: Using the console port of Intesis, connect a USB cable from the console port to the PC.

4. Set-up process and troubleshooting

1.11 Pre-requisites

It is necessary to have the Modbus RTU or TCP master/client device (BMS side device) operative and properly connected to the corresponding port of the gateway and the Hisense VRF installation connected to their corresponding ports as well.

Connectors, connection cables, PC for the Configuration Tool usage and other auxiliary material, if needed, are not supplied by Intesis for this standard integration.

Items supplied by HMS Networks for this integration are:

- Intesis gateway.
- Link to download the configuration tool.
- USB Console cable to communicate with Intesis.
- Product documentation.

1.12 Intesis MAPS. Configuration & monitoring tool for Intesis Modbus series

1.12.1 Introduction

Intesis MAPS is a Windows® compatible software developed specifically to monitor and configure Intesis new generation gateways.

The installation procedure and main functions are explained in the Intesis MAPS User Manual. This document can be downloaded from the link indicated in the installation sheet supplied with the Intesis device or in the product website at www.intesis.com

In this section, only the specific case of Hisense VRF to Modbus systems will be covered. Please check the Intesis MAPS User Manual for specific information about the different parameters and how to configure them.

1.12.2 Connection

To configure the Intesis connection parameters press on the Connection button in the menu bar.




Figure 4.1 MAPS connection

Intesis™ Modbus Server – HISENSE VRF

1.12.3 Configuration tab

Select the Configuration tab to configure the connection parameters. Three subsets of information are shown in this window: General (Gateway general parameters), Modbus Slave (Modbus interface configuration) and Hisense (Hisense interface parameters).

1. Modbus Configuration

1.1. Modbus type selection. Select RTU, TCP or simultaneous RTU and TCP communication.

2. TCP Configuration.

2.1. Modbus TCP Port: Modbus TCP communication port setting. Default port 502.

2.2. Keep Alive. Set the time of inactivity to send a keep Alive message. Default 10 minutes.

3. RTU Configuration.

3.1. RTU bus connection type. Select the RTU connection type serial bus RS485 or 232.

3.2 Baudrate. Set the RTU bus communication speed. Default: 9600 bps.

- Available values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 bps.

3.3 Data Type. Set the Data-bit/parity/stop-bit. Default: 8bit/None/1.

- Available selection: 8bit/None/1, 8bit/Even/1, 8bit/Odd/1, 8bit/None/2.

3.4 Slave Number. Set the Modbus Slave address. Default slave address: 1.

- Valid address: 1..255.

Intesis™ Modbus Server – HISENSE VRF

1.12.5 Hisense configuration

Set parameters for connection with Hisense's installation.




Figure 4.4 Intesis MAPS Hisense configuration tab

In Units Configuration section you need to enter, for each unit:

- Active. If it's active (checkbox at Unit xx), ranging from 1 to 64 indoor units that will be integrated (maximum number of units will depend on Intesis model)
- IU address. Address 1..64 of Unit in Hisense H-Link bus.

- OU address. Address 1..64 of Outdoor Unit in Hisense H-Link bus.
 - Description. Descriptive name to easy identification of the unit (for example, 'living room floor 1 unit', etc).
- Additional to manual entry of each unit, autodiscover of present units in an H-Link installation is possible. To do so, click button Scan. Following window will appear:

Intesis™ Modbus Server – HISENSE VRF

Scan Hisense Units

Bus Scan

Start Scan

Scan

Stop

Scan Results

Available Units

Add	OU	IU	Model
-----	----	----	-------

☒ Replace Units
 ☐ Add Units

Apply

Cancel

Figure 4.5 Intesis MAPS Scan Hisense Units window

By pressing Scan button, connected Hisense H-Link bus will be scanned for available units. Error window will appear if there is a problem in the connection with H-Link bus (units not powered, bus not connected, ...). A progress bar will appear during the scan, which will take up to a few minutes. After scan is completed, detected units will be shown in available units as follows:




Figure 4.6 Intesis MAPS Scan Hisense Units window with scan results

Intesis™ Modbus Server – HISENSE VRF

Select with its checkbox units to add (or replace) in installation, according to selection Replace Units / Add Units. After units to be integrated are selected, click button Apply, and changes will appear in previous Units Configuration window.




Figure 4.7 Intesis MAPS Hisense configuration tab after importing scan results

1.12.6 Signals

All available Modbus registers, its corresponding description and other main parameters are listed in the signals tab.

Name	Status	Address	ID	Object name	Count	Unit
1	OK	0x00000000	0	0x00000000	0	0
2	OK	0x00000001	1	0x00000001	0	0
3	OK	0x00000002	2	0x00000002	0	0
4	OK	0x00000003	3	0x00000003	0	0
5	OK	0x00000004	4	0x00000004	0	0
6	OK	0x00000005	5	0x00000005	0	0
7	OK	0x00000006	6	0x00000006	0	0
8	OK	0x00000007	7	0x00000007	0	0
9	OK	0x00000008	8	0x00000008	0	0
10	OK	0x00000009	9	0x00000009	0	0
11	OK	0x0000000A	10	0x0000000A	0	0
12	OK	0x0000000B	11	0x0000000B	0	0
13	OK	0x0000000C	12	0x0000000C	0	0
14	OK	0x0000000D	13	0x0000000D	0	0
15	OK	0x0000000E	14	0x0000000E	0	0
16	OK	0x0000000F	15	0x0000000F	0	0
17	OK	0x00000010	16	0x00000010	0	0
18	OK	0x00000011	17	0x00000011	0	0
19	OK	0x00000012	18	0x00000012	0	0
20	OK	0x00000013	19	0x00000013	0	0
21	OK	0x00000014	20	0x00000014	0	0
22	OK	0x00000015	21	0x00000015	0	0
23	OK	0x00000016	22	0x00000016	0	0
24	OK	0x00000017	23	0x00000017	0	0
25	OK	0x00000018	24	0x00000018	0	0
26	OK	0x00000019	25	0x00000019	0	0
27	OK	0x0000001A	26	0x0000001A	0	0
28	OK	0x0000001B	27	0x0000001B	0	0
29	OK	0x0000001C	28	0x0000001C	0	0
30	OK	0x0000001D	29	0x0000001D	0	0
31	OK	0x0000001E	30	0x0000001E	0	0
32	OK	0x0000001F	31	0x0000001F	0	0
33	OK	0x00000020	32	0x00000020	0	0
34	OK	0x00000021	33	0x00000021	0	0
35	OK	0x00000022	34	0x00000022	0	0
36	OK	0x00000023	35	0x00000023	0	0
37	OK	0x00000024	36	0x00000024	0	0
38	OK	0x00000025	37	0x00000025	0	0
39	OK	0x00000026	38	0x00000026	0	0
40	OK	0x00000027	39	0x00000027	0	0
41	OK	0x00000028	40	0x00000028	0	0
42	OK	0x00000029	41	0x00000029	0	0
43	OK	0x0000002A	42	0x0000002A	0	0
44	OK	0x0000002B	43	0x0000002B	0	0
45	OK	0x0000002C	44	0x0000002C	0	0
46	OK	0x0000002D	45	0x0000002D	0	0
47	OK	0x0000002E	46	0x0000002E	0	0
48	OK	0x0000002F	47	0x0000002F	0	0
49	OK	0x00000030	48	0x00000030	0	0
50	OK	0x00000031	49	0x00000031	0	0
51	OK	0x00000032	50	0x00000032	0	0
52	OK	0x00000033	51	0x00000033	0	0
53	OK	0x00000034	52	0x00000034	0	0
54	OK	0x00000035	53	0x00000035	0	0
55	OK	0x00000036	54	0x00000036	0	0
56	OK	0x00000037	55	0x00000037	0	0
57	OK	0x00000038	56	0x00000038	0	0
58	OK	0x00000039	57	0x00000039	0	0
59	OK	0x0000003A	58	0x0000003A	0	0
60	OK	0x0000003B	59	0x0000003B	0	0
61	OK	0x0000003C	60	0x0000003C	0	0
62	OK	0x0000003D	61	0x0000003D	0	0
63	OK	0x0000003E	62	0x0000003E	0	0
64	OK	0x0000003F	63	0x0000003F	0	0
65	OK	0x00000040	64	0x00000040	0	0
66	OK	0x00000041	65	0x00000041	0	0
67	OK	0x00000042	66	0x00000042	0	0
68	OK	0x00000043	67	0x00000043	0	0
69	OK	0x00000044	68	0x00000044	0	0
70	OK	0x00000045	69	0x00000045	0	0
71	OK	0x00000046	70	0x00000046	0	0
72	OK	0x00000047	71	0x00000047	0	0
73	OK	0x00000048	72	0x00000048	0	0
74	OK	0x00000049	73	0x00000049	0	0
75	OK	0x0000004A	74	0x0000004A	0	0
76	OK	0x0000004B	75	0x0000004B	0	0
77	OK	0x0000004C	76	0x0000004C	0	0
78	OK	0x0000004D	77	0x0000004D	0	0
79	OK	0x0000004E	78	0x0000004E	0	0
80	OK	0x0000004F	79	0x0000004F	0	0
81	OK	0x00000050	80	0x00000050	0	0
82	OK	0x00000051	81	0x00000051	0	0
83	OK	0x00000052	82	0x00000052	0	0
84	OK	0x00000053	83	0x00000053	0	0
85	OK	0x00000054	84	0x00000054	0	0
86	OK	0x00000055	85	0x00000055	0	0
87	OK	0x00000056	86	0x00000056	0	0
88	OK	0x00000057	87	0x00000057	0	0
89	OK	0x00000058	88	0x00000058	0	0
90	OK	0x00000059	89	0x00000059	0	0
91	OK	0x0000005A	90	0x0000005A	0	0
92	OK	0x0000005B	91	0x0000005B	0	0
93	OK	0x0000005C	92	0x0000005C	0	0
94	OK	0x0000005D	93	0x0000005D	0	0
95	OK	0x0000005E	94	0x0000005E	0	0
96	OK	0x0000005F	95	0x0000005F	0	0
97	OK	0x00000060	96	0x00000060	0	0
98	OK	0x00000061	97	0x00000061	0	0
99	OK	0x00000062	98	0x00000062	0	0
100	OK	0x00000063	99	0x00000063	0	0

Figure 4.8 Intesis MAPS Signals tab

1.12.7 Sending the configuration to Intesis

When the configuration is finished, follow the next steps.

1. Save the project (Menu option Project->Save) on your hard disk (more information in Intesis MAPS User Manual).
2. Go to tab 'Receive / Send' of MAPS, and in Send section, press Send button. Intesis will reboot automatically once the new configuration is loaded.



Figure 4.9 Intesis MAPS Receive/Send tab

After any configuration change, do not forget to send the configuration file to the Intesis using the Send button in the Receive / Send section.

1.12.8 Diagnostic

To help integrators in the commissioning tasks and troubleshooting, the Configuration Tool offers some specific tools and viewers.

In order to start using the diagnostic tools, connection with the Gateway is required.

The Diagnostic section is composed by two main parts: Tools and Viewers.


- Tools

Use the tools section to check the current hardware status of the box, log communications into compressed files to be sent to the support, change the Diagnostic panels' view or send commands to the gateway.

- Viewers

In order to check the current status, viewer for the Internal and External protocols are available. It is also available a generic Console viewer for general information about communications and the gateway status and finally a Signals Viewer to simulate the BMS behavior or to check the current values in the system.

Intesis™ Modbus Server – HISENSE VRF



More information about the Diagnostic section can be found in the Configuration Tool manual.

1.12.9 Set-up procedure

1. Install Intesis MAPS on your laptop, use the setup program supplied for this and follow the instructions given by the Installation wizard.
2. Install Intesis in the desired installation site. Installation can be on DIN rail or on a stable not vibrating surface (DIN rail mounted inside a metallic industrial cabinet connected to ground is recommended).
3. If using Modbus RTU, connect the communication cable coming from the EIA485 port of the Modbus RTU installation to the port marked as Port B of Intesis (More details in section 3).
If using, Modbus TCP, connect the communication cable coming from the Ethernet port of the Modbus TCP installation to the port marked as Ethernet Port of Intesis (More details in section 3).

4. Connect the communication cable coming from the Hisense VRF installation to the port marked as Port A of Intesis (More details in section 3).
5. Power up Intesis. The supply voltage can be 9 to 36 Vdc or just 24 Vac. Take care of the polarity of the supply voltage applied.

WARNING! In order to avoid earth loops that can damage Intesis and/or any other equipment connected to it, we strongly recommend:

- The use of DC power supplies, floating or with the negative terminal connected to earth. Never use a DC power supply with the positive terminal connected to earth.
- The use of AC power supplies only if they are floating and not powering any other device.

Intesis™ Modbus Server – HISENSE VRF

6. If you want to connect using IP, connect the Ethernet cable from the laptop PC to the port marked as Ethernet of Intesis (More details in section 3).

If you want to connect using USB, connect the USB cable from the laptop PC to the port marked as Console of Intesis (More details in section 3).

7. Open Intesis MAPS, create a new project selecting a copy of the one named INMBSHIS—O000.

8. Modify the configuration as desired, save it and download the configuration file to Intesis as explained in the Intesis MAPS user manual.

9. Visit the Diagnostic section, enable COMMS () and check that there is communication activity, some TX frames and some other RX frames. This means that the communication with the Centralized Controller and Modbus Master devices is OK. In case there is no communication activity between Intesis and the Centralized Controller and/or Modbus devices, check that those are operative: check the baud rate, the communication cable used to connect all devices and any other communication parameter.




Figure 4.11 Enable COMMS

5. Electrical & Mechanical Features

Power

1 x Plug-in screw terminal block (3 poles)
9 to 36VDC +/-10%, Max.: 140mA.
24VAC +/-10% 50-60Hz, Max.: 127mA
Recommended: 24VDC

Ethernet

1 x Ethernet 10/100 Mbps RJ45
2 x Ethernet LED: port link and activity

Port A

1 x H-Link Plug-in screw terminal block orange (2 poles)
1500VDC isolation from other ports
1 x Plug-in screw terminal block green (2 poles)
Reserved for future use

Switch A

x DIP-Switch for PORTA configuration:
Reserved for future use (leave OFF, default)

PORT B

1 x Serial EIA232 (SUB-D9 male connector)
Pinout from a DTE device
1500VDC isolation from other ports
(except PORT B: EIA485)
1 x Serial EIA485 Plug-in screw terminal block (3 poles)
A, B, SGND (Reference ground or shield)
1500VDC isolation from other ports
(except PORT B: EIA232)

Switch B

1 x DIP-Switch for serial EIA485 configuration:
Position 1:
ON: 120 Ω termination active
Off: 120 Ω termination inactive (default)
Position 2-3:
ON: Polarization active
Off: Polarization inactive (default)

Battery

Size: Coin 20mm x 3.2mm
Capacity: 3V / 225mAh
Type: Manganese Dioxide Lithium

Console Port

Mini Type-B USB 2.0 compliant
1500VDC isolation

USB port

Type-A USB 2.0 compliant
Only for USB flash storage device
(USB pen drive)
Power consumption limited to 150mA
(HDD connection not allowed)

Push Button

Type-A USB 2.0 compliant
Only for USB flash storage device
(USB pen drive)
Power consumption limited to 150mA
(HDD connection not allowed)

Push Button

Button A: Not used
Button B: Not used

Operation Temperature

0°C to +60°C

Operational Humidity

to 95%, no condensation


Protection


IP20 (IEC60529)

LED Indicators


10 x Onboard LED indicators
2 x Run (Power)/Error
2 x Ethernet Link/Speed
2 x Port A TX/RX
2 x Port B TX/RX
1 x Button A indicator
1 x Button B indicator

6. Dimensions





Recommended available space for its installation into a cabinet (wall or DIN rail mounting), with space enough for external connections



7. AC Unit Types compatibility

A list of Hisense unit model references compatible with INMBSHIS—O000 and their available features can be found in:

https://www.intesis.com/docs/compatibilities/inxxxhis001r000_compatibility

Intesis™ Modbus Server – HISENSE VRF

8. Error codes for Indoor and Outdoor Units

This list contains all possible values shown in Modbus register for “Error Code” for each indoor unit and outdoor unit.

It must be taken into account that Outdoor Units are only able to reflect a single error for each indoor / outdoor unit in the system. Thus, a unit having two or more active errors from that list will only report a single error code – the one of the first error that has been detected.

Id			
43	Protection Device	Activation of Low Compression Ratio Protection Device	Defective Compression (Failure of Compressor or Inverter, Loose Power Supply Connection)
44		Activation of Low Pressure Increase Protection Device	Overload at Cooling, High Temperature at Heating, Expansion Valve Locking (Lease Connector)
45		Activation of High Pressure Increase Protection Device	Overload Operation (Clogging, Short/Pipe), Pipe Clogging, Excessive Refrigerant, Inert Gas Mixing
47		Activation of Low Pressure Decrease Protection Device (Vacuum Operation Protection)	Insufficient Refrigerant, Refrigerant Piping Clogging, Expansion Valve Locking at Open Position (Loose Connector)
48		Activation of Inverter-Overcurrent Protection Device	Overload Operation, Compressor Failure
51	Current	Abnormal Inverter Current Sensor	Current Sensor Failure
53	Inverter	Inverter Error Signal Detection	Driver IC Error Signal Detection (Protection for Overcurrent, Low Voltage, Short Circuit)
54		Abnormality of Inverter Fin Temperature	Abnormal Inverter Fin Thermistor, Heat Exchanger Clogging, Fan Motor Failure
55		Inverter Failure	Inverter PCB Failure
57	Fan Controller	Activation of Fan/Controller Protection	Driver IC Error Signal Detection (Protection for Overcurrent, Low Voltage, Short Circuit), Instantaneous Overcurrent
58		Abnormality of Fan Controller Fin Temperature	Fin Thermistor Failure, Heat Exchanger Clogging, Fan Motor Failure
59		Activation of Overcurrent Protection	Fan Motor Failure
60		Abnormality of Fan Controller Sensor	Failure of Current Sensor (Instantaneous Overcurrent, Increase of Fin Temperature, Low Voltage, Earth Fault, Stop-Out)
68	Compressor	Compressor Protection Alarm (It cannot be reset from remote Controller)	This alarm code appears when the following alarm* occurs three times within 6 hours. *03, 07, 08, 09, 43 to 46, 47
81	Outdoor Unit No. Setting	Incorrect setting of Unit and Refrigerant Cycle No.	Over 64 Number is Set for Address or Refrigerant Cycle
	Indoor Unit No. Setting		More than 32 Non-Corresponding to Hi-SET Units are Connected to One System.

42			
43	Protection Device	Activation of Low Compression Ratio Protection Device	Defective Compression (Failure of Compressor or Inverter, Loose Power Supply Connection)
44		Activation of Low Pressure Increase Protection Device	Overload at Cooling, High Temperature at Heating, Expansion Valve Locking (Loose Connector)
45		Activation of High Pressure Increase Protection Device	Overload Operation (Digging, Short-Pass), Pipe Clogging, Excessive Refrigerant, Ice/Iron Ore Mixing
46		Activation of Low Pressure Decrease Protection Device (Vacuum Operation Protection)	Insufficient Refrigerant, Refrigerant Piping Clogging, Expansion Valve Locking at Open Position (Loose Connector)
48		Activation of Inverter Overcurrent Protection Device	Overload Operation, Compressor Failure
51	Sensor	Abnormal Inverter Current Sensor	Current Sensor Failure
53	Inverter	Inverter Error Signal Detection	Driver IC Error Signal Detection (Protection for Overcurrent, Low Voltage, Short-Circuit)
54		Abnormality of Inverter Fan Temperature	Abnormal Inverter Fan Thermistor, Heat Exchanger Clogging, Fan Motor Failure
55			
		Inverter Failure	Inverter PCB Failure
57	Fan Controller	Activation of Fan Controller Protection	Driver IC Error Signal Detection (Protection for Overcurrent, Low Voltage, Short-Circuit), Instantaneous Overcurrent
58		Abnormality of Fan Controller Fan Temperature	Fan Thermistor Failure, Heat Exchanger Clogging, Fan Motor Failure
59		Activation of Overcurrent Protection	Fan Motor Failure
60		Abnormality of Fan Controller Sensor	Failure of Current Sensor (Instantaneous Overcurrent), Increase of Fan Temperature, Low Voltage, Earth Fault, Stop-Out
66	Compressor	Compressor Protection Alarm (It is cannot be reset from remote Controller)	This alarm code appears when the following alarm* occurs three times within 6 hours. *61, 62, 68, 75, 43 to 45, 47
68	Outdoor Unit No. Setting	Incorrect Setting of Unit and Refrigerant Cycle No.	Over 64 Number is Set for Address of Refrigerant Cycle.
	Indoor Unit No. Setting		More than 32 Non-Corresponding to H-NET Units are Connected to One System.

b5		Incorrect Indoor Unit Connection Number Setting	
C1	Switch Box Unit	Incorrect Indoor Unit Connection	2 or more Switch Box Units are connected between outdoor unit and indoor unit.
C2		Incorrect Indoor Unit Connection No. Setting	9 or More Indoor Units Connected to Switch Box Unit
C3		Incorrect Indoor Unit Connection	The indoor units of different refrigerant cycle is connected to Switch Box unit.

Read More About This Manual & Download PDF:

Intesis Modbus Server for Hisense Air Conditioning Gateway integration of VRF Systems User Manual – [Download \[optimized\]](#)

Intesis Modbus Server for Hisense Air Conditioning Gateway integration of VRF Systems User Manual – [Download](#)