




Invertex Drives 82-PFNET-IN Profinet IO Interface User Guide

[Home](#) » [Invertex Drives](#) » Invertex Drives 82-PFNET-IN Profinet IO Interface User Guide 

Contents

- [1 Invertex Drives 82-PFNET-IN Profinet IO Interface](#)
- [2 Overview](#)
- [3 Optidrive Setup](#)
- [4 Installation](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Invertex

Invertex Drives 82-PFNET-IN Profinet IO Interface



Overview

This option module is specifically designed to be used with the Optidrive P2 and Optidrive Eco range of variable speed drive products and is intended for professional incorporation into complete equipment or systems. If installed incorrectly it may present a safety hazard. Before commencing installation and commissioning, the user should ensure they are fully familiar with the Optidrive P2, and in particular, have read the important safety information and warnings contained in the Optidrive P2 / Optidrive Eco User Guide.

Note:

This User Guide is intended to be used with Optidrive P2 & Eco firmware version 2.00 or later. The firmware

version of the drive can be displayed in parameter P0-28. Previous versions of firmware can be upgraded using Optidrive Studio PC software. Contact your local Invertek Sales Partner for further Information.

Available Functions

The PROFINET interface is intended to be installed in the Optidrive option slot and allows the Optidrive to be connected to a PROFINET network. The interface offers the following functionality:

- Cyclic Process Data Exchange
- 4 Input Words from the network master to the Optidrive
- 4 Output Words from the Optidrive to the network master

GSD File

A GSDXML file for the interface can be obtained from invertekdrives.com

IP Address Configuration

If it is desired to change the IP Address, an IP address configuration tool is available for download from invertekdrives.com


Compatibility

This Option is suitable for use on the following product ranges:

Optidrive Setup

- Set the drive to Fieldbus control mode by setting parameter P1-12 = 4
- Ensure Advanced Parameter Access is enabled on the drive-by setting P1-14 = 101
- By default, DHCP is enabled, and the module IP address will be automatically assigned. If a fixed IP address is desired, download the IP address configuration software from invertekdrives.com

Layout



1. Network Status LED
2. Module Status LED
3. Ethernet Port 1
4. Ethernet Port 2
5. Port 1 Activity LED
6. Port 2 Activity LED
7. Clamping screws, Torx 8, 0.25Nm

Network Status LED

| State | Indication |
|----------------|--|
| Off | Offline / No Power / Not inserted |
| Green | Online, Connection with IO Controller established, IO Controller in RUN state |
| Flashing Green | Online, Connection with IO Controller established, IO Controller in STOP state |

Module Status LED


| State | Indication |
|-----------------|--|
| Off | No Power / Initialising |
| Green | Normal Operation |
| Green 1 Flash | Diagnostic Event Present |
| Green 2 Flashes | Network Node Identification |
| Red | Exception Error, Module in Exception State |
| Red 1 Flash | Configuration Error |
| Red 2 Flashes | IP Address Not Set |
| Red 3 Flashes | Station Name Not Set |
| Red 4 Flashes | Internal Module Error |

Link / Port Activity LED

| State | Indication |
|------------------|------------------------------------|
| Off | No Link |
| Green | Link Established, No Communication |
| Green Flickering | Link Established & Communicating |

Installation

- Ensure the drive power is removed prior to installing the option module
- Remove the blanking cover from the option module slot
- Carefully slide the option module into the slot, ensuring that the locating tabs are correctly aligned. Do not use excessive force
- Tighten the 2 clamping screws to secure the module in place.



PLC Configuration

Configuration of the PLC varies between different systems. Refer to information on the specific PLC system in use for further guidance. Scan QR code opposite.

Data Mapping

The Optidrive P2 and Optidrive Eco support a 4-word cyclic process data exchange. The format and data contained in these words are shown below.

Input Data (PDI) Telegram

This part of the memory contains the real-time drive commands sent from the network master to the Optidrive, allowing the Optidrive to be controlled. The functions of the first two data words (PDI 1 and PDI 2) are fixed, to allow basic control over the drive operation and output frequency to be achieved. The configuration of the remaining two words can be adjusted by the user.

PDI Word 1: Fixed Function: Drive Control Word

A 16 Bit control word is used to control the behavior of the drive when P1-12 = 4. The bits function as follows:

| Bit | Name | Description | |
|------|------------------|--|---|
| 0 | Drive Run | 0 : Drive Stop 1 : Drive Run | <p>For normal operation, Bit 3 has the highest priority, bit 0 has the lowest priority (bit 3>bit 1>bit 0). For normal run/ stop control, Bit 0 only should be used.</p> <p>Note that the start/stop (bit 0), fast stop (bit 1) and coast stop (bit 3) can only be used to control the drive when P2-37 = 0 to 3. If P2-37 > 3, the start/stop function is controlled directly by the drive control terminals. The Reset function (bit 2) will operate providing that the drive is set for Fieldbus control P1-12 = 4.</p> |
| 1 | Fast Stop Select | 0 : No Function 1 : Drive Stop with Deceleration Ramp 2 | |
| 2 | Fault Reset | 0 : No Function 1 : Rising Edge fault reset request | |
| 3 | Coast Stop | 0 : No Function 1 : Drive Coasts to stop. Overrides bit 0 | |
| 4–15 | Not Used | | |

PDI Word 2: Fixed Function: Frequency Setpoint

This word is used to transfer the frequency setpoint to the Optidrive. The input data is a 16bit signed integer including one decimal place. For example, a value of 500 represents a frequency setpoint to the Optidrive of 50.0Hz, value 123 gives 12.3Hz. For a negative (reverse) speed reference, a negative value can be transferred to the drive, where the MSB of the high byte must be 1.

For example, -1(0xFFFF) gives -0.1Hz. -234(0xFF16) gives -23.4Hz.

The allowed input value range is from -5000 to +5000; however, the drive output speed will be limited by the maximum speed set by P1-01.

PDI Word 3 : User Defined Function

The function of this data word can be selected by the user using drive parameter P5-14. The possible setting options are shown below: 0: Torque limit/reference (Optidrive P2 Only) – This option must be selected if the drive output torque limit/setpoint is to be controlled from the Fieldbus. This also requires setting P4-06 = 3. The input data is a 16bit unsigned integer including one decimal place. For example, a value of 500 represents a torque setpoint to the Optidrive of 50.0%, value 123 gives 12.3%. The allowed input value range is from 0 to +2000; however, the drive output torque will be limited by the maximum limit set by P4-07. 1: User PID reference register – This option allows the setpoint to the PID controller to be received from the Fieldbus. In order for this option to be used, P9-38 must be set to 1, and the PID User setpoint must not be utilized within the drive PLC function.

User register:

The value received by the drive-in PDI 3 is transferred to User Register 3. This option allows the function of the process data word to be defined in Parameter Group 9. In this case, User Register 3 should not be written to within any PLC function code, although the value can be read.

PDI Word 4: User Defined Function

The function of this data word can be selected by the user using drive parameter P5-13. The possible setting options are shown below: 0: Fieldbus Ramp Control – This option must be selected if the drive acceleration and deceleration ramps are to be controlled from the Fieldbus. P5-07 must also be set to 1 to enable this function.

User register The value received by the drive-in PDI 4 is transferred to User Register This option allows the function of the process data word to be defined in Parameter Group 9. In this case, User Register 3 should not be written to within any PLC function code, although the value can be read.

Output Data

This part of the memory contains the real-time drive data returned from the Optidrive to the network master. The

function of the first two data words (PDO 1 and PDO 2) is fixed. The configuration of the remaining two words can be adjusted by the user.

PDO Word 1: Fixed Function : Drive Status & Error Code:

This word contains 2 bytes with information as follows:

| Bit | Logic 0 | Logic 1 | Notes |
|--------|---------------------------|--------------------------|---|
| 0 | Drive Stopped | Drive Running | Indicates when the output to the motor is enabled |
| 1 | Drive Healthy | Drive Fault (Tripped) | Indicates when the drive has tripped. The fault code is indicated in the high byte as shown below |
| 2 | Auto Control Mode | Hand Control Mode | Optidrive Eco Only. Indicates when Hand control is selected |
| 3 | OK | Inhibit | Indicates the status of the STO / Hardware Inhibit circuit |
| 4 | OK | Maintenance Time Reached | Indicates that the programmable System Maintenance Time Interval has expired |
| 5 | Not in Standby | Standby | No Function Assigned |
| 6 | Not Ready | Drive Ready | Mains Power applied, No Inhibit, No Trip, Enable Input present |
| 7 | Normal Load | Low/High Mode Detected | Optidrive Eco Only. Indicates when low or high load condition is detected |
| 8 – 15 | Last / Current Fault Code | | Indicates the last or current fault code. For further fault code information, refer to the Optidrive User Guide |

PDO Word 2 : Fixed Function: Output Frequency

This word gives the real-time drive output frequency information. The data is a 16bit signed integer with one decimal place. e.g. value 123 means 12.3Hz. Value -234 (0xFF16) means -23.4Hz.

PDO Word 3 : Output Current

Data to be transferred in this word can be selected by the User in drive parameter P5-12. The possible settings are as follows: 0: Motor current – Output current to 1 decimal place, e.g. 100 = 10.0 Amps

1. Power (x.xx kW) Output power in kW to two decimal places, e.g. 400 = 4.00kW
2. Digital input status – Bit 0 indicates digital input 1 status, bit 1 indicates digital input 2 status etc
3. Analog Input 2 Signal Level – 0 to 1000 = 0 to 100.0%
4. Drive Heatsink Temperature – 0 to 100 = 0 to 100°C
5. User register 1 – User Defined Register 1 Value
6. User register 2 – User Defined Register 1 Value
7. P0-80 value – User Selected data value

PDO Word 4 : User Defined

Data to be transferred in this word can be selected by the User in drive parameter P5-08. The possible settings are as follows: 0 : Output Torque (Optidrive P2 Only) – 0 to 2000 = 0 to 200.0%

1. Output Power – Output power in kW to two decimal places, e.g. 400 = 4.00kW
2. Digital Input Status – Bit 0 indicates digital input 1 status, bit 1 indicates digital input 2 status etc

3. Analog Input 2 Signal Level – 0 to 1000 = 0 to 100.0%
4. Drive Heatsink Temperature – 0 to 100 = 0 to 100°C

Documents / Resources

| | |
|---|---|
|  | Invertex Drives 82-PFNET-IN Profinet IO Interface [pdf] User Guide 82-PFNET-IN Profinet IO Interface |
|---|---|

References

- [🔍 Variable Frequency Drive Manufacturer | Variable Speed Drives | AC Drives | Invertex Drives](#)
- [🔍 Variable Frequency Drive Manufacturer | Variable Speed Drives | AC Drives | Invertex Drives](#)