



Invertex Drives ODE-2 Optipad TFT Remote Keypad User Guide

[Home](#) » [Invertex Drives](#) » Invertex Drives ODE-2 Optipad TFT Remote Keypad User Guide 

Contents

- 1 Invertek Drives ODE-2 Optipad TFT Remote Keypad User Guide
- 2 General Specification
- 3 Mechanical Installation
- 4 Through Panel Mount
- 5 Electrical Installation
- 6 Allowed System Configurations
- 7 Keypad and Display Layout
- 8 Easy Startup
- 9 Operating Displays
- 10 Additional Display Messages
- 11 Changing Parameters
- 12 Parameter Factory Reset / User Reset
- 13 Further Status Messages and Troubleshooting
- 14 Documents / Resources
 - 14.1 References

Invertek Drives ODE-2 Optipad TFT Remote Keypad User Guide




General Specification

- **Compatible Drives:** ODE-2, ODE-3, ODP-2, ODL-2, ODV-3, CV
- **Signal Interface:** Standard 8-way RJ45 connector
- **Supply Input:** 24V + / – 10%, DC, 30mA
- **RS485 Signal:** Industry standard 2-wire +5V differential
- **Environmental:** Operational: -10 ... 50°C
- **Storage:** -40°C ... 60°C

- **Relative Humidity:** < 95% (non condensing)
- **Protection Rating:** IP55
- **Max Cable Length:** 25m / 82.5ft shielded twisted pair


Mechanical Installation

Dimensions




Through Panel Mount

The panel on to which the Optipad is to be mounted should be cut out in accordance with the diagram below.




Electrical Installation

Cable Requirements



CAUTION! Incorrect cable connection may damage the drive. Extra care should be taken when using third party cable.

Allowed System Configurations




Different drive models can be used on the same Optipad network provided a unique communications address is assigned to each.

NOTE Cannot be used with Master – Slave or Cascade Control

Keypad and Display Layout

The illustration below explains the main features of the Optipad. Please note that some features and display messages are specific to certain variants of the Optidrive family.





Easy Startup

To setup the Optidrive communication address

By default, the Optipad will try to communicate with the drive that has Address 1 in the network after powering up for the first time.




The Optipad will display “Scanning for Drive 01.” after power up, which indicates that the Optipad is searching for the drive with the correct drive address in the network. Once the drive has been found, the message “Load...” will be displayed on the Optipad, which indicates that the Optipad is reading the configuration information from the drive. Usually it will take 1~2 seconds for the Optipad to read this information. After the data has been loaded, the Optipad will display the drive real time status.

NOTE In the case where the keypad is connected to a drive where the network address is not 1, the following steps can be used to set the address of the drive

Select Drive Address 01	Select Drive Address 01
	
Use the Up and Down arrows to select the address.	Press the Stop button once address has changed to match the connected drive.

Working with Multiple Drive Networks

When the Optipad is used on networks with multiple drives, the user can change the drive address to set up communication with another drive in the same drive network at anytime.

Select Drive Address xx	Select Drive Address xx	Select Drive Address xx
		
Briefly press the Stop and Down keys to display the above message.	Use the Up and Down arrows to select the desired address.	After selecting the new address, press the Stop and Down keys to establish communications with the drive.




NOTE For detailed parameter listing and functional setup, please refer to the corresponding Optidrive user guide

Networks with 2 Optipads connected

A maximum of 2 Optipads can be connected within the same drive network to communicate with the same drive

or different drives.




When using two Optipads simultaneously on a network, the user must change the Optipad Device Number on the second Optipad to ensure correct operation. All Optipad units are set to Device Number 1 by default.

Select OptiPad ID xx	Select OptiPad ID xx	Select OptiPad ID xx
		
To change the Device Number, press the Navigate, Stop and Down keys together.	Use the Up and Down arrows to select the desired Optipad Number (1 or 2).	Press the Stop key to return to normal operation.







NOTE Once the User has set the Optipad as Device Number 2, OptiTools software cannot be used on the same drive network.

The Optipad Device Address should only be changed to 2 if 2 Optipad units are connected on a network. An Optipad with Device Number 1 must always be present for the network to function correctly.





Changing the Display Language





STOP	Select Language Español Deutsch English	Select Language Español Deutsch English
		
Hold down the Start and Up keys for >1s	Use the Up and Down arrows to select a language.	Press the Navigate button to select.

Operating Displays







Inhibit / STO Active	Drive Stopped	Drive Running Output Frequency Display	Drive Running Output Current Display	Drive Running Motor Power Display	Drive Running Motor Speed Display
Name 01 INHIBIT	Name 01 STOP	Output Frequency 01 23.7Hz	Motor Current 01 15.3A	Motor Power 01 6.9kW	Motor Speed 01 718rpm
15kW 400V 3Ph	15kW 400V 3Ph	15.3A 6.9kW	6.9kW 23.7Hz	23.7Hz 15.3A	23.7Hz 15.3A
					
Drive Inhibited. The STO connections are not made.	Drive Stopped / Disabled.	Drive is enabled / running, display shows the output frequency (Hz). Press the Navigate key to select alternative displays.	Press the Navigate key for < 1 second. The display will show the motor current (Amps).	Press the Navigate key for < 1 second. The display will show the motor power (kW).	If P1-10 > 0, pressing the Navigate key for < 1 second will display the motor speed (Rpm).

Additional Display Messages







Auto Tuning in Progress	External 24VDC Supply	Overload	Fire Mode
Name 01 Auto-tuning	Name 01 Ext 24V	Name 01 OL 23.7Hz	Fire Mode
External 24V mode	15.3A 6.9kW		
			
Auto tune in progress.	The drive control board is powered only from an external 24 Volt source, with no mains power applied.	Indicates an Overload condition. Output current exceeds the motor rated current.	Display shows 'Fire Mode'.

Switching Frequency Reduction	Mains Loss	Maintenance Time Elapsed	
Name 01 SF↓ 23.7Hz	Name 01 ML 23.7Hz	Name 01 OL 23.7Hz	Name 01 Y 23.7Hz
15.3A	15.3A 6.9kW	15.3A 6.9kW	15.3A 6.9kW
			
Switching frequency is reduced, due to high heatsink temperature.	The incoming mains power supply has been disconnected or is missing.	The motor is in overload drawing a current higher than its rated current.	The user programmable maintenance reminder time has elapsed.

Changing Parameters

Name 01	Name 01	Name 01	Name 01	Name 01	Name 01
Stop	P1-01	P1-08	30.0A	P1-08	Stop
15kW 400V 3Ph	50.0Hz	30.0A	P1-08 130.0 13.0	30.0A	15kW 400V 3Ph
					
Press and hold the Navigate key > 2 seconds.	Use the Up and Down keys to select the required parameter. Display will show the present parameter value on the lower line of the display.	Press the Navigate key for < 1 second.	Adjust the value using the Up and Down keys. Display will show the maximum and minimum possible settings on the lower line of the display.	Press for < 1 second to return to the parameter menu.	Press for > 2 seconds to return to the operating display.

Parameter Factory Reset / User Reset

Factory Parameter Reset :			User Parameter Reset :		
Name 01	Name 01	Name 01	Name 01	Name 01	Name 01
Stop	P-Def	Stop	Stop	U-Def	Stop
15kW 400V 3Ph	50.0Hz	15kW 400V 3Ph	P1-08 130.0 13.0	30.0A	15kW 400V 3Ph
					
Press and hold the Up, Down, Start and Stop keys for >2s.	The display shows P-def. Briefly press the Stop key.	The display returns to Stop. All parameters are reset to Factory defaults.	Press and hold the Up, Down and Stop keys for >2s.	The display shows U-def. Briefly press the Stop key.	The display returns to Stop. All parameters are reset to User Defaults.

Drive Fault Messages and Trip Codes

See Optidrive User Guide for further information.

Further Status Messages and Troubleshooting

Optipad uses various display messages to indicate different working status. See the following table for more information.

Status Messages

Message	Explanation
Scanning for Drive xx	The Optipad is searching for the drive with address 'xx' in the network.
Load...	The Optipad has found the drive in the network and is loading the initialisation information from the drive.
SC-OBS	The communication link between the Optidrive and Optipad has failed.
Select Language	Displayed in the language selection screen, with a list of available languages. Press the Navigate key to select a language
Select drive address xx	Displayed when selecting the address of the Optidrive that the Optipad should try to communicate with. Press the Stop key to select the drive address.
Select OptiPad ID	Displayed when selecting the Optipad ID (1 or 2) so that two Optipads can be connected to a single drive, or network of multiple drives.

Troubleshooting

Symptom	Explanation
Select drive address xx displayed after 'SCAN..' message	The Optipad failed to successfully communicate with the specified drive address in the network. Check that the RJ45 data cable connection is correct. Check that the drive with address XX is available in the network. If XX > 1 and only one Optipad is connected, then check the Optipad device number, make sure the number is 1.
Display 'Err-id' on power up	This normally occurs when there are two Optipad units in the same drive network and both of them have the same device number. Check and change the device number of one Optipad.
Display 'Err-id' during normal operation	This normally occurs when the user plugs a second Optipad into the drive network. Change the device number of one of the Optipad units.
Display 'SC-OBS'	Communication link between the Optipad and Optidrive has failed during operation. Check the electrical connection, and make sure the cable is connected correctly between the Optipad and the drive. Press 'STOP' button to enable the Optipad to search for the drive again.


Invertek Drives Ltd. Offa's Dyke Business Park, Welshpool, Powys SY21 8JF United Kingdom

Tel: +44 (0)1938 556868 Fax: +44 (0)1938 556869

www.invertekdrives.com

Read More About This Manual & Download PDF:

Documents / Resources

	<p>Invertek Drives ODE-2 Optipad TFT Remote Keypad [pdf] User Guide ODE-2, ODE-3, ODP-2, ODL-2, ODV-3, CV, ODE-2 Optipad TFT Remote Keypad, ODE-2, Optipad TFT Remote Keypad, TFT Remote Keypad, Remote Keypad, Keypad</p>
---	--

References

- ① [Variable Frequency Drive Manufacturer](#) | [Variable Speed Drives](#) | [AC Drives](#) | [Invertek Drives](#)