

**iStorage®**  
diskAshur3 Secure  
Portable Hard Drive



# iStorage diskAshur3 Secure Portable Hard Drive User Guide

[Home](#) » [iStorage](#) » iStorage diskAshur3 Secure Portable Hard Drive User Guide 

## Contents

- [1 iStorage diskAshur3 Secure Portable Hard Drive](#)
- [2 Overview](#)
- [3 Quick Start Guide](#)
- [4 First Time Use](#)
- [5 Unlocking diskAshur3](#)
- [6 Technical Support](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

**iStorage®**

**iStorage diskAshur3 Secure Portable Hard Drive**




## Specifications

- Encryption: Hardware encrypted
- PIN Protection: Yes
- Admin PIN Length: 8-64 digits

## Overview

1.



Red LED

2. Green LED

3. Blue LED

4. Numeric keys
5. Unlock
6. Shift button

## Quick Start Guide

Thank you for purchasing the new iStorage diskAshur3/diskAshur PRO3, an ultra-secure and easy to use, hardware encrypted, PIN protected portable HDD/SSD drive. Your drive is supplied in the 'Initial Shipment State' with no pre-set Admin PIN. An 8-64 digit Admin PIN must be configured as described under

**'First Time Use' before the drive can be used.**

### First Time Use




#### PIN Requirements:


- PINs must be a minimum length of 8 and maximum 64 digits.
- Cannot contain all sequential numbers (12345678 or 87654321).
- Cannot contain all repeating numbers (11111111).
- The SHIFT key can be used for additional combinations (e.g. SHIFT+1 is a separate value to just 1).

To configure an 8-64 digit Admin PIN and unlock the diskAshur3 / diskAshur PRO3 for the first time, please follow the simple steps in the table below.

1. Connect the drive to a powered USB port on your computer



2. Press and hold down both UNLOCK (  ) + 1 buttons
3. Enter a New Admin PIN (8-64 digits) and press the UNLOCK (  ) button once  
Blinking GREEN and solid BLUE LEDs switch to a GREEN blink then back to Blinking GREEN and solid BLUE LEDs
4. Re-enter your New Admin PIN and press the UNLOCK (  ) button once  
BLUE LED rapidly blinks then switches to a solid BLUE LED and finally to a solid GREEN LED indicating the Admin PIN has been successfully configured and the drive is unlocked and ready to be used



### Locking the diskAshur3 / diskAshur PRO3

To lock the drive, safely eject from your computer and then unplug from the USB port. If data is being written to the drive, ejecting the drive will result in incomplete data transfer and possible data corruption.


### Unlocking diskAshur3

To unlock the drive with the Admin PIN, please follow the simple steps in the table below.


1. Connect the drive to a powered USB port on your computer A solid RED LED turns on indicating the drive is in Standby State

2. In Standby State (solid RED LED) press the UNLOCK (  ) button once GREEN and BLUE LEDs blink together



3. With the GREEN and BLUE LEDs blinking together, enter your Admin PIN and press the UNLOCK (  ) button once

The GREEN LED blinks several times and then switches to a solid GREEN LED indicating the drive has been successfully unlocked as Admin and is ready to be used



Your diskAshur3 / diskAshur PRO3 can be easily configured with a host of security features. For detailed instructions please refer to the user manual. The user manual can be found pre-loaded on your drive and published on our website: <https://istorage-uk.com/product-documentation/>

## Technical Support

iStorage provides the following helpful resources:

- [www.istorage-uk.com](http://www.istorage-uk.com)
- [support@istorage-uk.com](mailto:support@istorage-uk.com)
- +44 (0) 20 8991 6260


iStorage Technical Support Specialists are available from 9:00 a.m. to 5:30 p.m. GMT – Monday through Friday.

## FAQs

### Q: What should I do if I forget my Admin PIN?

A: If you forget your Admin PIN, please contact customer support for assistance in resetting the PIN and accessing your drive.

## Documents / Resources

	<p><a href="#">iStorage diskAshur3 Secure Portable Hard Drive</a> [pdf] User Guide diskAshur3 Secure Portable Hard Drive, diskAshur3, Secure Portable Hard Drive, Portable Hard Drive, Hard Drive</p>
---	---

## References

- [🇬🇧 UK.COM | A Powerful Domain for the United Kingdom](#)
- [iS One moment, please...](#)
- [iS One moment, please...](#)
- [iS One moment, please...](#)
- [User Manual](#)

### [Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.